

[manuals.plus](#) /› [Nillkin](#) /› **Nillkin Medley Series Case for iPhone 12/12 Pro Instruction Manual**

## Nillkin Medley Series Case for iPhone 12/iPhone 12 Pro

# Nillkin Medley Series Case for iPhone 12/12 Pro Instruction Manual

### INTRODUCTION

This manual provides instructions for the Nillkin Medley Series Wireless Charge Friendly Armor Case with Assembled Kickstand, designed for the iPhone 12 and iPhone 12 Pro (6.1" 2020 models). This case offers robust protection and enhanced functionality through its integrated kickstand.

Please read these instructions carefully before installing and using your new phone case to ensure proper fit and function.

### PRODUCT FEATURES

- **Compatible Model:** Specifically designed for iPhone 12 and iPhone 12 Pro. Not compatible with other models.
- **Assembled Design:** The kickstand can be disassembled to enable wireless charging and reattached for comfortable phone use.
- **Useful Kickstand:** Features a quality zinc alloy plated kickstand that rotates 180 degrees for both horizontal and vertical hands-free viewing.
- **Strong Protection:** Constructed with a hard PC back for scratch resistance and built-in airbags with highly elastic molecules in four corners for drop cushioning.
- **Accurate Cutouts:** Precision cuts for volume keys, power button, charging port, speaker, and camera. Tactile buttons provide solid feedback.

# Impact resistant bumpers

Anti falling bumpers on the corner, defend your phone from any impact



Image: The Nillkin case for iPhone 12/12 Pro, showcasing its impact-resistant bumpers and integrated kickstand.

# Double protection from soft and hard ways



Image: An exploded view of the Nillkin case, demonstrating the dual-layer protection with a hard PC body and soft TPU edges.

# Camera protection

Raised bezel protects the camera from scratching.



# Accurate cutouts

Molded by original phone. Responsive buttons

Image: Close-up of the Nillkin case highlighting the raised bezel for camera protection and accurate cutouts for buttons and ports.

## SETUP AND INSTALLATION

- Clean Your Device:** Before installation, ensure your iPhone 12 or iPhone 12 Pro is clean and free of dust or debris.
- Insert Phone:** Gently align your iPhone with the case, starting with one side, then carefully press the phone into the case until it is fully seated. Ensure all edges are securely covered by the case's TPU frame.
- Kickstand Attachment:** The kickstand is designed to be assembled. If detached, align the kickstand's

base with the circular recess on the back of the case and press firmly until it clicks into place.



**Removable  
Not affect wireless charging**

Image: The Nillkin case with its kickstand deployed for viewing and the kickstand detached to facilitate wireless charging.

## OPERATING INSTRUCTIONS

### Using the Kickstand

To use the kickstand, gently pull it outwards from the back of the case. The kickstand can be rotated 180 degrees to support your iPhone in both horizontal (landscape) and vertical (portrait) orientations for hands-free viewing. Push the kickstand back into its recess when not in use to keep it flush with the case.

# Removable stand



Image: The Nillkin case demonstrating the rotating functionality of its integrated kickstand.

## Wireless Charging Compatibility

The Nillkin Medley Series case is designed to be wireless charging friendly. For optimal wireless charging performance, the assembled kickstand can be easily disassembled (removed) from the case. This allows the phone to lie flat on a wireless charger without obstruction. Reattach the kickstand after charging if desired.

## Product Overview Video

---

Video: Official Nillkin video demonstrating various iPhone 12 series cases, including the Medley case with its kickstand and protective features. This video provides a visual overview of the product line.

## MAINTENANCE

To maintain the appearance and functionality of your Nillkin case, follow these simple care instructions:

- **Cleaning:** Wipe the case regularly with a soft, damp cloth. For stubborn dirt, a mild soap solution can be used. Avoid harsh chemicals or abrasive cleaners, as these may damage the case material.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.
- **Inspection:** Periodically inspect the case for any signs of wear or damage, especially around the edges and the kickstand mechanism, to ensure continued protection.

## TROUBLESHOOTING

If you encounter any issues with your Nillkin Medley Series case, consider the following:

- **Case Not Fitting Properly:** Ensure you have the correct model (iPhone 12 or iPhone 12 Pro). Remove any screen protectors or other accessories that might interfere with the fit.
- **Kickstand Issues:** If the kickstand feels loose or does not deploy smoothly, check for any debris obstructing the mechanism. Ensure it is correctly assembled and clicked into place.
- **Wireless Charging Interruption:** Confirm the kickstand is removed when attempting wireless charging. Ensure your wireless charger is compatible with your iPhone model and is functioning correctly.

For further assistance, please refer to the support information provided in the **Warranty and Support** section.

## SPECIFICATIONS

Feature	Detail
Compatible Models	iPhone 12, iPhone 12 Pro
Material	Polycarbonate (PC), Thermoplastic Polyurethane (TPU), Zinc Alloy (for kickstand)
Color	Green (for this specific variant)
Product Dimensions	5.91 x 2.99 x 0.47 inches
Item Weight	3.13 ounces
Special Features	Heavy Duty Protection, Assembled Kickstand, Wireless Charging Friendly (with kickstand removed)
Manufacturer	NILLKIN
Date First Available	October 21, 2020

## WARRANTY AND SUPPORT

Nillkin products are designed for quality and durability. For information regarding product warranty, returns, or technical support, please refer to the official Nillkin website or contact the retailer from whom you

purchased the product. Keep your proof of purchase for any warranty claims.

For direct inquiries, you may visit the [Nillkin Store on Amazon](#).