

Carlsbro CLUB100

Carlsbro Electronic Drum Set CLUB100 User Manual

Model: CLUB100

INTRODUCTION

The Carlsbro Club100 is a compact and versatile 5-pad, 2-pedal electronic drum kit designed for beginners, younger drummers, and those seeking a space-saving practice solution. Its portability makes it ideal for studio use or live performance. This manual provides comprehensive instructions for setting up, operating, and maintaining your Club100 electronic drum set.

SAFETY INFORMATION

Please read and understand all safety instructions before operating the Carlsbro Club100 electronic drum set. Retain this manual for future reference.

- **Power Supply:** Use only the specified power adapter. Ensure the voltage matches the requirements of the drum module.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or excessive humidity. Avoid placing liquid containers near the drum set.
- **Ventilation:** Ensure proper ventilation around the module and pads to prevent overheating. Do not block ventilation openings.
- **Handling:** Handle all components with care. Avoid dropping or subjecting the unit to strong impacts.
- **Cleaning:** Clean the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Disassembly:** Do not attempt to disassemble or modify the unit. Refer all servicing to qualified personnel.
- **Children:** Keep small parts out of reach of children to prevent choking hazards.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- 1 × Commander 100 Sound Module
- 1 × 7" Snare pad
- 2 × 7" Tom pads

- 1 × 8" Hi-hat cymbal
- 1 × 8" Crash/ride cymbal
- 1 × Bass kick pedal
- 1 × Hi-hat controller pedal
- 1 × Height adjustable 3-legged drum rack
- 1 × Pair of drum sticks



Image: All components of the Carlsbro Club100 Electronic Drum Set, including pads, cymbals, pedals, module, and drum sticks.

SETUP

Follow these steps to assemble your Carlsbro Club100 electronic drum set:

1. **Assemble the Drum Rack:** Unfold and secure the height-adjustable 3-legged drum rack. Ensure all locking mechanisms are tightened for stability.
2. **Attach Pads and Cymbals:**
 - Mount the 7" snare pad to its designated arm on the rack.
 - Attach the two 7" tom pads to their respective arms.
 - Secure the 8" hi-hat cymbal and 8" crash/ride cymbal to their posts.
3. **Connect Pedals:** Place the bass kick pedal and hi-hat controller pedal on the floor in their playing positions.
4. **Mount the Commander 100 Module:** Attach the Commander 100 Sound Module to the central part of the drum rack using the provided mount.
5. **Connect Cables:** Connect each pad, cymbal, and pedal to the corresponding input on the Commander 100 Sound Module using the included cables. Refer to the labels on the module for correct connections (e.g., "Snare," "Tom1," "Hi-Hat," "Kick," etc.).
6. **Power Connection:** Connect the power adapter to the "DC IN" port on the module and then plug it into a power outlet.
7. **Audio Output:** For sound, connect headphones to the "PHONE" output or an external amplifier/speaker system to the "OUTPUT" (mono line output) or "AUX" input if playing along to external audio.



Image: Overhead view of the assembled drum kit, showing pad and cymbal placement.



Image: A person seated and playing the Carlsbro Club100 Electronic Drum Set, demonstrating typical usage posture.

OPERATING THE COMMANDER 100 MODULE

The Commander 100 Sound Module is the brain of your electronic drum set. Familiarize yourself with its functions:



Image: Front panel of the Commander 100 Sound Module, showing display and controls.



Image: Rear view of the Commander 100 Sound Module, highlighting the various input and output ports.

Module Features:

- **Voices:** Access 108 high-quality percussion voices. Use the navigation buttons to select different sounds.
- **Drum Kits:**
 - **10 Preset Drum Kits:** Ready-to-use drum configurations for various music styles.
 - **2 User Drum Kits:** Create and save your own personalized drum kit configurations by assigning different voices to each pad.
- **Demo Songs:** Play along to 10 built-in demo songs. Use the "SONG" button to browse and select.
- **Recording and Playback:** The module features a record and playback facility.
 - Press the "RECORD" button to start recording your performance.
 - Press "START/STOP" to end recording and then again to play back your recorded track.
- **Adjustable Metronome:** Practice with a built-in metronome. Adjust the tempo using the dedicated controls.
- **Aux Input:** Connect an external audio device (e.g., smartphone, MP3 player) to the "AUX IN" socket to play along to your favorite songs.

- **Line Output:** Use the "OUTPUT" jack to connect the module to an external amplifier, mixer, or recording interface.
- **Headphone Output:** Connect headphones to the "PHONE" jack for private practice.
- **MIDI OUT:** Connect the module to other MIDI-compatible devices or computer software for advanced control and recording.

Basic Operation:

- **Power On/Off:** Use the "ON/OFF" switch to power the module.
- **Volume Control:** Adjust the overall volume using the "VOLUME" knob.
- **Kit Selection:** Press the "KIT" button and use the +/- buttons to cycle through preset and user drum kits.
- **Voice Selection:** Press the "VOICE" button and use the +/- buttons to select individual percussion voices.
- **Song Selection:** Press the "SONG" button and use the +/- buttons to select a demo song. Press "START/STOP" to play/pause.
- **Tempo Adjustment:** Press the "TEMPO" button and use the +/- buttons to adjust the metronome or song tempo.
- **Setup/Page:** Use these buttons to navigate through advanced settings and parameters within the module. Refer to the module's on-screen display for specific options.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your Carlsbro Club100 electronic drum set.

- **Cleaning:** Regularly wipe down the pads, cymbals, module, and rack with a soft, dry, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water, but ensure no moisture enters the electronic components.
- **Storage:** When not in use for extended periods, store the drum set in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Management:** Avoid kinking or excessively bending cables. Secure them neatly to prevent damage and tripping hazards.
- **Pad Care:** Avoid striking the pads with excessive force, which can reduce their lifespan. Use the provided drum sticks or similar non-abrasive sticks.
- **Pedal Care:** Keep the pedals free of dust and debris. Periodically check for any loose screws or connections.

TROUBLESHOOTING

If you encounter issues with your Carlsbro Club100, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from module.	Power off; Volume too low; Headphones/speakers not connected or faulty; Incorrect output selected.	Ensure power is on. Increase volume. Check headphone/speaker connections. Verify correct output (PHONE/OUTPUT) is used.
Specific pad/cymbal not producing sound.	Cable loose or disconnected; Pad/cymbal faulty; Module input faulty.	Check cable connection to both the pad/cymbal and the module. Try swapping cables with a working pad to isolate the issue.
Unresponsive pedals.	Pedal cable loose or disconnected; Pedal faulty.	Ensure pedal cables are securely connected to the module. Check for any physical damage to the pedals.

Problem	Possible Cause	Solution
Distorted sound.	Volume too high (clipping); Faulty cable; External amplifier issues.	Reduce module volume. Try a different audio cable. Check external amplifier settings and connections.
Module not powering on.	Power adapter not connected; Power outlet faulty; Power adapter faulty.	Ensure power adapter is fully plugged into module and wall outlet. Try a different outlet.

If the problem persists after trying these solutions, please contact Carlsbro customer support for further assistance.

SPECIFICATIONS

Key technical specifications for the Carlsbro Club100 Electronic Drum Set:

- **Model Number:** CLUB100
- **Item Weight:** 12.3 ounces
- **Product Dimensions:** 24.8 x 11.22 x 22.05 inches
- **Color:** Black
- **Material:** Plastic
- **Power Source:** Corded Electric
- **Output Wattage:** 200 Watts (referring to compatible amplifiers, not the module itself)
- **Connector Type:** 3.5mm Jack (for Aux/Headphone)
- **Compatible Devices:** Drum (referring to the kit's purpose)
- **Sound Module:** Commander 100
- **Percussion Voices:** 108 high quality
- **Drum Kits:** 10 preset, 2 user defined
- **Demo Songs:** 10
- **Features:** Recording and playback, Adjustable Metronome, Aux input, Line output, Headphone output, MIDI OUT
- **Kit Components:** 1x Commander 100 Sound Module, 1x 7" Snare pad, 2x 7" Tom pads, 1x 8" Hi-hat cymbal, 1x 8" Crash/ride cymbal, 1x Bass kick pedal, 1x Hi-hat controller pedal, 1x Height adjustable 3-legged drum rack, 1x Pair of drum sticks

WARRANTY AND SUPPORT

Carlsbro products are manufactured to high quality standards. For information regarding warranty coverage, technical support, or service, please refer to the warranty card included with your product or visit the official Carlsbro website.

Customer Support: For assistance with setup, operation, or troubleshooting, please contact Carlsbro customer support. Contact details can typically be found on the product packaging or the official brand website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question