

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Lexon LA124N9

Lexon MINO T Portable Bluetooth Speaker User Manual

Model: LA124N9

INTRODUCTION

The Lexon MINO T is a compact and versatile portable Bluetooth speaker designed for both indoor and outdoor use. Featuring a durable, water-resistant design and a convenient carabiner clip, it delivers balanced audio with a passive bass system. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your MINO T speaker.



The Lexon MINO T is designed as a portable Bluetooth speaker for various environments.

WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- Lexon MINO T Portable Bluetooth Speaker
- USB-C Charging Cable
- User Manual (this document)



The Lexon MINO T speaker and its included accessories are packaged as shown.

SETUP

1. Charging the Speaker

Before first use, fully charge your Lexon MINO T speaker. Use the provided USB-C cable to connect the speaker to a compatible USB power source (e.g., computer USB port, wall adapter). The charging indicator light will show the charging status.

- Charging Time: Approximately 2 hours for a full charge.
- Battery Life: Up to 5 hours of continuous playtime on a full charge.



The Lexon MINO T can be charged using its dedicated docking station or directly via USB-C cable.

2. Bluetooth Pairing

To connect your MINO T speaker to a device:

- 1. Power On:** Press and hold the power button on the speaker until you hear an audible cue or see an indicator light.
- 2. Activate Bluetooth:** Ensure Bluetooth is enabled on your smartphone, tablet, or laptop.
- 3. Search for Devices:** On your device, search for available Bluetooth devices.
- 4. Select 'MINO T':** From the list, select 'MINO T' to initiate pairing.

5. **Confirm Connection:** Once paired, the speaker will provide an audible confirmation.

The speaker will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the power button.
- **Power Off:** Press and hold the power button again.

Audio Playback

Control music playback directly from your connected device. The MINO T features a passive bass system for enhanced sound quality.

SOUND THAT MARVELS

The Mino T has been carefully engineered with a passive bass system.



The MINO T is engineered with a passive bass system for a balanced audio experience.

Hands-Free Calling

When connected to a smartphone, the MINO T can be used for hands-free calls.

- **Answer/End Call:** Use the touch control on the speaker (refer to specific button functions in the quick start guide if available).
- **Reject Call:** Use the touch control on the speaker.

Portability and Mounting

The integrated carabiner clip allows for easy attachment to bags, bikes, or clothing, making it ideal for outdoor activities.



The carabiner clip allows for convenient attachment to your belt loop.



Easily clip the speaker to your bicycle for music on the go.



The speaker's water-resistant design makes it suitable for outdoor adventures, even in light rain.

MAINTENANCE

Cleaning

To clean your Lexon MINO T speaker, use a soft, dry cloth. Do not use abrasive cleaners, solvents, or strong chemicals, as these may damage the surface or internal components.

Water Resistance (IPX4)

The MINO T speaker is rated IPX4 water resistant, meaning it is protected against splashing water from any direction. This makes it suitable for use in light rain or near splashes. **It is not designed to be submerged in water.** Ensure the USB-C port cover is securely closed when exposed to water.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.

TROUBLESHOOTING

If you encounter issues with your Lexon MINO T speaker, please refer to the following common solutions:


Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully using the provided USB-C cable.

Problem	Possible Cause	Solution
Cannot pair with Bluetooth device.	Bluetooth is off on your device; speaker is not in pairing mode; too far from device.	Ensure Bluetooth is on. Power cycle the speaker to enter pairing mode. Move speaker closer to your device (within 10 meters).
No sound or distorted sound.	Volume too low; speaker not connected; audio source issue.	Increase volume on both speaker and connected device. Re-pair the speaker. Test with a different audio source.
Short battery life.	Speaker not fully charged; high volume usage.	Ensure speaker is fully charged. Reduce volume to extend battery life.

SPECIFICATIONS

Detailed technical specifications for the Lexon MINO T Portable Bluetooth Speaker:

Model Name	MINO T
Item Model Number	LA124N9
Material	Acrylonitrile Butadiene Styrene (ABS)
Color	Black
Product Dimensions	2.08"D x 1.14"W x 3.81"H (5.28 cm D x 2.9 cm W x 9.68 cm H)
Item Weight	4.32 ounces (122.47 grams)
Speaker Type	Outdoor
Connectivity Technology	Bluetooth, USB
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters (33 feet)
Power Source	Battery Powered (1 Lithium Ion battery required)
Battery Life	5 Hours
Charging Time	2 Hours
Speaker Maximum Output Power	5 Watts
Audio Output Mode	Stereo
Control Method	Touch
Water Resistance Level	IPX4 (Water Resistant)
Mounting Type	Clip On, Freestanding



Dimensions of the Lexon MINO T speaker.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Lexon website or contact the retailer where you purchased the product. Keep your proof of purchase for any warranty claims.

You can also visit the Lexon Store on Amazon for more product information and support resources: [Lexon Store](#)

