



Manuals.plus /

› Infantino /

› Infantino Music & Lights 3-in-1 Discovery Seat & Booster Instruction Manual

## Infantino B08LMDMTYL

# Infantino Music & Lights 3-in-1 Discovery Seat & Booster Instruction Manual

Brand: Infantino | Model: B08LMDMTYL

## INTRODUCTION

---

The Infantino Music & Lights 3-in-1 Discovery Seat & Booster is a versatile infant booster seat designed to adapt as your child grows. It functions as an interactive play space, a practical snack seat, and a secure toddler booster for dining. This manual provides essential information for safe and effective use.

## Key Features

- **3-in-1 Design:** Converts from a baby activity center to a snack seat and toddler booster, suitable for ages 4 months to 4 years (up to 33 lbs).
- **Built-in Music, Lights & Toys:** Features a light-up piano with 20 songs and sounds, plus interactive toy pods to stimulate sensory exploration and fine motor skills.
- **Hidden Snack Tray:** Toy pods slide apart to reveal a snack tray with a built-in cup holder for easy transitions from play to feeding.
- **Comfortable & Secure:** Includes a soft, removable, wipe-clean foam cushion, a 3-point harness, and chair straps for safety.
- **Portable:** Lightweight and compact design makes it ideal for home use or travel.

## SETUP AND ASSEMBLY

---

### Unboxing Tips

Upon unboxing, ensure all components are present. The seat cushion may be located within a cardboard divider inside the packaging, and the straps might be packaged beneath the booster unit.

# unboxing tips

## seat cushion

may be between a cardboard divider within the packaging



## straps

may be packaged beneath the booster

*Image: Visual guide showing the location of the seat cushion and straps within the packaging for easy retrieval.*

### Attaching the Activity Tray

The activity tray, featuring the light-up piano and various toys, attaches to the front of the seat. Ensure it clicks securely into place on both sides.

### Converting to Snack Tray

To access the snack tray, slide the two toy pods of the activity tray apart. This reveals a flat surface with a built-in cup holder. To revert to activity mode, slide the toy pods back together until they lock.

### Securing to a Chair (Booster Mode)

For booster seat use, utilize the included chair straps. Securely fasten the straps around the back and bottom of a standard dining or kitchen chair. Always ensure the booster seat is stable and properly attached before placing your child in it.

# 3 ways to use



**1** Seated positioner



**2** Snack time booster



**3** Table booster seat



**+** Light up piano

*Image: Illustrates the three primary uses: seated positioner, snack time booster, and toddler booster seat.*

## OPERATING INSTRUCTIONS

### Activity Center Features

The activity tray includes a light-up piano that plays 20 songs and sounds. Encourage your child to press the colorful keys and interact with the various spinning gears, beads, and other tactile elements to develop fine motor skills and sensory exploration.

*Video: Demonstrates the interactive light-up piano and various toy features of the activity center.*

### Snack Tray Use

When it's time for snacks or meals, simply slide the toy pods apart to reveal the integrated snack tray. This allows for seamless transitions without needing to remove your child from the seat. The tray is designed for easy cleaning.



*Image: A baby happily using the booster seat with the snack tray extended, showing its practical use during meal times.*

## **Booster Seat Functionality**

The seat can be used as a standalone floor seat for infants learning to sit up, or as a booster seat securely attached to an adult chair for toddlers during family meals. Always use the 3-point harness to keep your child safely seated.



*Image: A baby comfortably seated in the booster seat, demonstrating its use as a secure seating option.*

## **CARE AND MAINTENANCE**

---

### **Cleaning Instructions**

The soft foam cushion is wipe-clean for easy maintenance. For the plastic components, wipe with a damp cloth and mild soap. Ensure all parts are dry before reassembly or next use. Do not immerse electronic components in water.



*Image: A person wiping down the booster seat, highlighting its easy-to-clean design.*

## **TROUBLESHOOTING**

---

No specific troubleshooting steps are provided in the product information. If you encounter any issues with the product, please ensure all parts are correctly assembled and batteries (if applicable) are properly installed. For persistent problems, refer to the manufacturer's website or contact customer support for assistance.

## **PRODUCT SPECIFICATIONS**

---

Feature	Specification
Brand	Infantino
Model Number	B08LMDMTYL
Age Range Description	Baby
Maximum Weight Recommendation	33 Pounds
Assembly Required	Yes
Item Dimensions (D x W x H)	4.19"D x 19.2"W x 10.5"H
Item Weight	5 Pounds
Color	Lavender
Material Type	Plastic
Is Portable	Yes

## front view



Image: Front view of the booster seat with key dimensions (depth, width, height) indicated.

## top view




Image: Top view of the booster seat with key dimensions (depth, width) indicated.

## IMPORTANT SAFETY INFORMATION

---

- Always use the 3-point harness to secure your child in the seat.
- When using as a booster, always use the chair straps to securely attach the seat to an adult chair.
- Never leave your child unattended in the discovery seat or booster.
- Ensure the product is placed on a flat, stable surface when used as a floor seat.
- Do not use this product if any components are damaged or missing.
- Maximum weight capacity is 33 lbs. Do not exceed this limit.

## WARRANTY AND CUSTOMER SUPPORT

---

Please refer to the product packaging or the official Infantino website for detailed warranty information and customer support contacts. Keep your purchase receipt for warranty claims.