

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [HAVERLAND](#) /

› [HAVERLAND COMPACT6 Portable Dry Thermal Emitter 900W User Manual](#)

HAVERLAND COMPACT6

HAVERLAND COMPACT6 Portable Dry Thermal Emitter 900W User Manual

Model: COMPACT6

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the HAVERLAND COMPACT6 Portable Dry Thermal Emitter. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the appliance is placed on a stable, level surface.
- Do not cover the heater. Overheating can occur if the heater is covered.
- Keep flammable materials such as furniture, curtains, and bedding at least 1 meter (3 feet) from the front and sides of the heater.
- Do not use this heater in the immediate surroundings of a bath, a shower, or a swimming pool.
- Do not insert any objects into the ventilation or exhaust openings as this may cause electric shock, fire, or damage to the heater.
- Unplug the heater when not in use.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. PRODUCT OVERVIEW

The HAVERLAND COMPACT6 is a portable dry thermal emitter designed for efficient and programmable heating. It features an electronic control panel with an LCD display for easy operation and temperature management. The unit is designed for floor mounting and comes with a remote control for convenient adjustments.



Image 2.1: Front view of the HAVERLAND COMPACT6 Portable Dry Thermal Emitter, showing its white finish, vertical heating elements, and integrated LCD control panel on the right side.



Image 2.2: Remote control for the HAVERLAND COMPACT6, featuring power, temperature adjustment, mode selection (sun, snowflake, moon), and program buttons.

3. SETUP

Follow these steps to set up your HAVERLAND COMPACT6 emitter:

1. **Unpacking:** Carefully remove the emitter from its packaging. Retain packaging for future storage or transport.

2. **Placement:** Place the emitter on a firm, level surface. Ensure there is adequate clearance around the unit for proper air circulation (at least 1 meter from walls, furniture, and curtains). The unit is designed for floor mounting.
3. **Power Connection:** Ensure the power cord is fully extended and plug it into a suitable electrical outlet (220V). Do not use extension cords or power strips.
4. **Initial Power On:** Press the power button on the control panel or remote control to turn on the unit. The LCD display will illuminate.

4. OPERATING INSTRUCTIONS

The HAVERLAND COMPACT6 offers various operating modes and programming options for optimal comfort and energy efficiency.

4.1 Control Panel and Remote Control

The emitter can be controlled using the integrated LCD control panel or the provided remote control. Both offer similar functionalities.

4.2 Basic Operation

- **Power On/Off:** Press the **Power** button (*red circle with vertical line*) to turn the emitter on or off.
- **Temperature Adjustment:** Use the **Up** (*triangle pointing up*) and **Down** (*triangle pointing down*) buttons to set your desired temperature. The current temperature setting will be displayed on the LCD.
- **Mode Selection:** Press the **Mode** button (often represented by a *sun, moon, or snowflake icon*) to cycle through available operating modes:
 - **Comfort Mode (Sun icon):** Maintains a comfortable temperature.
 - **Economy Mode (Moon icon):** Maintains a lower, energy-saving temperature.
 - **Anti-frost Mode (Snowflake icon):** Prevents the room temperature from dropping below a certain point (e.g., 5°C) to protect against freezing.

4.3 Programming

The COMPACT6 features programmable settings to customize heating schedules. Refer to the detailed programming section in the full manual for specific instructions on setting daily or weekly programs. Generally, this involves:

1. Pressing the **Program (P)** button.
2. Using the **Up/Down** buttons to select the day and time.
3. Selecting the desired operating mode (Comfort, Economy, Anti-frost) for each time slot.
4. Confirming your settings.

5. MAINTENANCE

Regular maintenance ensures the longevity and efficient operation of your HAVERLAND COMPACT6 emitter.

- **Cleaning:** Before cleaning, always unplug the emitter and allow it to cool down completely. Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners, solvents, or harsh chemicals.
- **Storage:** If storing the emitter for an extended period, ensure it is clean and dry. Store it in its original packaging in a cool, dry place.
- **No Internal Maintenance:** The emitter does not require any internal maintenance. Do not attempt to

open or repair the unit yourself. Contact qualified service personnel for any repairs.

6. TROUBLESHOOTING

If you encounter issues with your HAVERLAND COMPACT6, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Emitter does not turn on.	No power supply. Unit is unplugged. Power button not pressed.	Check if the unit is properly plugged into a working outlet. Press the power button. Check circuit breaker.
Emitter is on but not heating.	Temperature setting is too low. Anti-frost mode is active.	Increase the desired temperature setting. Change the operating mode from Anti-frost to Comfort or Economy.
Remote control not working.	Batteries are depleted. Obstruction between remote and emitter.	Replace batteries in the remote control. Ensure a clear line of sight to the emitter's receiver.
Unusual noises or smells.	Dust accumulation. Internal fault.	Unplug the unit and clean the exterior. If the problem persists, discontinue use and contact customer support.

If the problem persists after attempting these solutions, please contact HAVERLAND customer support.

7. SPECIFICATIONS

Key technical specifications for the HAVERLAND COMPACT6 Portable Dry Thermal Emitter:

- **Brand:** HAVERLAND
- **Model:** COMPACT6
- **Type:** Portable Dry Thermal Emitter
- **Power:** 900 W (Wattage derived from product title)
- **Voltage:** 220 Volts
- **Power Source:** Corded Electric
- **Control:** Electronic, Programmable LCD
- **Form Factor:** Pedestal
- **Mounting Compatibility:** Floor Mount
- **Product Weight:** Approximately 1 kg

8. WARRANTY AND SUPPORT

Specific warranty details are not provided in this document. For information regarding the warranty period, terms, and conditions for your HAVERLAND COMPACT6 emitter, please refer to the warranty card included with your purchase or visit the official HAVERLAND website.

For technical support, spare parts, or service inquiries, please contact HAVERLAND customer service through their official channels. Always have your model number (COMPACT6) and purchase date ready when contacting support.

You can visit the HAVERLAND store on Amazon for more information:[HAVERLAND Store](#)