

[Manuals.plus](#) /

› [Feit Electric](#) /

› Feit Electric LED A19 Dusk to Dawn Light Bulb Instruction Manual

## Feit Electric A800/927CA/DD/LEDI/4

# Feit Electric LED A19 Dusk to Dawn Light Bulb Instruction Manual

## INTRODUCTION

---

This instruction manual provides important information for the installation, operation, and maintenance of your Feit Electric LED A19 Dusk to Dawn Light Bulb. This bulb features a built-in light sensor for automatic operation, turning on at dusk and off at dawn, offering convenience and energy efficiency.

The bulb provides 800 lumens of 2700K soft white light, equivalent to a 60W incandescent bulb, while consuming only 8.8W. It is designed for a long lifespan of up to 15,000 hours.



*Image: Feit Electric LED A19 Dusk to Dawn Light Bulb, showcasing its standard A19 shape and E26 base.*

## SAFETY INFORMATION

---

Please read and understand all instructions before installation and use. Retain this manual for future reference.

- No specific safety warnings are applicable beyond standard electrical safety practices.
- Ensure power is turned off at the switch and circuit breaker before installation or removal.
- Do not use with dimmers unless explicitly stated as dimmable. This bulb is non-dimmable.
- Suitable for indoor and outdoor use in appropriate fixtures.

## SETUP AND INSTALLATION

---

1. **Turn off Power:** Before replacing any light bulb, ensure the power to the fixture is turned off at the wall switch and the main circuit breaker to prevent electrical shock.
2. **Remove Old Bulb:** Carefully unscrew the existing light bulb from the fixture.
3. **Install New Bulb:** Screw the Feit Electric LED A19 Dusk to Dawn Light Bulb into the standard E26 medium base socket until it is finger-tight. Do not overtighten.

4. **Sensor Placement:** Ensure the built-in light sensor on the bulb is not obstructed by the fixture housing or any other objects. The sensor needs clear access to ambient light to function correctly.
5. **Restore Power:** Turn the power back on at the circuit breaker and the wall switch.



*Image: Close-up view of the Feit Electric LED A19 bulb, highlighting the integrated light sensor.*

Your browser does not support the video tag.

*Video: Demonstration of the Feit Electric Dusk to Dawn Light Bulb's automatic functionality in an outdoor fixture.*

## **OPERATING INSTRUCTIONS**

---

The Feit Electric LED A19 Dusk to Dawn Light Bulb operates automatically based on ambient light levels.

- Once installed and power is supplied to the fixture, the bulb will automatically turn on when the surrounding light level drops (dusk).
- The bulb will automatically turn off when the surrounding light level increases (dawn).
- For continuous automatic operation, ensure the light fixture's wall switch remains in the 'ON' position.



*Image: An exterior view of a house at night, demonstrating the effective illumination provided by the Feit Electric Dusk to Dawn bulbs.*

## MAINTENANCE

---

This LED light bulb requires minimal maintenance.

- **Cleaning:** Ensure the power is off before cleaning. Wipe the bulb with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **No User-Serviceable Parts:** The bulb contains no user-serviceable parts. Do not attempt to open or repair the bulb.
- **Sensor Care:** Periodically check that the light sensor is clean and free from dust or debris to ensure optimal performance.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Bulb does not turn on at dusk or off at dawn.	Light switch is off; sensor is obstructed; insufficient ambient light change.	Ensure the light switch is always in the 'ON' position. Check that the sensor is not blocked by the fixture or other objects. Relocate the fixture if necessary to an area with clear light exposure.
Bulb flickers or cycles on/off rapidly.	Sensor interference from nearby light sources (e.g., streetlights, other bulbs); unstable power supply.	Ensure the bulb is not exposed to direct light from other sources that might confuse the sensor. Check the electrical connection for stability.
Light output is not as expected (too dim).	Incorrect expectation of brightness; bulb defect.	Confirm the bulb's specifications (800 lumens, 60W equivalent) meet your requirements. If the issue persists, contact customer support.

## SPECIFICATIONS

Feature	Detail
Brand	Feit Electric
Model Number	A800/927CA/DD/LED/4
Light Type	LED
Special Feature	Light Sensor (Dusk-to-Dawn)
Wattage	8.8 watts
Incandescent Equivalent	60 Watts
Bulb Shape Size	A19
Bulb Base	E26 Medium Base
Light Color	Soft White
Color Temperature	2700 Kelvin
White Brightness	800 Lumens
Voltage	120 Volts
Indoor/Outdoor Usage	Indoor, Outdoor
Power Source	AC
Color Rendering Index (CRI)	90
Light Source Operating Life	15,000 Hours
Item Weight	4 ounces
Item Dimensions (W x H)	2.3"W x 1"H

Feature	Detail
Material Type	Plastic
Style Name	Dusk-To-Dawn

## WARRANTY INFORMATION

---

This Feit Electric LED A19 Dusk to Dawn Light Bulb is covered by a **1-year manufacturer warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use.

For warranty claims or further details, please refer to the official Feit Electric website or contact their customer support.

## SUPPORT AND CONTACT

---

If you encounter any issues or have questions regarding your Feit Electric LED A19 Dusk to Dawn Light Bulb that are not addressed in this manual, please contact Feit Electric customer support.

- **Online Support:** Visit the official Feit Electric website for FAQs, product information, and support resources.
- **Manufacturer's Store:** You can find more products and information at the [Feit Electric Amazon Store](#).