

iFrogz Impulse 2 (Model 304103570)

iFrogz Impulse 2 Over-Ear Bluetooth Headphones User Manual

INTRODUCTION

This manual provides comprehensive instructions for the proper use, setup, and maintenance of your iFrogz Impulse 2 Over-Ear Bluetooth Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.

PACKAGE CONTENTS

Verify that all items are present in the package:

- iFrogz Impulse 2 Over-Ear Bluetooth Headphones
- USB Charging Cable
- User Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your headphones.



Image: iFrogz Impulse 2 Over-Ear Bluetooth Headphones. This image displays the headphones in black, showcasing the over-ear design and the iFrogz logo on the earcups.

Controls and Ports:

- **Power/Multi-function Button:** Used for powering on/off, play/pause, answering/ending calls, and activating voice assistant.
- **Volume Up Button:** Increases volume, long press for next track.
- **Volume Down Button:** Decreases volume, long press for previous track.
- **Charging Port:** Connects the USB charging cable.
- **Microphone:** For hands-free calls.

1. Charging the Headphones

1. Connect the small end of the USB charging cable to the charging port on the headphones.
2. Connect the larger end of the USB charging cable to a powered USB port (e.g., computer, wall adapter).
3. The LED indicator will illuminate during charging and turn off when fully charged.
4. A full charge provides approximately 20 hours of playback time.

2. Bluetooth Pairing

1. Ensure the headphones are fully charged.
2. Press and hold the Power/Multi-function Button for approximately 3-5 seconds until the LED indicator flashes blue and red, indicating pairing mode.
3. On your Bluetooth-enabled device (smartphone, tablet, computer), navigate to the Bluetooth settings.
4. Turn on Bluetooth and search for available devices.
5. Select "iFrogz Impulse 2" from the list of found devices.
6. Once paired, the LED indicator on the headphones will flash blue periodically, and your device will confirm the connection.
7. The headphones will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Power On/Off

- **Power On:** Press and hold the Power/Multi-function Button for 2 seconds. The LED will flash blue.
- **Power Off:** Press and hold the Power/Multi-function Button for 3 seconds. The LED will turn off.

Music Playback

- **Play/Pause:** Press the Power/Multi-function Button once.
- **Volume Up:** Press the Volume Up Button.
- **Volume Down:** Press the Volume Down Button.
- **Next Track:** Press and hold the Volume Up Button for 2 seconds.
- **Previous Track:** Press and hold the Volume Down Button for 2 seconds.

Call Management

- **Answer/End Call:** Press the Power/Multi-function Button once.
- **Reject Call:** Press and hold the Power/Multi-function Button for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Double-press the Power/Multi-function Button.

MAINTENANCE

Cleaning

- Wipe the headphones with a soft, dry, lint-free cloth.
- Do not use abrasive cleaners, solvents, or spray cleaners.
- Keep the charging port free of dust and debris.

Storage

- Store the headphones in a cool, dry place away from extreme temperatures and direct sunlight.
- When not in use for extended periods, charge the headphones periodically to maintain battery health.
- The headphones feature a foldable design for compact storage.

TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

Problem	Solution
Headphones will not power on.	Ensure the headphones are charged. Connect to a power source using the USB cable.
Cannot pair with a device.	Ensure headphones are in pairing mode (flashing blue/red LED). Turn off and on Bluetooth on your device. Forget previous pairings on your device and try again. Ensure headphones are within range.
No sound or low volume.	Check volume levels on both the headphones and the connected device. Ensure the headphones are properly paired. Try playing different audio.
Poor sound quality.	Ensure the headphones are within Bluetooth range of your device. Avoid obstacles between the headphones and the device. Check the audio source quality.

SPECIFICATIONS

Feature	Detail
Model Name	Impulse 2
Model Number	304103570
Connectivity	Bluetooth 5.0 (Wireless)
Ear Placement	Over-Ear (around the ear)
Audio Driver Type	Dynamic Driver
Audio Driver Size	40 mm
Battery Life	Up to 20 Hours
Noise Control	Sound Isolation
Special Features	Foldable, Microphone Included, Volume Control
Item Weight	15.8 ounces (0.45 Kilograms)
Color	Black

Feature	Detail
UPC	848467099058

SAFETY INFORMATION

- Do not expose the headphones to extreme temperatures, humidity, or liquids.
- Avoid dropping or subjecting the headphones to strong impacts.
- Do not attempt to disassemble or modify the headphones. This will void the warranty.
- Listen at moderate volume levels to prevent hearing damage.
- Use caution when using headphones in situations requiring awareness of your surroundings.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the official iFrogz website or contact their customer service directly. Keep your proof of purchase for warranty claims.