

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [aooshine](#) /

› [Aooshine Grey Touch Control Bedside Table Lamp with USB-C, USB-A, and Dual AC Outlets User Manual](#)

## aooshine Grey Touch Lamp with USB & Outlets

# Aooshine Grey Touch Control Bedside Table Lamp User Manual

Model: Grey Touch Lamp with USB & Outlets

Brand: aooshine

## 1. INTRODUCTION

Thank you for choosing the Aooshine Grey Touch Control Bedside Table Lamp. This lamp is designed to provide versatile lighting and convenient charging options for your bedroom, living room, or office. It features 3-way dimmable touch control, USB-A and USB-C charging ports, and dual AC outlets. Please read this manual thoroughly before use to ensure proper operation and safety.

## 2. SAFETY INSTRUCTIONS

- Ensure the lamp is unplugged before assembly, cleaning, or bulb replacement.
- Do not use the lamp in wet or damp environments to prevent electric shock.
- Use only the specified bulb type (E26 base LED bulb, 6W, 3000K) or an equivalent.
- Keep the lamp away from heat sources and direct sunlight.
- Do not attempt to disassemble or repair the lamp yourself. Contact customer support if needed.
- Ensure the power cord is not pinched or damaged.

## 3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Lamp Base with integrated USB-A, USB-C, and Dual AC Outlets
- Lamp Pole
- Fabric Lampshade (Grey)
- E26 LED Dimmable Bulb (6W, 3000K)
- User Manual

## 4. SETUP INSTRUCTIONS

Follow these steps to assemble your Aooshine Bedside Table Lamp:

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Attach Lamp Pole:** Screw the lamp pole securely into the lamp base.
3. **Install Bulb:** Screw the provided E26 LED bulb into the lamp socket.
4. **Place Lampshade:** Position the fabric lampshade over the lamp pole and secure it.
5. **Connect to Power:** Plug the lamp's power cord into a standard AC outlet.



Figure 1: Fully assembled lamp with charging devices.





Figure 2: Lamp base and shade structure before final assembly.

## 5. OPERATING INSTRUCTIONS

### 5.1. Touch Control for Lighting

The lamp features a smart touch-sensitive sensor for easy control. Simply tap any metal part of the lamp base or pole to adjust the brightness.

- **First Touch:** Turns on the lamp at the lowest brightness setting (Night Light).
- **Second Touch:** Increases brightness to medium (Comfortable Light for general use).
- **Third Touch:** Activates the brightest setting (Reading Lamp).
- **Fourth Touch:** Turns the lamp off.

## 3-Way Dimmable

### Touch Control



Figure 3: Demonstrating the 3-way dimmable touch control.

### 5.2. Charging Ports and AC Outlets

The lamp base is equipped with convenient charging options that function whether the lamp is on or off.

- **USB-A Port (5V/2.1A):** Connect your devices using a standard USB-A cable for charging.
- **USB-C Port (5V/2.1A):** Connect your USB-C compatible devices for charging.
- **Dual AC Outlets (120V):** Plug in other electronic devices that require a standard wall outlet.



## 4-in-1 Convenient Charger

Convenient to power 4 devices at the same time no matter the light is on or off.



Figure 4: Overview of the 4-in-1 charging capabilities.

Video 1: Demonstrates the touch control and charging ports (USB-C & A) for bedroom, living room, and office use.

Video 2: Highlights the bedside lamp's USB port and touch control features.

## 6. MAINTENANCE

- Cleaning:** Wipe the lamp base and pole with a soft, dry cloth. Do not use abrasive cleaners or solvents. The fabric lampshade can be gently dusted.
- Bulb Replacement:** Ensure the lamp is unplugged. Allow the bulb to cool completely before replacing it. Use an E26 base LED bulb with a maximum wattage of 6W.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Not plugged in, loose bulb, faulty bulb, power outage.	Check power connection, tighten bulb, replace bulb, check power supply.

Problem	Possible Cause	Solution
Touch control is unresponsive.	Lamp is not properly grounded, electrical interference.	Ensure lamp is on a stable surface and plugged into a grounded outlet. Try moving away from other electronics.
Charging ports are not working.	Device cable is faulty, device is not compatible, power issue.	Try a different charging cable. Ensure the lamp is plugged in. Check device compatibility.
Light flickers.	Loose bulb, incompatible bulb, unstable power supply.	Tighten bulb, ensure correct bulb type is used, check power outlet.

## 8. SPECIFICATIONS

Feature	Detail
Brand	aooshine
Model Number	Grey Touch Lamp with USB & Outlets
Dimensions (D x W x H)	4.72"D x 4.72"W x 15.35"H
Item Weight	0.635 ounces
Finish Type	Sliver Metal
Base Material	Silver
Shade Color	Grey
Shade Material	Fabric
Switch Type	Touch
Special Feature	3-Way Dimmable, Dual AC Outlets
Light Source Type	LED
Included Components	Bulb
Bulb Base	E26
Wattage	6 watts
Brightness	680 Lumen
Color Temperature	3000 Kelvin
Power Source	Corded Electric
Voltage	110 Volts (AC)
USB Output	USB-A & Type-C (5V/2.1A)
Certification	UL

## **9. WARRANTY AND SUPPORT**

---

Aooshine is committed to providing high-quality, durable, and safe products. If you have any questions or require assistance with your product, please do not hesitate to contact our customer service team. We aim to provide quick and friendly service, addressing all inquiries within 24 hours.

For support, please refer to the contact information provided with your purchase or visit the official Aooshine store on Amazon: [Aooshine Store](#).