

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Young](#) /

› [Young SAM-919 Universal Replacement Remote Control Instruction Manual for Samsung TVs and Blu-ray Players](#)

Young YY-Sam919

Young SAM-919 Universal Replacement Remote Control Instruction Manual

Model: YY-Sam919

INTRODUCTION

This manual provides instructions for the Young SAM-919 Universal Replacement Remote Control. This remote is designed to be compatible with a wide range of Samsung televisions and Blu-ray players, offering a direct replacement without the need for complex programming.

PACKAGE CONTENTS

- 1 x Young SAM-919 Universal Replacement Remote Control

Note: AAA batteries are not included and must be purchased separately.

SETUP: BATTERY INSTALLATION

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or press the latch and lift to open.
3. Insert two (2) AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Image: Rear view of the SAM-919 remote control with the battery cover removed, illustrating the correct orientation for inserting two AAA batteries.

The remote control is ready for use immediately after battery installation. No programming is required for most compatible Samsung devices.

OPERATING INSTRUCTIONS

The SAM-919 remote control functions identically to many original Samsung remote controls. Point the remote directly at your Samsung TV or Blu-ray player for optimal performance.







Image: Front view of the SAM-919 remote control, showing the layout of all buttons, including power, volume, channel, number pad, navigation, and dedicated Netflix and Smart Hub buttons.

Key Functions:

- **Power ():** Turns the device on or off.
- **Source:** Selects input sources (HDMI, AV, etc.).
- **VOL (+/-):** Adjusts volume up or down.
- **CH (▲/▼):** Changes channels up or down.
- **Number Pad (0-9):** Direct channel selection or input.
- **Netflix:** Direct access to the Netflix application.
- **Smart Hub:** Direct access to the Samsung Smart Hub.
- **Navigation Buttons (▲ ▼ ◆):** Navigates menus and selections.
- **Enter/OK:** Confirms selections.
- **Return/Exit:** Returns to the previous screen or exits a menu.
- **Play/Pause/Stop/Fast Forward/Rewind:** Controls media playback.
- **Color Buttons (A, B, C, D):** Access specific functions within certain applications or menus.

MAINTENANCE

Battery Replacement:

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries simultaneously with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

To clean the remote control, use a soft, dry cloth. For stubborn dirt, lightly dampen the cloth with water. Avoid using harsh chemicals, abrasive cleaners, or excessive moisture, as these can damage the remote.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity (+/-).
 - Replace old batteries with new AAA alkaline batteries.
 - Ensure there are no obstructions between the remote control and the device's infrared receiver.
 - Confirm the remote is pointed directly at the device.
- **Specific buttons not working:**
 - This remote is designed for broad compatibility. While most functions will work, some highly specific or advanced features of certain Samsung models might not be supported.
 - Ensure the device (TV/Blu-ray) is powered on and in a state where the button's function is applicable (e.g., media playback buttons require media to be playing).

SPECIFICATIONS

Feature	Detail
Model Number	YY-Sam919
Brand	Young
Compatibility	Universal for Samsung TVs and Blu-ray Players (99% models)
Power Source	2 x AAA Alkaline Batteries (not included)
Connectivity Technology	Infrared
Controller Type	Button Control
Product Dimensions	2 x 8 x 0.5 inches
Item Weight	4 ounces

WARRANTY AND SUPPORT

This product comes with a 100% satisfaction guarantee. If you encounter any issues or are not satisfied with your purchase for any reason, please contact the seller or manufacturer for assistance.

For support, refer to the contact information provided with your purchase or on the product packaging.