

MAIDeSITe 55x28 White+Oak

MAIDeSITe Dual Motor Standing Desk User Manual

Model: 55"x28" White+Oak Adjustable Height Desk

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before assembly and operation. Keep this manual for future reference.

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or damaged.
- Keep children and pets away from the desk during operation.
- Do not place hands or other objects near the moving parts of the desk frame during height adjustment.
- Ensure the power cord is not pinched or damaged. Only use the provided power adapter.
- Do not overload the desk. Refer to the specifications for maximum weight capacity.
- Avoid spilling liquids on the control panel or motor components.
- If the desk malfunctions or makes unusual noises, disconnect power immediately and contact customer support.
- This desk is designed for indoor use only.

2. PRODUCT OVERVIEW

The MAIDeSITe Dual Motor Standing Desk is an adjustable height desk designed for home and office use. It features a robust dual-motor lifting system, a spacious tabletop, and a smart memory handset for convenient operation.

Adjustable Height Range

HEIGHT ADJUSTABLE



This desk offers a wide height adjustment range, allowing users to easily switch between sitting and standing positions. The dual motor system ensures smooth and quiet transitions, operating at less than 45 dB.

Spacious Tabletop

LARGE TABLETOP



55" * 28"
LARGER AREA

MEET YOUR DAILY OFFICE AND LEARNING NEEDS

The generous 55" x 28" tabletop provides ample space for multiple monitors, laptops, and other office essentials, accommodating various work and learning needs.

Smart Memory Handset

SMART MEMORY HANDSET



Height Memory
Setup your desired position



UP and DOWN
adjust desk height up/down



LED Display
better operating experience



Memory 1/2/3
3 height presets

The intuitive control panel features an LED display and three programmable memory presets, allowing you to save your preferred sitting and standing heights for quick adjustments.

Sturdy Construction

STURDY MATERIAL



26.8"

Wide desk feet

100% Steel Frame

Adapt to most floor

Anti-collision patch

Adjustable feet level

Constructed with a 100% steel frame and wide desk feet (26.8"), the desk provides exceptional stability. It also includes an anti-collision patch and adjustable feet levelers for uneven floors.

3. ASSEMBLY INSTRUCTIONS

Assembly is required for this product. Please follow the steps below. It is recommended to have two people for assembly.

- 1. Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all parts listed in the packing list are present.
- 2. Attach Desk Feet:** Secure the desk feet to the lifting columns using the provided screws.

3. **Assemble Frame:** Connect the lifting columns to the crossbar/frame components. Ensure all connections are tight and secure.
4. **Mount Tabletop:** Carefully place the tabletop upside down on a soft surface. Position the assembled frame onto the tabletop, aligning the pre-drilled holes. Secure the frame to the tabletop using the appropriate screws.
5. **Install Control Panel:** Attach the smart memory handset to the underside of the tabletop in the designated location.
6. **Connect Cables:** Connect the motor cables to the control box, and then connect the control panel cable to the control box. Finally, connect the power adapter to the control box.
7. **Cable Management:** Use the included cable ties or clips to organize and secure all cables, preventing them from dangling or getting caught.
8. **Position Desk:** Carefully flip the desk upright and place it in its desired location. Ensure it is stable and level. Adjust the foot levelers if necessary.

Note: Detailed diagrams and specific screw types are typically provided in the physical assembly manual included with the product. This section provides a general guide.

4. OPERATING INSTRUCTIONS

The MAIDeSITe standing desk is equipped with an intuitive control panel for easy height adjustment and memory functions.

4.1. Basic Height Adjustment

- **To Raise:** Press and hold the **UP (▲)** button. The desk will move upwards. Release the button to stop at your desired height.
- **To Lower:** Press and hold the **DOWN (▼)** button. The desk will move downwards. Release the button to stop at your desired height.
- The current height will be displayed on the LED screen.

4.2. Setting Memory Presets

The desk allows you to save three preferred height settings for quick recall.

1. Adjust the desk to your desired height using the UP or DOWN buttons.
2. Press the "**M**" button. The LED display will show "S-".
3. Within 3 seconds, press one of the preset buttons ("**1**", "**2**", or "**3**") to save the current height to that memory slot. The display will show "S-1", "S-2", or "S-3" to confirm.

4.3. Using Memory Presets

- Simply press the desired preset button ("**1**", "**2**", or "**3**"). The desk will automatically move to the saved height.
- Press any button during automatic movement to stop the desk.

4.4. Anti-Collision Feature

The desk is equipped with an anti-collision system. If the desk encounters an obstacle during movement, it will automatically stop and reverse slightly to prevent damage. Remove the obstacle before resuming operation.

5. MAINTENANCE AND CARE

- **Cleaning:** Wipe the desk surface and frame with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Retighten if necessary.
- **Cable Management:** Ensure cables remain tidy and are not pinched or damaged.
- **Environment:** Keep the desk in a dry environment. Avoid extreme temperatures or humidity.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk does not move.	Power cord disconnected; Control box issue; Overload.	Check power connections. Ensure desk is not overloaded. Unplug for 10 minutes, then plug back in.
Desk moves unevenly or makes unusual noise.	Loose connections; Obstruction; Damaged component.	Check all screws and connections. Ensure no obstructions. Disconnect power and contact support if issue persists.
Error code on display (e.g., E01, E02).	Overheat protection; Motor fault; Sensor issue.	Unplug the desk for at least 20 minutes to allow it to cool down and reset. If the error persists, contact customer support.
Memory presets not working.	Presets not saved correctly.	Re-save the memory presets following the instructions in Section 4.2.

If you encounter problems not listed here or if the suggested solutions do not resolve the issue, please contact MAIDeSITe customer support.

7. SPECIFICATIONS

Brand: MAIDeSITe

Model: Dual Motor Standing Desk (55"x28", White+Oak)

Tabletop Dimensions: 55 inches x 28 inches

Height Adjustment Range: Approximately 27 inches to 46.7 inches

Lifting Speed: Approximately 1.4 inches per second

Noise Level: Less than 45 dB

Motor Type: Dual Motor

Frame Material: 100% Steel

Control Panel: Smart Memory Handset with LED Display and 3 Presets

Assembly Required: Yes

Special Features: Adjustable Height, Anti-Collision System, Adjustable Feet Levelers

Color: White+Oak


8. WARRANTY AND SUPPORT

MAIDeSITe products are manufactured to high-quality standards. For specific warranty information regarding your Dual Motor Standing Desk, please refer to the warranty card included with your product or visit the official MAIDeSITe website.

If you require technical assistance, have questions about assembly, operation, or troubleshooting, please contact MAIDeSITe customer support through their official channels. Contact information can typically be found on the manufacturer's website or on the product packaging.

For customer support, you may also refer to the [MAIDeSITe Store on Amazon](#).

Related Documents

 <p>Electric Height Adjustable Desk User Manual</p> <p>For assembly assistance, feel free to contact us: Email: S.O. Customer service: CustomerService@Maidesite.com WhatsApp: +86 186 106 002 Facebook: Maidesite Electric Adjustable Desk</p>	<p><u>MAIDESITE Electric Height Adjustable Desk User Manual</u></p> <p>Comprehensive user manual for the MAIDESITE Electric Height Adjustable Desk, detailing assembly, operation, safety guidelines, and troubleshooting for optimal use. Includes parts list and package contents.</p>
 <p>Electric Height Adjustable Desk User Manual</p> <p>For assembly assistance, feel free to contact us: Email: S.O. Customer service: CustomerService@Maidesite.com WhatsApp: +86 186 106 002 Facebook: Maidesite Electric Adjustable Desk</p>	<p><u>Maidesite Electric Height Adjustable Desk User Manual</u></p> <p>User manual for the Maidesite Electric Height Adjustable Desk, covering assembly, operation, and troubleshooting.</p>
 <p>MAIDESITE</p> <p>Standing Desk User Guide T2 Pro/T2 Pro Plus</p> <p>Email: S.O. Customer service: CustomerService@Maidesite.com WhatsApp: +86 186 106 002 Facebook: Maidesite Standing Desk</p>	<p><u>Maidesite Standing Desk T2 Pro/T2 Pro Plus User Guide</u></p> <p>Comprehensive user guide for the Maidesite Standing Desk T2 Pro and T2 Pro Plus, covering safety, assembly, and control panel instructions.</p>
 <p>INSTRUCTIONS</p>	<p><u>Maidesite Gas Spring Aluminum LCD Monitor Desk Mount Installation Guide</u></p> <p>Comprehensive installation instructions for the Maidesite Gas Spring Aluminum LCD Monitor Desk Mount, covering clamp and grommet base installation, monitor attachment, tilt, swivel, rotation, and cable management.</p>