

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [PuraFlame](#) /

› [PuraFlame Klaus Electric Fireplace Insert User Manual \(Model B08LQFFN3F\)](#)

PuraFlame B08LQFFN3F

PuraFlame Klaus Electric Fireplace Insert User Manual

Model: B08LQFFN3F | Brand: PuraFlame

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your PuraFlame Klaus Electric Fireplace Insert. Please read all instructions carefully before installation and use. Keep this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Always ensure the fireplace is plugged into a 120V outlet. Do not hardwire the unit.
- Keep combustible materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Do not block air vents. Ensure proper airflow around the unit.
- This appliance is for indoor use only.
- Do not use this fireplace as a primary heat source. It is designed for supplemental heating.
- Unplug the fireplace when not in use or before cleaning.

PACKAGE CONTENTS

Verify that all items are present in the package:

- Electric Firebox
- Remote Handset
- Owner's Manual

SETUP

The PuraFlame Klaus Electric Fireplace Insert is designed for easy installation. It can be freestanding or inserted into an existing fireplace opening.

Dimensions and Placement

Ensure your fireplace opening or desired placement area meets the following dimensions:

- Overall dimensions: Width: 27.95" x Height: 24.61" x Depth: 8.78"
- Minimum opening width: 26"
- Minimum opening height: 23 7/16"
- Minimum opening depth: 7 13/16" (suggested 8 3/16")



Image: Detailed diagram illustrating the width, height, and depth measurements of the fireplace insert, including the removable handle.

Width: min 26"
max 27 3/16"

Height: min 23 7/16"
max 24 7/16"

Depth: min 7 13/16"
suggest 8 3/16"



Image: Visual guide indicating the required minimum and maximum width, height, and suggested depth for proper installation into a fireplace opening.

Installation

The insert features a flat bottom, allowing it to sit directly on the floor. Simply plug it into a standard 120V electrical outlet. No hardwiring is required.

Battery Installation for Remote Handset

The remote handset requires 2 AAA batteries (not included). Open the battery compartment on the back of the remote and insert the batteries, ensuring correct polarity.

OPERATING INSTRUCTIONS

Your PuraFlame Klaus Electric Fireplace Insert can be operated using the control panel located on the unit or the included remote handset.

Powering On/Off

To power on the unit, open the fence on the control panel and press the rocker switch to the 'On' position. The unit can also be turned on/off using the power button on the remote control.

Flame Settings

The fireplace features 3 flame settings with variable intensity and brightness. These can be used with or without heat. Use the flame button on the control panel or remote to cycle through the settings.

Heat Settings

The unit provides supplemental heat for areas up to 400 sq. ft. It offers 750W and 1500W fan heater settings. Use the heater buttons on the control panel or remote to select your desired heat output. An adjustable thermostat allows for precise temperature control.

Crackling Sound

Enhance the ambiance with realistic fire crackling sounds. Use the crackling sound button on the remote to activate or adjust the sound level.

Control Panel and Remote Handset



Image: The remote handset for the PuraFlame Klaus Electric Fireplace Insert, showing buttons for flame effects, crackling sounds, 750W and 1500W heater settings, and power on/off.




Image: A detailed view of the fireplace's control panel, highlighting the ON/OFF switch, flame settings, heater (750/1500W) controls, and thermostat dial, with the speaker located inside.

Product Features in Action

Video: This video demonstrates the PuraFlame Klaus Electric Fireplace Insert, showcasing its realistic oak logs, hidden vent outlet and control panel design, ease of power-on, openable glass door, adjustable mesh screen, and various flame and crackling sound settings. It also highlights the availability of an extra trim kit.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- **Cleaning:** Always unplug the unit before cleaning. Use a soft, damp cloth to wipe down the exterior surfaces. Do not use abrasive cleaners or sprays.
- **Glass Cleaning:** For glass surfaces, use a non-abrasive glass cleaner and a soft cloth.
- **Ventilation:** Periodically check that the air vents are clear of dust and debris to maintain proper heating function.

TROUBLESHOOTING

If you encounter any issues with your fireplace, refer to the following common problems and solutions:

- **No Power:** Ensure the power cord is securely plugged into a 120V outlet. Check the rocker switch on the control panel is in the 'On' position. Verify that the circuit breaker has not tripped.
- **No Heat:** Confirm the heater function is activated on the control panel or remote. Check the thermostat setting; increase it if the room temperature is below the set point. Ensure air vents are not obstructed.
- **Flames Not Visible:** Check the flame setting on the control panel or remote. Adjust brightness if

necessary.

- **Remote Not Working:** Replace the AAA batteries in the remote handset. Ensure there are no obstructions between the remote and the fireplace's receiver.

If problems persist, contact customer service for assistance.

SPECIFICATIONS

Feature	Detail
Brand	PuraFlame
Model Name	PuraFlame Klaus Electric Fireplace Insert
Product Dimensions	8.78"D x 27.94"W x 24.61"H
Item Weight	46.2 pounds
Power Source	Corded Electric
Heat Output	750W / 1500W (5100 British Thermal Units)
Heating Coverage	Up to 400 sq. ft. (supplemental heat)
Material	Metal
Finish Type	Wood (log appearance)
Installation Type	Wall Mount, Plug In, Freestanding
Special Feature	Adjustable thermostat, 3 flame settings, crackling sound
Color	Black
Burner Type	Resin logs
Batteries Required	2 AAA batteries (for remote)

WARRANTY AND SUPPORT

The PuraFlame Klaus Electric Fireplace Insert comes with a one-year limited warranty. For any questions, technical support, or warranty claims, please contact PuraFlame customer service. Contact information can typically be found on the manufacturer's website or the product packaging.