Ewin EW-ZR050BR

Ewin BIJP-028 Wireless Bluetooth Keyboard Instruction Manual

Model: EW-ZR050BR

Introduction Features What's in the Box Setup Operating Maintenance Troubleshooting Specifications Warranty Support

1. Introduction

Thank you for purchasing the Ewin BIJP-028 Wireless Bluetooth Keyboard. This compact, foldable keyboard features a Japanese JIS layout, an integrated touchpad, and multi-device connectivity, making it ideal for on-the-go productivity across various operating systems. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal use of your device.

2. Key Features

- **Foldable & Portable Design:** Tri-fold design for compact storage, easily fits into bags. Includes an adjustable stand and pouch for convenience.
- **Multi-OS Compatibility:** Seamlessly compatible with iOS, Android, Mac OS, and Windows devices.
- **Multi-Device Connectivity:** Pair with up to 3 devices and switch between them with a single touch.
- **Integrated Touchpad:** Full-size touchpad eliminates the need for an external mouse, saving space and enhancing portability.
- **Japanese JIS Layout:** Features a JIS standard Japanese layout for efficient typing.
- **Silent Pantograph Keys:** Utilizes a pantograph key system for quiet, comfortable, and responsive typing, suitable for various environments.
- **Rechargeable Battery with Auto-Sleep:** Built-in 140 mAh battery provides up to 90 hours of continuous use on a 2-hour charge. Features an auto-sleep function after 10 minutes of inactivity to conserve power.

3. What's in the Box

Please check the package contents upon unboxing:

- Ewin BIJP-028 Wireless Bluetooth Keyboard
- USB Charging Cable
- Adjustable Stand (may be included as an accessory)
- Storage Pouch/Case (may be included as an accessory)

4. Setup

4.1 Initial Charging

Before first use, fully charge the keyboard. Connect the provided USB charging cable to the keyboard's micro USB port and the other end to a USB power source (e.g., computer, USB wall adapter). The charging indicator light will illuminate and turn off once fully charged. A full charge typically takes about 2 hours.

4.2 Powering On/Off

To power on the keyboard, unfold it. The keyboard will automatically power on. To power off, fold the keyboard. It will automatically enter sleep mode after 10 minutes of inactivity and can be woken by pressing any key.

4.3 Bluetooth Pairing

The keyboard supports pairing with up to three devices.

1. **Turn on the keyboard:** Unfold the keyboard.
2. **Enter Pairing Mode:** Press and hold the **Fn** key and one of the device keys (**A** for Device 1, **S** for Device 2, or **D** for Device 3) for 3-5 seconds until the Bluetooth indicator light starts blinking. This indicates the keyboard is in pairing mode.
3. **Enable Bluetooth on your device:** Go to your device's Bluetooth settings (e.g., smartphone, tablet, computer).
4. **Select the keyboard:** Look for "Ewin Keyboard" or a similar name in the list of available Bluetooth devices and select it.
5. **Confirm Pairing:** Your device may prompt you to enter a code displayed on the screen using the keyboard, then press **Enter**. Once paired, the Bluetooth indicator light on the keyboard will stop blinking.
6. **Repeat for additional devices:** To pair with a second or third device, repeat steps 2-5, using a different device key (Fn+S or Fn+D).



Image: The Ewin BIJP-028 keyboard shown connected to a laptop, tablet, and smartphone, demonstrating its multi-device capability. The image highlights the Fn+A/S/D keys for switching between devices.

5. Operating Instructions

5.1 Folding and Unfolding

The keyboard is designed to fold into a compact size for portability. Gently unfold the keyboard to power it on and begin use. Fold it back to power off and store.



Image: The Ewin BIJP-028 keyboard in its folded state, placed next to an iPhone to illustrate its compact size and portability. The image

also shows the keyboard unfolded and in use.

5.2 Touchpad Usage

The integrated touchpad allows for mouse-like control without an external device. Here are common gestures:

- **Left Click:** Tap with one finger.
- **Right Click:** Tap with two fingers.
- **Scroll:** Slide two fingers up or down.
- **Zoom In/Out:** Pinch with two fingers.
- **Search:** Tap with three fingers.
- **Switch Windows:** Slide three fingers left or right.
- **Return to Desktop:** Slide three fingers down.



Image: A close-up view of the Ewin BIJP-028 keyboard's touchpad, illustrating various multi-finger gestures for navigation and control, such as left-click, right-click, scroll, zoom, search, and window switching.

5.3 Switching Between Devices

To switch between your paired devices (up to 3), simply press the **Fn** key simultaneously with the corresponding device key:

- **Fn + A:** Switch to Device 1
- **Fn + S:** Switch to Device 2
- **Fn + D:** Switch to Device 3

5.4 Shortcut Keys and Function Keys

The keyboard features a row of function keys (F1-F12) that also serve as multimedia and shortcut keys. To use the multimedia functions, press the **Fn** key along with the desired function key.
Note: In Windows mode, F1-F12 functions are prioritized. For media functions, press Fn + F-key. Android and iOS devices require pressing Fn + F-key for F1-F12 functions.



Image: The Ewin BIJP-028 keyboard displaying its full layout, with a focus on the top row of keys that include various shortcut functions for media control, volume, and system actions.

6. Maintenance

6.1 Charging the Keyboard

When the battery is low, the indicator light will blink. Connect the keyboard to a power source using the provided USB cable. A full charge takes approximately 2 hours and provides up to 90 hours of continuous use or 220 hours of standby time.



Image: The Ewin BIJP-028 keyboard connected to a power source via its micro USB charging cable, illustrating the charging process.

Battery life and charging times are also displayed.

6.2 Cleaning

To clean the keyboard, gently wipe the surface with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure the keyboard is powered off and disconnected from any power source before cleaning.

6.3 Storage

When not in use, fold the keyboard to protect the keys and touchpad. Store it in the provided pouch or case to prevent scratches and damage.

7. Troubleshooting

- **Keyboard does not connect via Bluetooth:**
  - Ensure the keyboard is charged and powered on.
  - Make sure Bluetooth is enabled on your device.
  - Put the keyboard into pairing mode (Fn + A/S/D for 3-5 seconds).
  - Forget the keyboard from your device's Bluetooth list and try pairing again.
  - Ensure your device is within the Bluetooth range (typically 10 meters).
- **Keys are not responding:**
  - Check if the keyboard is connected to the correct device (Fn + A/S/D).
  - Ensure the keyboard battery is not depleted.
  - Restart the keyboard and your device.
- **Touchpad is not working:**
  - Ensure the keyboard is properly connected.
  - Check if the touchpad is enabled (some systems may have a toggle).
  - Clean the touchpad surface.
- **Keyboard frequently disconnects:**
  - Ensure there are no strong interferences (e.g., Wi-Fi routers, other Bluetooth devices) nearby.
  - Keep the keyboard and device close to each other.
  - Ensure the keyboard is fully charged.

8. Specifications

Brand	Ewin
Model Number	EW-ZR050BR
Connectivity Technology	Bluetooth
Compatible Devices	Tablet, Smartphone, PC (iOS, Android, Mac OS, Windows)
Keyboard Description	Wireless, Foldable, Japanese JIS Layout, Built-in Touchpad
Special Feature	Rechargeable, Multi-Device Switching (up to 3 devices), Auto-Sleep
Number of Keys	90

Battery Capacity	140 mAh
Charging Time	Approx. 2 hours
Continuous Use Time	Approx. 90 hours
Standby Time	Approx. 220 hours
Item Dimensions (L x W x H)	30.5L x 9.8W x 0.6H Centimeters (unfolded)
Color	Gray
UPC	742377592299

9. Warranty Information

Ewin products are manufactured to the highest quality standards. This product is covered by a limited warranty against manufacturing defects from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact Ewin customer support.

10. Customer Support

If you encounter any issues or have questions regarding your Ewin BIJP-028 Wireless Bluetooth Keyboard that are not addressed in this manual, please contact our customer support team. You can typically find support contact information on the Ewin official website or through your retailer's customer service portal.
Please have your model number (EW-ZR050BR) and proof of purchase ready when contacting support.

© 2024 Ewin. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question