



[Manuals.plus](#) /

› [Samsung](#) /

› Samsung Galaxy A21 Smartphone User Manual

Samsung Galaxy A21

Samsung Galaxy A21 Smartphone User Manual

Your guide to setting up, operating, and maintaining your Samsung Galaxy A21.

1. PRODUCT OVERVIEW

The Samsung Galaxy A21 is a versatile smartphone designed for daily use. It features a 6.5-inch Infinity-O Display, a long-lasting 4000 mAh battery, and a quad-camera system. This device is GSM unlocked, compatible with major Canadian carriers, but not with CDMA networks like Sprint or Verizon.

Key features include a 16.0 MP main rear camera, 8.0 MP ultra-wide, 2.0 MP macro, and 2.0 MP depth cameras, alongside a 13.0 MP front camera. It runs on Android, has 3GB RAM, and 32GB internal memory, expandable up to 512GB with a microSD card.



Figure 1: Front and back view of the Samsung Galaxy A21 smartphone.

2. DEVICE LAYOUT

Familiarize yourself with the physical components of your Galaxy A21.

- **Bottom:** USB-C port for charging and data transfer, speaker grill, and 3.5mm headphone jack.
- **Left Side:** SIM and microSD card slot.
- **Top:** Microphone.
- **Right Side:** Power button and volume rockers.
- **Back:** Quad-camera setup with flash, and a fingerprint sensor.

- **Front:** 6.5-inch Infinity-O Display with a punch-hole front camera.



Figure 2: Left side view of the Samsung Galaxy A21, showing the SIM/SD card slot.



Figure 3: Right side view of the Samsung Galaxy A21, showing the power and volume buttons.



Figure 4: Back view of the Samsung Galaxy A21, highlighting the quad-camera system and fingerprint sensor.

3. SETUP

3.1. Inserting SIM and microSD Card

1. Locate the SIM/microSD card tray on the left side of the device.
2. Use the provided ejection tool to open the tray.
3. Place your Nano-SIM card into the SIM slot.
4. If desired, insert a microSD card (up to 512GB) into the designated slot for expanded storage.
5. Carefully reinsert the tray into the phone.

3.2. Initial Power On and Configuration

1. Press and hold the Power button on the right side until the Samsung logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Configure security features such as fingerprint unlock or face recognition.

4. OPERATING YOUR DEVICE

4.1. Navigation and Interface

The Galaxy A21 runs on Android, offering a user-friendly interface. Navigate by tapping, swiping, and pinching the touchscreen. Use the volume buttons to adjust audio levels and the power button to lock/unlock the screen or power the device on/off.

4.2. Camera Features

The device is equipped with a versatile quad-camera system on the rear and a single front camera.

- **Rear Cameras:** 16.0 MP (main, f/1.8 aperture), 8.0 MP (ultra-wide, f/2.2), 2.0 MP (macro), and 2.0 MP (depth sensor).
- **Front Camera:** 13.0 MP punch-hole camera, suitable for video calls and selfies.

To access the camera, tap the camera icon on your home screen or lock screen. Select different modes like Photo, Video, Portrait, or Macro from the camera interface.

4.3. Fingerprint Sensor

The fingerprint sensor is located on the back of the device. To set up fingerprint unlock, go to *Settings > Biometrics and security > Fingerprints* and follow the instructions. This provides quick and secure access to your device.

5. MAINTENANCE

5.1. Software Updates

Ensure your device is running the latest software for optimal performance and security. To check for updates, go to *Settings > Software update > Download and install*. Connect to Wi-Fi and ensure your battery is sufficiently charged before starting an update.

5.2. Storage Management

The Galaxy A21 comes with 32GB of internal storage. If you require more space, you can expand it up to 512GB using a microSD card. Regularly review and delete unnecessary files, apps, and media to free up storage.

5.3. Cleaning Your Device

To clean your phone, power it off and gently wipe the screen and back with a soft, lint-free cloth. Avoid using harsh chemicals or abrasive materials.

6. TROUBLESHOOTING

6.1. Common Issues

- **Device unresponsive:** Press and hold the Power button and Volume Down button simultaneously for about 10 seconds to force restart the device.

- **Apps freezing or crashing:** Clear the app's cache (*Settings > Apps > [App Name] > Storage > Clear cache*) or reinstall the app. Ensure your software is up to date.
- **Battery draining quickly:** Reduce screen brightness, disable unnecessary background apps, and limit location services. Check for apps consuming excessive battery in *Settings > Battery and device care*.
- **Fingerprint sensor not working:** Ensure your finger is clean and dry. Re-register your fingerprints if issues persist.

6.2. Factory Reset

If you experience persistent software issues, a factory reset may resolve them. **Warning:** This will erase all data on your device. Back up important data before proceeding. Go to *Settings > General management > Reset > Factory data reset* and follow the prompts.

7. SPECIFICATIONS

Feature	Specification
Brand	Samsung
Model Name	Galaxy A21
Operating System	Android
Screen Size	6.5 Inches
Resolution	720 x 1520 Pixels (HD+)
CPU Model	Core i3
CPU Speed	1.35 GHz
RAM Memory Installed Size	3 GB
Memory Storage Capacity	32 GB (Expandable up to 512GB with microSD)
Rear Facing Camera Photo Sensor Resolution	16 MP (Main) + 8 MP (Ultra-wide) + 2 MP (Macro) + 2 MP (Depth)
Front Photo Sensor Resolution	13 MP
Battery Capacity	4000 Milliamp Hours (Lithium-Ion)
Connectivity Technology	Bluetooth, 4G, GSM
Connector Type	USB Type C
Headphones Jack	3.5 mm
Biometric Security Feature	Fingerprint Sensor, Face Recognition
Item Weight	0.42 Pounds
Item Dimensions	6.61 x 3.02 x 0.32 inches

8. WARRANTY AND SUPPORT

8.1. Warranty Information

This Samsung Galaxy A21 (Renewed) product comes with a 90-day limited warranty. Please refer to the warranty documentation provided with your purchase for full terms and conditions.

8.2. Customer Support

For further assistance, please visit the official Samsung support website or contact their customer service. You can also refer to the Amazon Renewed Store for information regarding renewed product conditions and support.