

STANLEY SXWT-PC517 SP

Stanley PC517 Folding Platform Truck User Manual

Model: SXWT-PC517 SP

INTRODUCTION

Thank you for choosing the Stanley PC517 Folding Platform Truck. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new platform truck. Please read this manual thoroughly before initial use and retain it for future reference.



Figure 1: Stanley PC517 Folding Platform Truck

SAFETY INFORMATION

Always observe the following safety precautions to prevent injury or damage to the product:

- Do not exceed the maximum load capacity of **120 kg (264.6 lbs)**.
- Ensure the handle is securely locked in place before moving the truck.
- Distribute the load evenly on the platform.
- Do not use on uneven or sloped surfaces without proper caution.

- Keep hands and feet clear of moving parts, especially during folding and unfolding.
- Store the truck in a dry, safe place when not in use.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Stanley PC517 Folding Platform Truck:





**SALES AND AFTER
SALES SUPPORT**



**GREAT SERVICE
NETWORK**



WARRANTY



ORIGINAL PARTS



INFORMATION



**OMNICHANNEL
SUPPORT**

CUSTOMER CARE CONTACT

<p>PHONE:</p> <p>1800-203-0644</p> <p>MON-SAT 09:00 AM - 06:00 PM IST EXCEPT GOVERNMENT HOLIDAYS</p>	<p>EMAIL:</p> <p>SBD-CUSTOMER COMMUNICATIONS @SBDINC.COM</p> <p>NUMBER OF AUTHORIZED SERVICE CENTER : 500+</p>	<p>WHATSAPP:</p>  <p>+91 96060 55835 SCAN THE CODE TO CONTACT US</p>
---	--	--

Figure 2: Key Components of the Platform Truck

Handle Grip: Ergonomic grip for comfortable pushing/pulling.

Handle Lock Knobs: Secure the handle in the upright position.

Folding Handle Frame: Allows the handle to fold flat for storage.

Platform Base: The main load-bearing surface.

Integrated Carry Handles: For easy transport when folded.

Textured Surface: Provides grip for items placed on the platform.

Swivel Casters: Front wheels that rotate 360 degrees for maneuverability.

Fixed Casters: Rear wheels that provide stability and directional control.

Treaded Wheels: Durable wheels designed for various surfaces.

SPECIFICATIONS

Detailed specifications for the Stanley PC517 Folding Platform Truck:

Feature	Detail
Platform Size (L×W)	68 × 41 cm (26.77"L x 16.14"W)
Maximum Load Capacity	120 kg (264.6 lbs)
Material	Aluminum frame, Polypropylene platform
Item Weight	6.4 kg (14.08 lbs)
Number of Wheels	4 (2 swivel, 2 fixed)
Wheel Type	Solid, TPR (Thermoplastic Rubber)
Product Dimensions (Open)	92 cm H x 68 cm L x 41 cm W (36.22"L x 16.14"W x 36.22"H)
Product Dimensions (Folded)	68 cm L x 41 cm W x 80 cm H (approx.)
Color	Black



Figure 3: Product Dimensions

SETUP AND FOLDING

Unfolding the Platform Truck:

1. Place the folded platform truck on a flat, stable surface.
2. Grasp the handle frame and lift it upwards until it clicks into the fully upright position. Ensure the handle lock knobs engage securely.
3. Carefully unfold the platform base by pushing down on the center until it lies flat and locks into place.
4. Verify that all wheels are properly extended and the platform is stable before use.





Figure 4: Unfolded Platform Truck Views

Folding the Platform Truck for Storage:

1. Ensure the platform truck is empty and clean.
2. Locate the release mechanism for the platform base (often a lever or button near the hinge) and disengage it, allowing the platform to fold upwards.
3. Press the handle lock knobs to release the handle frame, then carefully push the handle downwards until it lies flat against the folded platform.
4. Confirm that all parts are securely folded before storing.









Figure 5: Folded Platform Truck Views

OPERATING INSTRUCTIONS

To use your platform truck effectively and safely:

1. **Load Placement:** Place items centrally on the platform, ensuring the weight is evenly distributed. Avoid stacking items too high that they obstruct your view or become unstable.
2. **Weight Limit:** Never exceed the maximum load capacity of 120 kg. Overloading can damage the truck and cause injury.
3. **Maneuvering:** Use the handle to push or pull the truck. The swivel casters at the front allow for easy turning and navigation in tight spaces.
4. **Surface Considerations:** Operate on flat, stable surfaces whenever possible. Exercise extreme caution on ramps or uneven terrain.
5. **Securing Loads:** For unstable or multiple items, consider using straps or bungee cords (not included) to secure the load to the handle frame or platform.



Figure 6: Transporting Objects with the Platform Truck

MAINTENANCE

Regular maintenance will extend the life of your platform truck:

- **Cleaning:** Wipe down the platform and frame with a damp cloth after use, especially if exposed to dirt or moisture. Avoid harsh chemicals.
- **Wheel Inspection:** Periodically check the wheels for debris, wear, or damage. Remove any tangled hair or string from the axles.
- **Lubrication:** Apply a small amount of silicone spray or light oil to the wheel axles and folding mechanisms

annually to ensure smooth operation.

- **Storage:** Store the folded truck in a dry, cool place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your platform truck, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Handle does not lock in upright position.	Handle not fully extended; debris in locking mechanism.	Ensure handle is pulled up completely until it clicks. Check and clear any obstructions around the lock knobs.
Platform does not fold flat.	Mechanism obstructed; not properly disengaged.	Check for any items or debris preventing the platform from folding. Ensure the release mechanism is fully activated.
Wheels are stiff or squeaky.	Dirt/debris in axles; lack of lubrication.	Clean wheels and axles. Apply a small amount of lubricant to the wheel bearings/axles.

WARRANTY INFORMATION

The Stanley PC517 Folding Platform Truck comes with a **1-year EU Spare Part Availability Duration**. For specific warranty terms and conditions, please refer to your purchase documentation or contact customer support.


CUSTOMER SUPPORT

For any inquiries, technical assistance, or spare parts, please contact Stanley customer care:

FLAT-FOLDING TRUCKS

4-wheeled professional platform truck, folds and opens in seconds
 Robust design made of lightweight and durable ALUMINIUM and polypropylene
 Soft grip telescopic handle for secure maneuvering of loads
 Built for commercial warehouses, retail stores, delivery services and professional movers
 Soft grip handle, platform with basket pin slots

SXWT-PC517




PRODUCT CODE	BARCODE	CAPACITY	WEIGHT	FOLDED / UNFOLDED DIMENSION'S	PLATFORM SIZE	WHEELS
SXWT-PC517-SP	8717496637635	120 KG	6,4KG	680 MM X 410 MM X 80 MM 680 MM X 410 MM X 920 MM	680 MM X 410 MM	100 MM TPR

COMBI PACK

This Combi Pack includes the SXWT-PC517 Flat-Folding Platform Truck and SXWT-FT505 Folding Utility Basket

SXWT-PC519



PRODUCT CODE	BARCODE	CAPACITY	WEIGHT	FOLDED / UNFOLDED DIMENSIONS	PLATFORM SIZE	WHEELS
SXWT-PC519-SP	8717496638748	120 / 25 KG	8,5KG	SEE SPECIFICATIONS OF SXWT-PC517 AND SXWT-FT505	680 MM X 410 MM	75 MM TPR

Figure 7: Stanley Customer Care Contact Details

Phone: 1800-203-0644 (Mon-Sat, 09:00 AM - 06:00 PM IST, except government holidays)


Email: SBD-CUSTOMER.COMMUNICATIONS@SBDINC.COM

WhatsApp: [+91 96060 55835](https://wa.me/919606055835)

Service Center Network: 500+ authorized service centers.

© 2024 STANLEY. All rights reserved.

Related Documents

	<p>Stanley SXWT-FT585 Folding Hand Truck: User Manual and Specifications</p> <p>Comprehensive user manual and specifications for the Stanley SXWT-FT585 Folding Hand Truck, detailing its features, folding instructions, safety guidelines, and warranty information. This guide helps users operate and maintain the product safely and effectively.</p>
	<p>Stanley 213661 Steel Sack Truck / Platform Truck (70/137 KG)</p> <p>Discover the versatile Stanley 213661 steel sack truck, easily convertible to a platform truck. With a 70kg capacity as a sack truck and 137kg as a platform truck, it's ideal for transporting heavy loads. Features ergonomic handles and compact storage.</p>
	<p>Stanley MT515 Multi Truck Assembly and Usage Guide</p> <p>Assembly instructions and usage guide for the Stanley MT515 Multi Truck, a versatile aluminum hand truck with a 200kg/250kg load capacity.</p>
	<p>Stanley SRP 4960 Compaction Reversible Plate Parts Manual</p> <p>Comprehensive parts manual for the Stanley SRP 4960 Compaction Reversible Plate, detailing all components, part numbers, quantities, and assembly kits. Includes technical specifications, adhesive torque conversions, and maintenance information.</p>