

[Manuals.plus](#) /

› [CHITA](#) /

› CHITA Counter Height Swivel Barstool (Model Y1510M-B1106) Instruction Manual

CHITA Y1510M-B1106

CHITA Counter Height Swivel Barstool (Model Y1510M-B1106) Instruction Manual

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your CHITA Counter Height Swivel Barstool, Model Y1510M-B1106. Please read all instructions carefully before assembly and use to ensure safe and proper functionality.





Image: Front view of the CHITA Counter Height Swivel Barstool in fog fabric.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or product damage.

- Always assemble according to the provided instructions.
- Do not use if any parts are missing or damaged.
- Keep the stool away from heat sources and sharp objects to prevent damage to the upholstery.
- Use the stool on stable, level surfaces only to prevent tipping.
- Do not exceed the maximum weight recommendation of 300 pounds.
- Always wipe the stool with a dry cloth for cleaning.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. The package typically includes:

- 1 x Seat Assembly (with pre-attached swivel mechanism)
- 4 x Legs

- 4 x Side Rails (footrests)
- Hardware pack (bolts, lock washers, flat washers, Allen wrench)
- Assembly Manual



Image: Exploded view of barstool components including seat, legs, and side rails.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward, typically taking approximately 10 minutes. Follow these steps:

1. **Prepare Components:** Unpack all parts and lay them out on a clean, soft surface to prevent scratches. Identify the seat assembly, four legs, and four side rails.
2. **Attach Legs to Seat:** Align each leg with the corresponding mounting points on the underside of the seat assembly. Use the provided bolts, lock washers, and flat washers to secure the legs. **Note: Do not fully tighten yet.**
3. **Attach Side Rails (Footrests):** Connect the side rails between the legs. Ensure they are properly aligned to form the footrest structure. Secure with the remaining bolts and washers. **Note: Do not fully tighten yet.**
4. **Final Tightening:** Once all legs and side rails are in place, carefully place the stool upright on a level surface. Apply even pressure to the seat, then gradually tighten all bolts using the Allen wrench until secure. Avoid over-tightening.

Video: Official CHITA video demonstrating the assembly process of the bar stool.

OPERATING INSTRUCTIONS

Your CHITA Counter Height Swivel Barstool features a smooth 360-degree swivel mechanism, allowing for effortless rotation. To operate:

- Simply sit on the stool and gently push off with your feet or hands to rotate the seat in any direction.
- The swivel mechanism is designed for quiet and smooth movement.





Image: A CHITA barstool with arrows indicating its 360-degree swivel capability.

Maintenance and Care

Proper care will extend the life and appearance of your barstool:

- **Cleaning:** Wipe with a dry cloth to clean. For spills, blot immediately with a clean, dry cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Care:** For fabric upholstery, regular vacuuming with a soft brush attachment can help remove dust and debris.
- **Wood Care:** Periodically check and tighten all bolts to ensure stability. Avoid prolonged exposure to direct sunlight or extreme temperatures to prevent wood damage.
- **Footrest Protection:** The footrest is designed with a protective strip to minimize wear from shoes.

Troubleshooting

If you encounter any issues with your barstool, consider the following common solutions:

- **Wobbling:** Ensure all assembly bolts are securely tightened. Check that the stool is placed on a flat, even surface.
- **Stiff Swivel:** The swivel mechanism should operate smoothly. If it feels stiff, ensure no debris is obstructing the mechanism. Avoid applying lubricants unless specifically recommended by the manufacturer.
- **Noise:** If the stool makes noise, check all connections for tightness. Loose bolts can cause creaking.

For persistent issues, please contact CHITA customer support.

Specifications

Feature	Detail
Model Number	Y1510M-B1106
Product Dimensions	22.8"D x 18.9"W x 39.4"H
Seat Height	26.8 Inches
Seat Width	17.3 Inches
Color	Fabric in Fog
Material	Fabric (Upholstery), Wood (Frame)
Maximum Weight Recommendation	300 Pounds
Assembly Required	Yes
Swivel Feature	360-Degree Swivel




Image: Detailed dimensions of the barstool, including overall height, seat height, depth, and width.

WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official CHITA website. Keep your proof of purchase for any warranty claims.

For additional information or to explore other CHITA products, visit the [CHITA Store](#).