

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [OPTIMUS](#) /

› [Optimus 3.0 GPS Tracker User Manual](#)

OPTIMUS 3.0

Optimus 3.0 GPS Tracker User Manual

Brand: OPTIMUS | Model: 3.0

1. PRODUCT OVERVIEW

The Optimus 3.0 GPS Tracker is a compact, real-time tracking device designed for vehicles, machinery, and other valuable assets. It features a long-lasting battery and comes with a heavy-duty waterproof case equipped with powerful magnets for secure attachment. The device provides accurate location data, customizable alerts, and detailed history reports accessible via a user-friendly tracking software.




Image: Optimus 3.0 GPS Tracker with its waterproof magnetic case.

2. WHAT'S INCLUDED

Your Optimus 3.0 GPS Tracker package includes the following items:

- Optimus 3.0 GPS Tracker Device
- Heavy Duty Waterproof Magnetic Case
- USB Charging Cable
- Activation Steps Card
- Warranty Information Card

SUPER STRONG MAGNETS

3.0 GPS Tracker

with Waterproof Twin
Magnetic Case



1. Activate
2. Charge
3. Place inside case
4. Attach to any flat metal surface
5. Start tracking!

Strength to hold over
50 pounds!

Image: The Optimus 3.0 GPS Tracker device alongside its heavy-duty waterproof magnetic case.

3. SETUP AND ACTIVATION

Follow these steps to set up and activate your Optimus 3.0 GPS Tracker:

3.1. Unboxing and Initial Inspection

Carefully unbox your Optimus 3.0 GPS Tracker and ensure all components listed in Section 2 are present. Inspect the device and case for any visible damage.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing process, powering on the device, charging, and placing the tracker inside its waterproof magnetic case.

3.2. Powering On the Device

There are two methods to power on your Optimus 3.0 GPS Tracker:

1. **Press and Hold Power Button:** Locate the power button on the device. Press and hold it until the indicator lights illuminate.
2. **Connect to Charger:** Plug the USB charging cable into the device and connect it to a power source. The device will automatically power on.

3.3. Charging the Device

Before first use, fully charge the device. Connect the USB charging cable to the tracker and a power source. A blinking red light indicates the device is charging. A solid red light indicates a full battery.

3.4. Activating Your Tracker

To activate your Optimus 3.0 GPS Tracker, follow these steps:

1. Visit the official Optimus Tracking website: www.optimustracker.com.
2. Click on the "Activate Tracker" link.
3. Fill out the required form. You will need the IMEI number, which is a 15-digit number printed on the tracker's label.
4. After submitting, wait a few minutes for the activation email. Check your spam/junk folder if you do not receive it promptly.

A monthly subscription is required for the tracking service.

3.5. Initial GPS Signal Acquisition

For the device to acquire its initial GPS signal, leave it outdoors in an open area for 10-15 minutes, or take it for a short drive. This allows the tracker to calibrate and lock onto satellite signals.

4. OPERATING INSTRUCTIONS

The Optimus 3.0 GPS Tracker provides real-time tracking and data access through both a mobile application and a web portal.


4.1. Mobile Application Tracking

Download the Optimus Tracking app from your device's app store (available for Android and iPhone). Log in with your account credentials to view your tracker's location, route history, and manage settings.


Optimus 3.0 GPS Tracker

with Heavy Duty Magnetic Case

- Over 1 month battery life
- Real-Time Tracking
- Route Details
- 10 second updates
- Instant Alerts
- Geofence
- Speed Monitoring
- History Reports
- App and Web Access
- As low as \$15.95 per month*
- Coverage: USA, Canada and Mexico



Desktop



Laptop



Tablet



Smartphone

Image: The Optimus 3.0 GPS Tracker's mobile application interface displayed on a smartphone, tablet, laptop, and desktop computer.

4.2. Web Portal Access

Access the tracking software via any web browser by visiting optimustracking.com. The web portal offers a comprehensive view of your tracker's activity, including detailed reports and advanced settings.


4.3. Setting Up Alerts

Configure custom instant alerts (text and/or email) for various events, such as:

- **Geofence Alerts:** Receive notifications when the tracker enters or exits a predefined boundary area.
- **Speed Alerts:** Get notified if the tracker exceeds a set speed limit.
- **Movement Alerts:** Receive alerts when the device starts moving after being stationary.

Instant Alerts.

Anytime. Anywhere.



GPS Tracker for every scenario

Vehicles | Assets | People

Real-Time Tracking • Route Details • Instant Alerts • Geofence
Speed Monitoring • History Reports • App and Web Access
Coverage: USA, Canada and Mexico

Image: Examples of instant alerts displayed on a smartwatch and smartphone.



Image: A map illustrating a geofence, a pre-defined boundary area for alerts.

5. INSTALLATION AND PLACEMENT

The Optimus 3.0 GPS Tracker, when enclosed in its waterproof magnetic case, can be securely attached to any flat metal surface. Ensure the device is placed in a location that allows for optimal GPS signal reception and is not easily dislodged.

- Place the tracker inside the waterproof magnetic case, ensuring it is properly sealed.
- Attach the case to a clean, flat metal surface on the vehicle or asset you wish to track. The powerful magnets will hold it in place.
- Verify the device is securely attached by gently tugging on it. It should not move easily.



Image: The GPS tracker securely installed underneath a truck.



Image: A hand demonstrating the attachment of the magnetic case to a metal surface.

6. MAINTENANCE

To ensure optimal performance and longevity of your Optimus 3.0 GPS Tracker:

- **Regular Charging:** Recharge the device regularly to maintain battery life. The battery can last up to 2 months with default 1-minute update settings.
- **Case Inspection:** Periodically inspect the waterproof magnetic case for any signs of wear or damage to ensure it remains sealed and secure.
- **Software Updates:** Keep your mobile application and web browser updated to the latest versions for the best tracking experience and access to new features.


7. SPECIFICATIONS

Feature	Detail
Model	Optimus 3.0
Dimensions	6.34 x 4.72 x 3.31 inches (Package)
Item Weight	8.1 ounces
Battery	1 Lithium Polymer battery (included)
Battery Life	Up to 2 months (at 1-minute update setting)
Connectivity	Cellular

Feature	Detail
Special Features	Portable, Real-Time Tracking, Instant Alerts, Geofence, Speed Monitoring, History Reports
Interface Input	Buttons
Color	Black
Material	Plastic
Coverage	USA, Canada, and Mexico

Optimus 3.0 GPS Tracker

with Heavy Duty Magnetic Case



- Over 1 month battery life
- Real-Time Tracking
- Route Details
- 10 second updates
- Instant Alerts
- Geofence
- Speed Monitoring
- History Reports
- App and Web Access
- As low as \$15.95 per month*
- Coverage: USA, Canada and Mexico

Image: Optimus 3.0 GPS Tracker showing its dimensions and key features.

8. TROUBLESHOOTING

If you encounter issues with your Optimus 3.0 GPS Tracker, consider the following common troubleshooting steps:

- **No Signal/Location Updates:**

- Ensure the device is powered on and fully charged.
- Verify the device is in an area with good cellular and GPS reception (outdoors, away from heavy obstructions).
- Confirm your subscription is active and in good standing.
- Allow 10-15 minutes for initial GPS signal acquisition in an open area.

- **Battery Draining Quickly:**

- Check your update frequency settings. More frequent updates consume more battery. Adjust to a longer interval if extended battery life is needed.
- Ensure the device is not in an area with extremely poor signal, as it will consume more power trying to connect.

- **Device Not Charging:**

- Verify the USB charging cable is securely connected to both the device and the power source.
- Try a different USB cable or power adapter to rule out faulty accessories.

- **App/Web Portal Issues:**

- Ensure your internet connection is stable.
- Clear your browser cache or reinstall the mobile app.
- Check for any service outages or announcements from Optimus Tracking.

If these steps do not resolve your issue, please contact customer support.

9. WARRANTY AND SUPPORT

Optimus Tracking is committed to providing reliable products and excellent customer service. Your Optimus 3.0 GPS Tracker comes with a warranty. Please refer to the Warranty Information Card included in your package or visit the official website for full details on warranty coverage and exclusions.

For any questions, technical assistance, or support, please contact Optimus Tracking customer service:

- **Phone:** (855) 893-0707
- **Email:** support@optimustracker.com
- **Website:** www.optimustracker.com

Customer support is available Monday to Friday from 8 AM to 8 PM CT, and Saturday and Sunday from 9 AM to 5 PM CT.

© 2026 Optimus Tracking Corp. All rights reserved.

Legal Disclaimer: By purchasing this product, the customer agrees it is his or her responsibility to use the product and/or service in accordance with local, state, and federal laws. Optimus GPS Tracking Corp will not be responsible in any way the customer uses this product and/or service. Optimus GPS Tracking Corp will not be responsible for any lost property, damages of any kind during the use of the product and/or service.