Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

iJoy 44646

iJoy Chase Phone Stand Instruction Manual

Model: 44646

Introduction

The iJoy Chase Phone Stand is an intelligent device designed to enhance your video recording and photography experience. Featuring advanced face and object tracking, it automatically rotates 360 degrees to keep you or your subject in frame. This manual provides detailed instructions for setting up, operating, and maintaining your iJoy Chase Phone Stand.



Image: The iJoy Chase Phone Stand, a black device with a phone holder on top, shown with a smartphone actively tracking a person's face.

Product Features

- **Smart Tracking:** Intuitive face and object tracking ensures you stay in frame during recording.



Image: A split image demonstrating the smart tracking technology, with green tracking boxes highlighting a person's face and a dog's face.

- **360-Degree Movement:** The adjustable head rotates fully to follow your movement.



Image: A visual representation of the multi-rotational capabilities, showing the device tracking movement in a 360-degree arc and options for manual rotation.

- **Integrated App:** Download the dedicated iJoy Chase app for seamless Bluetooth pairing and access to tracking, filters, and effects.



Image: A graphic detailing the dedicated iJoy Chase app, highlighting Bluetooth auto-pairing, fun facial distortion filters, and cool effects and props, with QR codes for iOS and Android app downloads.

- **Wide Compatibility:** Fits most smartphones, including various iPhone and Samsung models.



Image: A depiction of the wide compatibility feature, showing the phone stand accommodating different phone sizes in both portrait and landscape modes, with green tracking boxes around faces.

- **Tripod Compatible:** Easily attach the iJoy Chase to an existing tripod for expanded use.



Image: The bottom of the iJoy Chase Phone Stand, highlighting its tripod compatibility with a screw mount, and showing QR codes for app downloads.

Package Contents

- iJoy Chase Phone Stand Unit
- USB Charging Cable (Type not specified, assume standard)
- User Manual (This document)

Setup

1. Charging the Device

Before first use, fully charge the iJoy Chase Phone Stand. Connect the provided USB charging cable to the charging port on the device and to a standard USB power adapter (not included). The charging indicator light will show the charging status.

2. Installing the App

The iJoy Chase requires a dedicated app for full functionality. Scan the QR code located on the bottom of the device or refer to the

product packaging to download the "iJoy Chase" app from your device's app store (iOS App Store or Google Play Store).

3. Pairing with Your Phone

1. Ensure your phone's Bluetooth is enabled.
2. Press and hold the power button on the iJoy Chase Phone Stand until the indicator light flashes, indicating it's in pairing mode.
3. Open the iJoy Chase app on your smartphone. The app will automatically detect and connect to the device via Bluetooth. No manual Bluetooth pairing from your phone's settings is typically required.
4. Once connected, the indicator light on the device will become solid.

4. Securing Your Smartphone

Gently pull apart the spring-loaded phone holder at the top of the stand and insert your smartphone. Ensure the phone is securely gripped by the holder. The stand supports both portrait and landscape orientations.

Operating Instructions

Power On/Off

- To power on, press and hold the power button until the indicator light illuminates.
- To power off, press and hold the power button until the indicator light turns off.

Using Face/Object Tracking

1. Ensure the iJoy Chase Phone Stand is powered on and successfully paired with the app.
2. Open the iJoy Chase app.
3. Within the app, select the desired tracking mode (face tracking or object tracking).
4. Position yourself or the object you wish to track within the camera's view. The app will display a green box around the detected subject.
5. The stand will automatically rotate to follow the detected subject, keeping it centered in the frame.

Manual Rotation

While the device is on, you can manually adjust the angle of the phone holder by gently rotating it. The 360-degree rotation allows for flexible positioning.

Using with a Tripod

The iJoy Chase Phone Stand features a standard 1/4-inch screw mount on its base, allowing it to be attached to most tripods. Simply screw the stand onto your tripod's mounting plate.

Maintenance

- **Cleaning:** Wipe the device with a soft, dry cloth. Do not use abrasive cleaners or immerse the device in water.
- **Storage:** Store the iJoy Chase Phone Stand in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge the device regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Device does not power on.	Low battery.	Charge the device fully using the provided USB cable.

Problem	Possible Cause	Solution
App cannot connect to the device.	Bluetooth is off on phone; device not in pairing mode; app not open.	Ensure phone's Bluetooth is on. Power cycle the iJoy Chase to enter pairing mode. Open the iJoy Chase app.
Face/Object tracking is not working.	Subject out of frame; insufficient lighting; app setting issue.	Ensure the subject is clearly visible within the camera's view. Provide adequate lighting. Check tracking settings within the iJoy Chase app.
Device is not rotating.	Tracking not activated; obstruction.	Verify tracking is active in the app. Ensure there are no physical obstructions preventing rotation.

Specifications

Brand	iJoy
Model Number	44646
Product Dimensions	3.6 x 3.6 x 6.7 inches
Item Weight	8.8 ounces (249 Grams)
Color	Black
Compatible Devices	iPhone, Samsung, and other compatible smartphones
UPC	842700167443

Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official iJoy website. Keep your proof of purchase for any warranty claims.

© 2024 iJoy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B08M4DX5PL

More documents and user manuals: **https://manuals.plus/**