

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BAYROL](#) /

› [BAYROL Mini Pool & Spa Leaf Skimmer - 25 cm Instruction Manual](#)

**BAYROL EAN4008367110505**

# BAYROL Mini Pool & Spa Leaf Skimmer - 25 cm Instruction Manual

## INTRODUCTION

This manual provides instructions for the safe and effective use of your BAYROL Mini Pool & Spa Leaf Skimmer. Designed for small pools and spas, this tool helps maintain water cleanliness by removing leaves and debris.



# Mini Pool & Spa

Für kleine Pools und Whirlpools aller Art

Image: BAYROL Mini Pool & Spa branding, illustrating the product's intended use in small pools and spas.

## PRODUCT OVERVIEW

The BAYROL Mini Pool & Spa Leaf Skimmer is a fine and robust net designed for efficient debris removal. It is compatible with standard telescopic poles for extended reach.

- **Efficient Cleaning:** Effectively collects leaves and debris from both the water surface and the bottom of small pools and spas.
- **Telescopic Pole Compatibility:** The handle can be removed to attach the skimmer to a standard telescopic pole (sold separately) for extended reach.
- **Durable Construction:** Features a robust frame and fine mesh net for long-lasting performance.



Image: The BAYROL Mini Pool & Spa Leaf Skimmer, showing its net and handle design.

## SETUP

1. **Inspect the Skimmer:** Before first use, check the skimmer net and frame for any damage or defects.
2. **Handheld Use:** For close-range cleaning, hold the skimmer by its integrated handle.
3. **Attaching a Telescopic Pole (Optional):**
  - Locate the attachment point on the skimmer handle.
  - Remove the existing handle if it obstructs the pole attachment.
  - Insert the telescopic pole (not included) into the designated slot and secure it according to the pole's instructions. Ensure a firm connection to prevent detachment during use.

## OPERATING INSTRUCTIONS

---

Follow these steps for effective cleaning of your pool or spa:

- Surface Cleaning:** Gently glide the skimmer across the water surface to collect floating leaves, insects, and other debris. Use slow, sweeping motions to avoid stirring up settled particles.
- Bottom Cleaning:** For debris settled at the bottom, slowly lower the skimmer to the pool floor. Carefully scoop up the debris, ensuring not to disturb it excessively, which could cloud the water.
- Emptying the Net:** Periodically lift the skimmer out of the water and empty the collected debris into a waste receptacle. Rinse the net if necessary to remove fine particles.
- Regular Use:** Regular skimming helps maintain water clarity and reduces the load on your filtration system.

## MAINTENANCE

---

- **Cleaning the Net:** After each use, rinse the skimmer net thoroughly with clean water to remove any remaining debris or chemical residues.
- **Inspection:** Regularly inspect the net for tears or holes and the frame for cracks or damage. Replace the skimmer if significant damage is found.
- **Storage:** Store the skimmer in a cool, dry place away from direct sunlight and harsh chemicals to prolong its lifespan.

## SAFETY INFORMATION

---

Please observe the following safety precautions:

- **Sharp Objects:** Exercise caution when handling the skimmer, especially if there are any sharp edges or broken parts.
- **Avoid Tangling:** Prevent the net from tangling with pool equipment or other objects.
- **Proper Disposal:** Dispose of the net properly if it becomes unusable or damaged.
- **Children:** Keep out of reach of children when not in use.

## SPECIFICATIONS

---

<b>Brand</b>	BAYROL
<b>Model Name</b>	Laubkescher
<b>Item Model Number</b>	EAN4008367110505
<b>ASIN</b>	B08M6DNF7J
<b>Product Dimensions</b>	10.6 x 10.6 x 17.5 cm
<b>Net Size</b>	25 cm
<b>Item Weight</b>	220 Grams
<b>Color</b>	Turquoise

Outer Material (Net)	Nylon
Frame Material	Rubber

## TROUBLESHOOTING

---

- **Net not collecting debris effectively:**
  - Check if the net is torn or has large holes. Replace if damaged.
  - Ensure you are using slow, deliberate motions to scoop debris, rather than pushing it away.
- **Skimmer detaches from telescopic pole:**
  - Verify that the telescopic pole is securely attached to the skimmer. Refer to the pole's instructions for proper attachment.
  - Ensure the attachment mechanism is clean and free of debris.
- **Water becomes cloudy after skimming:**
  - This can happen if debris at the bottom is stirred up too quickly. Use slower, gentler motions when cleaning the bottom.
  - Allow your pool's filtration system to run to clear the water.

## SUPPORT

---

For further assistance or inquiries regarding your BAYROL Mini Pool & Spa Leaf Skimmer, please refer to the manufacturer's official website or contact their customer support channels. Keep your product model number (EAN4008367110505) and ASIN (B08M6DNF7J) available when seeking support.