

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [Teufel](#) /
- › [Teufel Radio 3SIXTY User Manual](#)

Teufel 105959001

Teufel Radio 3SIXTY User Manual

Model: **105959001**

Brand: **Teufel**

INTRODUCTION

Welcome to the user manual for your Teufel Radio 3SIXTY. This guide provides detailed instructions on setting up, operating, maintaining, and troubleshooting your device. The Teufel Radio 3SIXTY is a versatile internet radio offering DAB+, FM, Bluetooth connectivity, and a unique 360-degree sound experience with an integrated subwoofer.



Image: Front view of the Teufel Radio 3SIXTY, showcasing its display, control knobs, and speaker grille.

SETUP

Unboxing and Placement

Carefully remove all components from the packaging. Ensure all accessories are present. Place the Radio 3SIXTY on a stable, flat surface. For optimal sound and ventilation, ensure there is sufficient space around the device.

Power Connection

Connect the provided power adapter to the 'POWER' input on the rear of the radio, then plug the adapter into a suitable wall outlet. The device will power on automatically or enter standby mode.

Antenna Connection

Extend the telescopic antenna located at the rear of the unit for optimal DAB+ and FM radio reception. Adjust its position for the best signal quality.

Network Configuration (Wi-Fi)

Upon first power-on, the radio will guide you through the initial setup, including Wi-Fi network configuration. Use the control knob to select your network and enter the password. A stable internet connection is required for Internet Radio and streaming services.

Bluetooth Pairing

To pair a Bluetooth device, select the Bluetooth source on the radio. On your smartphone or tablet, search for available Bluetooth devices and select 'Teufel Radio 3SIXTY'. Once connected, you can stream audio wirelessly.

USB and AUX-In Connections

The USB port allows for playback of audio files from a USB storage device. The AUX-In port enables connection of external audio sources using a 3.5mm audio cable.



Image: Rear view of the Teufel Radio 3SIXTY, showing the AUX IN, USB, and POWER ports, along with the telescopic antenna.

OPERATING INSTRUCTIONS

Controls Overview

The Teufel Radio 3SIXTY features intuitive controls. The left knob controls volume and acts as a snooze button. The right knob is for selection and navigation. Buttons below the display provide quick access to power, source, presets, alarm, and playback controls.



Image: Close-up view of the 'SELECT' knob on the Teufel Radio 3SIXTY, highlighting its textured surface and clear labeling.

Navigating the Menu

Use the right 'SELECT' knob to scroll through menu options displayed on the LCD screen. Press the knob to confirm a selection. The 'Back' button allows you to return to the previous menu.

Radio Modes

Internet Radio

Access thousands of global radio stations via your Wi-Fi connection. Browse by genre, location, or search for specific stations.

DAB+ Radio

Enjoy high-quality digital radio broadcasts. The radio will automatically scan for available DAB+ stations in your area.

FM Radio

Tune into traditional FM radio stations. Use the manual tuning or auto-scan function to find stations.

Bluetooth Audio Streaming

Once paired, select the Bluetooth source on the radio. Play audio from your connected device, and the sound will be output through the Radio 3SIXTY.

USB Playback

Insert a USB drive into the USB port. The radio will detect compatible audio files and allow you to browse and play them.

Alarm and Sleep Timer Functions

Set alarms to wake up to your favorite radio station or a buzzer. The sleep timer allows the radio to turn off

automatically after a set period.

Smart Features

The Teufel Radio 3SIXTY supports compatibility with Alexa and Amazon Music streaming services. It can also be conveniently controlled via the dedicated Teufel App or the TechniSat Connect App, offering enhanced control and navigation options.



Image: The Teufel Radio 3SIXTY positioned on a surface, with its remote control placed in front, illustrating its compact design and included accessories.

MAINTENANCE

Care and Cleaning

To clean the Teufel Radio 3SIXTY, disconnect it from the power supply. Use a soft, dry, lint-free cloth to wipe down the exterior. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Avoid spraying liquids directly onto the device.

TROUBLESHOOTING

Common Issues and Solutions

- **No Power:** Ensure the power adapter is securely connected to both the radio and a working power outlet. Try a different outlet.
- **No Sound:** Check the volume level on the radio and any connected Bluetooth device. Ensure the correct audio source is selected. If using AUX-In, check the cable connection.
- **Cannot Connect to Wi-Fi:** Verify your Wi-Fi password. Ensure the radio is within range of your router. Restart your router and the radio.
- **Poor Radio Reception (DAB+/FM):** Fully extend and adjust the telescopic antenna. Try relocating the radio to an area with better signal reception.
- **Device Unresponsive:** Disconnect the power cable from the radio for a few seconds, then reconnect it to perform a soft reset.

SPECIFICATIONS

















Technical Specifications

Feature	Detail
Brand	Teufel
Model Number	105959001
Color	Black
Connectivity Technology	USB, Bluetooth, Wi-Fi
Tuning Technology	FM, DAB+, Internet Radio
Supported Radio Bands	DAB+ (174-240 MHz)
Special Features	360-degree sound, Dynamore technology, Downfire subwoofer, Alexa and Amazon Music compatibility
Compatible Devices	Smartphone, Tablet, Laptop
Power Source	Electric Cable
Battery Composition	Lithium-ion (included)
Rechargeable Battery	Yes
Display Technology	LCD
Water Resistance Level	Not waterproof
Recommended Uses	Music

WARRANTY AND SUPPORT

Your Teufel Radio 3SIXTY comes with a manufacturer's warranty. For detailed information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Teufel website. For technical support, troubleshooting assistance, or service inquiries, please contact Teufel customer support through their official channels.

Related Documents - 105959001

<p>Technical Description And User Manual</p>  <p>RADIO 3SIXTY</p> <p>Radio with FM, DAB/DAB+, Internet radio, USB playback, Bluetooth®, Spotify Connect, Amazon Music® and app</p> 	<p>Teufel RADIO 3SIXTY: Technical Description and User Manual</p> <p>User manual for the Teufel RADIO 3SIXTY, detailing its features like FM/DAB/DAB+ radio, Internet radio, Bluetooth, Spotify Connect, Amazon Music, USB playback, setup, operation, safety, and troubleshooting.</p>
   <p>RADIO 3SIXTY</p>	<p>Teufel RADIO 3SIXTY: Quick Start Guide and Technical Specifications</p> <p>Concise guide to setting up and using the Teufel RADIO 3SIXTY internet radio with Bluetooth. Includes connection instructions, source selection, playback controls, and technical specifications.</p>
   <p>KOMBO 43</p>	<p>Teufel KOMBO 43 CD Receiver: Quick Start Guide</p> <p>A concise guide to setting up and operating the Teufel KOMBO 43 CD Receiver, covering its features, connections, source selection, radio tuning, Bluetooth pairing, CD playback, volume and sound adjustments, and technical specifications.</p>
   <p>RADIO ONE</p>	<p>Teufel RADIO ONE Bluetooth Speaker with DAB+/FM Radio and Alarm Clock - User Guide</p> <p>Concise guide to the Teufel RADIO ONE Bluetooth speaker, featuring DAB+/FM radio, alarm clock, and snooze functions. Learn how to connect, set up, and use its features.</p>
   <p>Flat-Subwoofer T4000</p>	<p>Teufel Flat-Subwoofer T4000 Quick Start Guide and Technical Data</p> <p>Comprehensive guide for the Teufel Flat-Subwoofer T4000, covering setup, wired and wireless connections, pairing instructions, room placement, and technical specifications.</p>
<p>Technical description and user manual</p>  <p>BOOMSTER 4</p> <p>Bluetooth® speaker with integrated DAB+/FM receiver</p> 	<p>Teufel BOOMSTER 4 Bluetooth Speaker User Manual and Technical Description</p> <p>Comprehensive user manual and technical description for the Teufel BOOMSTER 4 Bluetooth speaker, covering setup, operation, features like DAB+/FM radio, Bluetooth connectivity, and troubleshooting. Includes technical specifications and contact information.</p>