



Manuals.plus /

- › Lexon /
- › Lexon Mina Small Mushroom Lamp User Manual

Lexon Mina Small (LH60NG)

Lexon Mina Small Mushroom Lamp User Manual

Model: Mina Small (LH60NG)

[Instructions](#) [Introduction](#) [Maintenance](#) [What's in the Box](#) [Troubleshooting](#) [Setup](#) [Specifications](#) [Operating](#) [Warranty & Support](#) [Safety Information](#)

1. INTRODUCTION

The Lexon Mina Small Mushroom Lamp is a portable LED light designed for various indoor settings such as bedrooms, nurseries, and living rooms. It features a compact design, rechargeable battery, and adjustable light settings to suit different moods and needs.



Image 1: The Lexon Mina Small Mushroom Lamp in Glossy Black.

2. WHAT'S IN THE BOX

Upon unboxing your Lexon Mina Small Mushroom Lamp, please ensure all components are present:

- Lexon Mina Small Mushroom Lamp (1 unit)
- USB-C Charging Cable (1 unit)
- User Manual (this document)

3 DIFFERENT SIZES



Image 2: The Lexon Mina lamp is available in three sizes. This manual refers to the Small size (Mina).

3. SETUP

3.1 Initial Charging

Before first use, fully charge your Lexon Mina lamp. Use the provided USB-C cable to connect the lamp to a compatible USB power source (e.g., computer, wall adapter). A full charge typically takes approximately 2 hours and provides up to 12 hours of battery life, depending on brightness settings.



Image 3: Connect the USB-C cable to the charging port located at the base of the lamp.

3.2 Placement

Place the lamp on a stable, flat surface. Its compact and cordless design allows for flexible placement in any indoor area where ambient lighting is desired.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off and Light Mode Selection

The Lexon Mina lamp is controlled by a single push button located at its base. Press the button to cycle through the following modes:

1. **First Press:** Turns on the lamp with warm light.
2. **Second Press:** Switches to cold light.
3. **Third Press:** Turns off the lamp.



Image 4: Control the lamp by pressing the button at its base to switch between warm and cold light modes.

4.2 Dimming Function (Memory Dimmer)

To adjust the brightness, press and hold the button while the lamp is on. The light will dim or brighten. Release the button when the desired brightness level is reached. The lamp features a memory dimmer, meaning it will recall your last brightness setting when turned on again.

5. MAINTENANCE

- **Cleaning:** Wipe the lamp with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the lamp in a cool, dry place when not in use for extended periods.
- **Battery Care:** To prolong battery life, avoid fully discharging the lamp frequently. Recharge it when the light becomes dim.
- **Water Resistance:** This product is **not water resistant**. Avoid exposure to water or high humidity.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp using the provided USB-C cable.
Light is dim or flickers.	Low battery.	Recharge the lamp.
Cannot change light mode or dim.	Button malfunction or internal issue.	Ensure the button is pressed correctly. If the issue persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	MINA-GLOSSY-BLACK (LH60NG)
Brand	Lexon
Dimensions (D x W x H)	2.7" x 2.7" x 3.2"
Item Weight	88 Grams
Material	Aluminum
Light Source Type	LED
Power Source	Battery Powered (Rechargeable via USB-C)
Battery Life	Up to 12 hours
Charging Time	Approx. 2 hours
Control Method	Push Button / Touch (for dimming)
Features	Cordless, Warm & Cold Light Modes, Memory Dimmer
Water Resistance	Not Water Resistant

8. WARRANTY & SUPPORT

The Lexon Mina Small Mushroom Lamp comes with a manufacturer's warranty. For specific warranty details and to register your product, please visit the official Lexon website or contact Lexon customer support. Keep your purchase receipt for warranty claims.

Customer Support: For technical assistance, troubleshooting, or warranty inquiries, please refer to the contact information provided on the Lexon official website or your product packaging.

9. SAFETY INFORMATION

- Do not expose the lamp to water or moisture. This product is not waterproof.
- Do not attempt to disassemble or modify the lamp. This may void the warranty and pose a safety risk.
- Keep out of reach of small children to prevent accidental ingestion of small parts.
- Use only the provided USB-C cable for charging.
- Avoid extreme temperatures.

- If the lamp is damaged, discontinue use immediately and contact customer support.

10. PRODUCT VIDEOS

The MINA Collection by Lexon

Your browser does not support the video tag.

Video 1: An overview of the Lexon MINA lamp collection, showcasing its design and features.

Meet the MINA by Lexon

Your browser does not support the video tag.

Video 2: A short introduction to the Lexon MINA lamp, highlighting its portability and ease of use.