Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- > Thrustmaster /
- > Thrustmaster Ferrari 458 Racing Wheel for Xbox 360 User Manual

Thrustmaster Ferrari 458 Racing Wheel

Thrustmaster Ferrari 458 Racing Wheel for Xbox 360 User Manual

Model: Ferrari 458 Racing Wheel

INTRODUCTION

Welcome to the user manual for your Thrustmaster Ferrari 458 Racing Wheel for Xbox 360. This manual provides essential information for setting up, operating, and maintaining your racing wheel to ensure an optimal gaming experience. Designed for immersive racing simulation, this wheel offers precise control and a realistic feel, enhancing your gameplay on the Xbox 360 console.

PACKAGE CONTENTS

Please verify that all components listed below are included in your package.

- Thrustmaster Ferrari 458 Racing Wheel
- Pedal Set (Accelerator and Brake)
- Attachment System (for table mounting)
- User Manual (this document)



Image: The retail packaging of the Thrustmaster Ferrari 458 Racing Wheel, showing the wheel and pedal set.



Image: The Thrustmaster Ferrari 458 Racing Wheel and its accompanying pedal set, ready for setup.

SETUP

1. Attaching the Racing Wheel

- 1. Place the racing wheel on a stable, flat surface such as a desk or table.
- 2. Secure the wheel using the integrated clamping system. Turn the screw mechanism clockwise until the wheel is firmly attached. Ensure the table thickness is suitable for the clamp.



Image: Front view of the racing wheel, highlighting the central Ferrari logo and various control buttons.

2. Connecting the Pedal Set

- Connect the cable from the pedal set to the designated port on the back of the racing wheel.
- Place the pedal set on the floor in front of your seating position. For optimal stability, consider placing it against a wall or using a non-slip mat, as the pedals are relatively light.

3. Connecting to Xbox 360

- Plug the USB connector from the racing wheel into an available USB port on your Xbox 360 console.
- The console should automatically detect the racing wheel. The Xbox Guide button on the wheel will illuminate when connected.
- Ensure no other controllers are signed in as the primary player if you intend to use the wheel exclusively for driving.

OPERATING INSTRUCTIONS

The Thrustmaster Ferrari 458 Racing Wheel is designed to provide an intuitive and responsive racing experience.

Wheel Controls

- Steering Wheel: Provides 270 degrees of rotation for precise steering input.
- Paddle Shifters: Located behind the wheel, these metal shifters (UP/DOWN) allow for quick gear changes in compatible games.
- Action Buttons: The wheel features standard Xbox 360 action buttons (A, B, X, Y) for in-game commands.
- **D-Pad:** For menu navigation and specific in-game functions.
- Xbox Guide Button: Accesses the Xbox 360 dashboard.
- Engine Start Button: A red button that can be mapped to various functions in games.

Pedal Controls

- Accelerator Pedal: The right pedal controls acceleration.
- Brake Pedal: The left pedal controls braking. Both pedals offer progressive resistance for realistic feel.

In-Game Settings

For the best experience, adjust your in-game controller settings to recognize and optimize for a racing wheel. Many racing games offer specific calibration options for steering linearity, dead zones, and pedal sensitivity.

MAINTENANCE

- Cleaning: Use a soft, dry cloth to clean the wheel and pedals. Avoid abrasive cleaners or solvents.
- **Storage:** Store the racing wheel and pedal set in a cool, dry place away from direct sunlight and extreme temperatures.
- Cable Management: Avoid sharp bends or kinks in the cables to prevent damage.

TROUBLESHOOTING

Issue	Possible Solution
Wheel not recognized by Xbox 360.	Ensure the USB cable is securely plugged into the console. Try a different USB port. Restart the Xbox 360 console.
Pedals are slipping on the floor.	Place the pedal set against a wall or a sturdy object. Use a non-slip mat or carpet underneath the pedals.
Wheel feels loose or unstable on the table.	Tighten the clamping screw mechanism. Ensure the table surface is flat and the thickness is within the clamp's range.
In-game controls are not responsive or feel off.	Check the in-game controller settings and calibrate the wheel if the option is available. Ensure no other controllers are interfering with the wheel's input.

SPECIFICATIONS

• Product Type: Racing Wheel and Pedal Set

• Compatibility: Xbox 360, PC (with compatible drivers/software)

• Steering Rotation: 270 degrees

• Pedals: Accelerator and Brake (progressive resistance)

Connectivity: Wired USBASIN: B08MBMBDPG

• Date First Available: October 30, 2020

WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official documentation provided by Thrustmaster.

A copy of the warranty document can be found here: Thrustmaster Warranty Information (PDF) For further assistance, please visit the official Thrustmaster support website.

© 2023 Thrustmaster. All rights reserved.

Related Documents - Ferrari 458 Racing Wheel

Europa Rédite East Berth America' Britanties des Br	Thrustmaster TX Racing Wheel Ferrari 458 Italia Edition User Manual for Xbox One / Xbox Series X S Comprehensive user manual for the Thrustmaster TX Racing Wheel Ferrari 458 Italia Edition, detailing setup, technical specifications, safety warnings, and operational guides for Xbox One and Xbox Series X S gaming consoles.
	Ferrari 458 Spider Racing Wheel User Manual and Setup Guide This document provides instructions for setting up, configuring, and troubleshooting the Thrustmaster Ferrari 458 Spider Racing Wheel for Xbox One and Xbox Series X S consoles. It includes technical specifications, sensitivity adjustments, and safety warnings.
	Thrustmaster Ferrari 458 Spider Racing Wheel Setup and Troubleshooting Guide Comprehensive guide for setting up, configuring, and troubleshooting the Thrustmaster Ferrari 458 Spider Racing Wheel for Xbox One and Xbox Series X S consoles.
	Thrustmaster Ferrari 458 Spider Racing Wheel for Xbox One User Manual User manual for the Thrustmaster Ferrari 458 Spider Racing Wheel, providing setup, usage, and troubleshooting instructions for Xbox One.

