

## Fayleeko LBWG-801

# Fayleeko Wall Mounted 4-Digit Combination Key Lock Box (Model LBWG-801) Instruction Manual

Model: LBWG-801 | Brand: Fayleeko

## 1. PRODUCT OVERVIEW

The Fayleeko Wall Mounted 4-Digit Combination Key Lock Box is designed to provide secure storage for your keys, access cards, or other small valuables. Constructed from high-strength zinc alloy and heavy-duty stainless steel, it offers robust protection against tampering. The ABS shell provides effective resistance against rain, dust, snow, and sun exposure, making it suitable for both indoor and outdoor use.

This lock box features a customizable 4-digit combination, offering 10,000 unique code possibilities for enhanced security. Its spacious interior can accommodate up to 5 house keys (shorter than 3.35 inches).

### How to Set Your New Combination



Image 1: Overview of Fayleeko Key Lock Box features: High Security, Easy to Install, Weatherproof, and Large Capacity.

## 2. SETUP AND INSTALLATION

The Fayleeko Key Lock Box is designed for easy wall mounting. All necessary hardware is included in the package.

## 2.1 Package Contents:

- 1 x Fayleeko Key Lock Box
- 4 x Mounting Screws
- 4 x Nylon Expansion Plugs
- 1 x Instruction Manual

## 2.2 Installation Steps:

1. **Mark Screw Locations:** Open the lock box and hold it against the desired wall surface. Use a pencil to mark the four screw locations through the pre-drilled holes on the back of the box.
2. **Drill Holes:** Using an appropriate drill bit, drill four holes at the marked locations.
3. **Insert Expansion Plugs:** Gently tap the nylon expansion plugs into the drilled holes with a hammer until they are flush with the wall surface.
4. **Mount the Lock Box:** Align the lock box with the installed expansion plugs. Insert the mounting screws and tighten them securely with a screwdriver. Ensure the lock box is firmly attached to the wall.



Image 2: Visual guide for wall installation, showing marking, drilling, inserting plugs, and securing the box.

## 3. OPERATING INSTRUCTIONS

---

### 3.1 Setting Your Combination:

The default combination for the lock box is 0-0-0-0. Follow these steps to set your personalized 4-digit code:

1. **Open the Lock Box:** Dial the default code (0-0-0-0) to open the key box.
2. **Locate Reset Lever:** Inside the lock box, locate the reset lever on the back of the door.
3. **Move Lever to 'B':** Push the reset lever from position 'A' to position 'B'.
4. **Set New Combination:** Rotate the dials to your desired 4-digit combination. Choose a memorable but secure code.
5. **Move Lever to 'A':** Push the reset lever back from position 'B' to position 'A'. Your new combination is now set.

**Important: Always record your new password immediately after setting it, by taking a photo or**

writing it down. If the password is forgotten, there is no way to retrieve it.



Image 3: Steps for setting a new 4-digit combination.

### 3.2 Opening and Closing the Lock Box:

- **To Open:** Dial your set 4-digit combination. Push the black lever down to release the front cover.
- **To Close:** Place keys or items inside. Close the front cover firmly until it clicks into place. Scramble the dials to lock the box and conceal your combination.

## Don't Worry about Forgetting Your Keys



Image 4: Demonstrating how to open the lock box and insert keys.



Image 5: Close-up of the combination dials for setting and entering codes.

## 4. MAINTENANCE

To ensure the longevity and proper functioning of your Fayleeko Key Lock Box, follow these maintenance guidelines:

- **Regular Cleaning:** Wipe the exterior with a soft, damp cloth to remove dust and dirt. Avoid abrasive cleaners.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the moving parts of the combination dials and the opening mechanism to ensure smooth operation.
- **Weather Protection:** Keep the shutter door closed when not in use to protect the dials from rain, dust, and other environmental elements.
- **Dial Rotation:** Rotate the dials weekly to prevent them from sticking due to prolonged exposure or lack of use.
- **Avoid Extreme Conditions:** Do not use the lock box in extreme temperatures or expose it to open flames.
- **Secure Mounting:** Regularly check the mounting screws to ensure the lock box remains securely attached to the surface.

## 5. TROUBLESHOOTING

---

If you encounter issues with your Fayleeko Key Lock Box, consider the following:

- **Difficulty Opening:**
  - Ensure the correct 4-digit combination is entered.
  - Verify that the dials are aligned precisely with the indicator marks.
  - Apply light pressure to the front cover while entering the code, then release and try to open.
  - If the dials feel stiff, apply a small amount of lubricant as described in the Maintenance section.
- **Forgotten Combination:**
  - Unfortunately, if the combination is forgotten and not recorded, there is no master key or override function to open the lock box. This is a security feature to prevent unauthorized access.
- **Physical Damage:**
  - If the lock box is visibly damaged or broken, its security integrity may be compromised. Consider replacing the unit.

## 6. SPECIFICATIONS

---

Feature	Detail
Brand	Fayleeko
Model Number	LBWG-801
Product Dimensions	1.6"D x 3.54"W x 4.7"H
Lock Type	Mechanical Code Lock (4-Digit Combination)
Color	Black
Capacity	Up to 5 house keys (shorter than 3.35 inches)
Material	High-strength Zinc Alloy, Heavy-duty Stainless Steel, ABS Shell
Special Features	Anti-Theft, Combination Lock, Portable, Waterproof
Mounting Type	Wall Mount
Item Weight	7.7 ounces (0.48 Pounds)



Image 6: Dimensions and key capacity of the Fayleeko Key Lock Box.

## 7. WARRANTY AND SUPPORT

---

Fayleeko offers a 100% satisfaction guarantee or a 30-day money-back guarantee. For any questions or concerns regarding your key lock box, please contact Fayleeko customer support for assistance. For further information or support, please visit the official Fayleeko Store:[Fayleeko Store on Amazon](#).