

[Manuals.plus](#) /

› [Linkidea](#) /

› Linkidea USB Zoom Meeting Button User Manual

Linkidea LI3467

Linkidea USB Zoom Meeting Button User Manual

Model: LI3467

PRODUCT OVERVIEW

The Linkidea USB Zoom Meeting Button is a dedicated hardware controller designed to simplify your online meeting experience on Windows PCs. It provides quick access to essential Zoom functions: muting/unmuting your microphone and starting/stopping your video, all with a simple press of a button. This plug-and-play device requires no driver installation, making it an efficient tool for online classes, conferences, and virtual meetings.

PACKAGE CONTENTS

- 1 x Linkidea USB Zoom Meeting Button (White)
- 1 x USB-A Connection Cable (150 cm / 6.5 feet)



Image: The Linkidea USB Zoom Meeting Button in white, shown with its included USB-A connection cable. The button unit features two distinct keys for control.

COMPATIBILITY

This device is specifically designed for use with the **Windows Zoom meeting application only**. It is not compatible with macOS, browser-based Zoom applications, or other conferencing platforms such as Microsoft Teams or Cisco WebEx.

External Button with Start/Stop Video Mute/Unmute Microphone Audio windows zoom application



Windows 10/8/7/XP



Desktop



Laptop



ZOOM



USB HUB

Image: A visual representation of the product's compatibility, indicating support for Windows operating systems (Windows 10/8/7/XP), desktop PCs, laptops, and connection via a USB hub, specifically for the Zoom application.

BUTTONS AVAILABLE

BUTTON NOT AVAILABLE



Note: To use the conference button, please use it on the conference page. If you are not on the conference page, you cannot use it.

Image: This image illustrates the operational requirement: the buttons are functional only when the Zoom conference window is actively in focus. The left side shows a typical Zoom meeting screen with a green checkmark, indicating functionality. The right side shows a desktop with the Zoom application icon, but not an active meeting, marked with a red cross, indicating non-functionality in this state.

SETUP INSTRUCTIONS

1. **Connect the Cable:** Insert the micro USB end of the provided connection cable into the port on the Linkidea USB Zoom Meeting Button.
2. **Connect to PC:** Plug the USB-A end of the cable into an available USB port on your Windows desktop PC or laptop. You may also use a USB hub.
3. **Plug & Play:** The device is plug-and-play and does not require any driver installation. Your computer should automatically recognize the device.
4. **Launch Zoom:** Open the Zoom meeting application on your Windows PC and join or start a meeting.

ZOOM Conference Button USB-A Connector, plug and play




Image: The Linkidea USB Zoom Meeting Button connected via its white USB cable to a laptop, demonstrating a typical setup for use during online meetings.

OPERATING INSTRUCTIONS

Once connected and with the Zoom application in focus, the buttons will control your microphone and video status.

- **Mute/Unmute Microphone:** Press the button with the microphone icon (typically the left button) to toggle your microphone's mute status.
- **Start/Stop Video:** Press the button with the video camera icon (typically the right button) to toggle your video feed on or off.

Important Note: For the buttons to function, the Zoom meeting window must be the active application on your screen. If you switch to another program, the buttons may not respond until you bring the Zoom window back into focus.




Micro USB Charging Port



Non-slip Gasket



Button Identification



Mechanical Buttons

Image: A composite image showing detailed views of the product. It highlights the Micro USB Charging Port, Non-slip Gaskets on the base, the Button Identification icons (microphone and video camera), and the internal Mechanical Buttons (red shafts) that provide tactile feedback.



Image: A user's hand is shown pressing the Linkidea USB Zoom Meeting Button, which is connected to a laptop. In the background, a large screen displays a video conference, illustrating the device's use in a typical meeting environment.

MAINTENANCE

The Linkidea USB Zoom Meeting Button requires minimal maintenance.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the device. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Cable Care:** Avoid bending or kinking the USB cable excessively to prevent internal damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Buttons do not respond.	<p>Not connected properly.</p> <p>Zoom application not in focus.</p> <p>Incompatible operating system or application.</p>	<p>Ensure the USB cable is securely plugged into both the device and your PC. Try a different USB port.</p> <p>Make sure the Zoom meeting window is the active window on your desktop.</p> <p>Verify you are using a Windows PC and the official Zoom desktop application. This device is not compatible with macOS or browser-based Zoom.</p>
Device not recognized by PC.	<p>Faulty USB port.</p> <p>Damaged cable.</p>	<p>Try connecting the device to a different USB port on your computer.</p> <p>Test with another USB cable if available, though the provided cable is recommended.</p>
Buttons feel sticky or unresponsive.	<p>Debris under keycap.</p> <p>Mechanical switch issue.</p>	<p>Gently try to remove any visible debris around the keycaps. Do not attempt to disassemble the unit.</p> <p>If the issue persists, contact customer support.</p>

SPECIFICATIONS

Model Number	LI3467
Dimensions	1.97 x 1.97 x 1.18 inches (5cm x 5cm x 1.4cm)
Weight	2.54 ounces (72 Grams)
Material	Acrylic Base, Red Shaft Mechanical Keyboard Buttons
Color	White
Connector Type	USB-A (Male-to-Male cable included)
Cable Length	150 cm (6.5 feet)
Power Source	Corded Electric (USB 5V DC)
Compatible Platform	Windows PC (Desktop, Laptop)
Compatible Application	Zoom Meeting App (Windows desktop version only)

WARRANTY AND SUPPORT

For warranty information or technical support, please contact Linkidea customer service through the retailer where you purchased the product or visit the official Linkidea website. Please have your model number (LI3467) and purchase details ready when contacting support.

Manufacturer: Linkidea