



Manuals.plus /

› tectake /

› tectake 403197 Trevi Rattan Cafe Set - User Manual

tectake 403197

tectake 403197 Trevi Rattan Cafe Set - User Manual

Model: 403197

1. PRODUCT OVERVIEW

The tectake Trevi Rattan Cafe Set is a three-piece furniture ensemble designed for both indoor and outdoor use. It features an elegant design, high flexibility, and comfort, making it ideal for small balconies, terraces, or patios. The set includes two chairs and one table, all constructed with a robust powder-coated steel frame and durable poly rattan weaving. A key feature of this set is its foldable design, allowing for compact storage and easy transport. The materials are UV-protected and designed for easy cleaning.



Image 1.1: The tectake Trevi Rattan Cafe Set, featuring two chairs and a table, displayed in an outdoor setting. The set is grey and has a woven poly rattan finish on a dark metal frame.

2. SAFETY INSTRUCTIONS

- Ensure the furniture is placed on a stable, level surface to prevent tipping.
- Do not exceed the maximum load capacities: 120 kg for each chair and 45 kg for the table.
- Keep children under supervision when near the furniture, especially during folding/unfolding.
- Avoid placing hot items directly on the table surface without protection.
- Regularly inspect the furniture for any signs of wear or damage. Do not use if damaged.
- When folding or unfolding, ensure fingers and other body parts are clear of moving parts to prevent pinching.

3. PACKAGE CONTENTS

Verify that all components are present and undamaged upon receipt. The package should contain:

- 2 x tectake Trevi Rattan Chairs (Grey)
- 1 x tectake Trevi Rattan Table (Grey)

No additional assembly hardware is included as the set is delivered pre-assembled.

4. SETUP

The tectake Trevi Rattan Cafe Set requires no assembly. All elements are delivered pre-assembled and ready for immediate use.

4.1 Unfolding the Chairs

1. Carefully remove the folded chair from its packaging.
2. Hold the chair frame and gently pull the seat and backrest apart until the chair locks into its open position.
3. Ensure all four plastic feet are firmly on the ground and the chair is stable before use.

4.2 Unfolding the Table

1. Remove the folded table from its packaging.
2. Unfold the table legs outwards until they are fully extended and locked into place.
3. Place the table on a flat surface, ensuring it is stable and does not wobble.




- 1. Smart hopfällbar funktion**
möjliggör platsbesparande förvaring och enkel transport av rottingsetet



- 2. Praktisk och flexibel**
perfekt för alla med lite utrymme: detta set passar även på små balkonger och terrasser



- 3. Golvvänliga plastfötter**
säkerställer hög stabilitet och skyddar golv från skador



- 4. Fint utformad väv**
av särskilt högkvalitativ polyrotting garanterar stark hållbarhet

Image 4.1: Visual representation of the smart folding function for compact storage and easy transport of the rattan set.

5. OPERATING AND USAGE

The tectake Trevi Rattan Cafe Set is designed for versatile use in various settings, both indoors and outdoors.

- **Placement:** Position the set on a stable, flat surface. The plastic feet are designed to protect floors.
- **Outdoor Use:** The poly rattan material is UV-protected and weather-resistant, making it suitable for balconies, patios, and gardens.
- **Indoor Use:** Its compact size and elegant design also make it suitable for indoor spaces where extra seating or a small table is needed.
- **Folding for Storage:** When not in use, the chairs and table can be easily folded to save space. To fold, reverse the unfolding steps, ensuring the locking mechanisms are disengaged.

UPPLEV STUNDER AV NJUTNING



 **tectake**[®]
GARDEN

EN PLATS FÖR MYSIGA STUNDER

Skapa en plats på din uteplats för att dricka kaffe, varva ner eller bara chill. Den slående utemöbeln med bord och stolar för två personer skapar en avkopplande atmosfär var som helst på nolltid.

Image 5.1: The cafe set in use, demonstrating its suitability for creating a comfortable outdoor seating area for two.

6. MAINTENANCE

Maintaining your tectake Trevi Rattan Cafe Set is simple due to its durable materials.

- **Cleaning:** Wipe down the poly rattan and steel frame with a damp cloth and mild soap solution. Rinse with clean water and dry thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Storage:** For prolonged periods of non-use, especially during harsh weather conditions, it is recommended to store the folded set indoors or cover it with a protective furniture cover to extend its lifespan.
- **Inspection:** Periodically check all joints and screws to ensure they are tight. The set features robust, rust-free screws for enhanced durability.



Image 6.1: Detail highlighting the 100% rust-free screws used in the construction of the furniture, ensuring longevity.

7. TROUBLESHOOTING

- **Issue: Furniture wobbles.**

Solution: Ensure the furniture is placed on a completely flat and stable surface. Check that all legs are fully extended and locked into position. The plastic feet are designed to provide stability.

- **Issue: Difficulty folding/unfolding.**

Solution: Ensure no obstructions are present in the folding mechanism. Apply gentle, even pressure. Do not force the mechanism. Refer to the setup section for correct procedure.

- **Issue: Surface appears dirty or faded.**

Solution: Clean the surface as described in the Maintenance section. The poly rattan is UV-protected, but prolonged exposure to extreme sunlight can still cause minor fading over many years. Regular cleaning helps maintain its appearance.

8. SPECIFICATIONS

MÅTT



Totalmått stol
ca. 46 x 51 x 84 cm

Mått på hopfälld stol
ca. 46 x 12 x 96 cm

Sitthöjd
ca. 46 cm

Totalmått bord
ca. 59 x 59 x 72 cm

Mått på hopfällt bord
ca. 59 x 14 x 92 cm



Lastkapacitet

Stol 120 kg
Bord 45 kg

Vikt
Stol ca. 3 kg
Bord ca. 4 kg




Image 8.1: Comprehensive dimensions for the chairs and table, both in their open and folded states.

Feature	Measurement
Chair Total Dimensions (WxDxH)	approx. 45 x 54.5 x 81 cm
Chair Folded Dimensions (WxDxH)	approx. 45 x 12 x 94 cm
Chair Seat Area (WxD)	approx. 41 x 39 cm
Chair Seat Height	approx. 46 cm
Chair Backrest (WxH)	approx. 44 x 19.5 cm
Table Total Dimensions (LxWxH)	approx. 59 x 59 x 72 cm
Table Folded Dimensions (WxDxH)	approx. 59 x 14 x 92 cm
Chair Load Capacity	120 kg
Table Load Capacity	45 kg
Chair Weight	approx. 3.2 kg
Table Weight	approx. 4 kg
Materials	Powder-coated steel, Poly rattan (Polyester)
Color	Grey
Assembly Required	No

9. WARRANTY INFORMATION

This product is covered by a standard manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary based on your region and point of purchase. Please retain your proof of purchase for any warranty claims.

For detailed warranty information, please refer to the documentation provided with your purchase or contact tectake customer support.

10. CUSTOMER SUPPORT

Should you have any questions, require assistance with your product, or need to report a defect, please contact tectake customer support.

Please have your product model number (403197) and proof of purchase ready when contacting support to ensure efficient service.

For contact details, please visit the official tectake website or refer to the contact information provided by your retailer.

