



[Manuals.plus](#) /

> [Motorola Sound](#) /

> Motorola Escape 220 Over-The-Ear Bluetooth Wireless Headphones User Manual

Motorola Sound SH057-White

Motorola Escape 220 Over-The-Ear Bluetooth Wireless Headphones User Manual

Model: SH057-White

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Motorola Escape 220 Over-The-Ear Bluetooth Wireless Headphones. Please read this manual thoroughly before using the product to ensure optimal performance and longevity. Keep this manual for future reference.



Image: Motorola Escape 220 Over-The-Ear Bluetooth Wireless Headphones, showcasing the white over-ear design with the Motorola logo on the earcups.

PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- Escape 220 Wireless Over-ear Headphones

- USB Charging Cable
- 3.5 mm Audio Cable
- Quick Start Instruction Guide
- General Information

PRODUCT FEATURES

The Motorola Escape 220 headphones are designed with several key features for an enhanced audio experience:

- **Extended Battery Life:** Up to 23 hours of continuous play time on a single charge.
- **Integrated Microphone:** For clear, hands-free calling.
- **High-Definition Audio:** Equipped with 40mm sound drivers for crisp and clear sound.
- **Wireless Connectivity:** Bluetooth technology for untangled listening freedom.
- **Comfortable Design:** Cushioned ear caps and an adjustable headband ensure a soft and comfortable fit for extended wear.
- **Passive Noise Isolation:** Helps to reduce external distractions for a more immersive listening experience.
- **Foldable Design:** Compact and convenient for storage and travel.
- **Voice Assistant Compatibility:** Works with Siri, Alexa, and Google Assistant.



Image: A man wearing the Motorola Escape 220 headphones, with an overlay highlighting key features such as Bluetooth 5.0, 24-hour battery life, passive noise isolation, HD sound, lightweight design, foldable ear cups, in-line microphone, and voice assistant compatibility.

SETUP

1. Charging the Headphones

Before initial use, fully charge your Motorola Escape 220 headphones. Use the provided USB charging cable to connect the headphones to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator light will provide status. A full charge provides up to 23 hours of play time.

2. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the Power button on the headphones until the indicator light flashes blue and red, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.

4. Select "Motorola Escape 220" from the list of found devices.
5. Once connected, the indicator light on the headphones will turn solid blue or flash blue slowly.

Note: The headphones will automatically attempt to reconnect to the last paired device when powered on.

OPERATING INSTRUCTIONS

Power On/Off

- **To Power On:** Press and hold the Power button until the indicator light turns blue.
- **To Power Off:** Press and hold the Power button until the indicator light turns red and then off.

Music Playback

Use the controls on the headphones to manage your audio:

- **Play/Pause:** Press the Multi-function button once.
- **Next Track:** Press and hold the Volume Up button.
- **Previous Track:** Press and hold the Volume Down button.
- **Volume Up:** Press the Volume Up button briefly.
- **Volume Down:** Press the Volume Down button briefly.



Image: A man running outdoors while wearing the Motorola Escape 220 headphones, illustrating the product's portability and long battery life for uninterrupted music.

Call Management

The built-in microphone allows for hands-free calls:

- **Answer/End Call:** Press the Multi-function button once.
- **Reject Call:** Press and hold the Multi-function button for 2 seconds.
- **Redial Last Number:** Double-press the Multi-function button.

In-Line Microphone

For hands-free calling



Image: A man smiling while wearing the Motorola Escape 220 headphones, emphasizing the convenience of the in-line microphone for hands-free calling.

Voice Assistant Activation

Activate your device's voice assistant (Siri, Alexa, Google Assistant) by pressing the Multi-function button twice quickly. This allows you to issue voice commands directly through your headphones.

MAINTENANCE

Proper care ensures the longevity of your headphones:

- **Cleaning:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use abrasive cleaners, solvents, or spray directly onto the headphones.
- **Storage:** When not in use, store the headphones in a cool, dry place. The foldable design allows for compact storage.
- **Avoid Moisture:** Keep the headphones away from water and excessive humidity.

- **Temperature:** Avoid exposing the headphones to extreme temperatures (hot or cold).

Foldable Design
Perfect for travel



Image: The Motorola Escape 220 headphones being folded and placed into a suitcase, demonstrating their compact and travel-friendly design for easy storage.



Designed for
Extra Comfort
with soft ear cushions

Image: A man wearing the Motorola Escape 220 headphones while relaxing on a couch with a laptop, illustrating the comfortable fit provided by the soft ear cushions.

TROUBLESHOOTING

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source using the USB cable.
Cannot pair with device.	Ensure headphones are in pairing mode (flashing blue/red light). Make sure Bluetooth is enabled on your device. Move headphones closer to the device. Forget "Motorola Escape 220" from your device's Bluetooth list and try pairing again.

Problem	Possible Solution
No sound or low volume.	Increase volume on both headphones and connected device. Ensure headphones are properly connected to the device. Check if the 3.5mm audio cable is connected if using wired mode.
Poor call quality.	Ensure the microphone is not obstructed. Move closer to your connected device. Check network signal strength on your phone.




Image: A woman wearing the Motorola Escape 220 headphones, demonstrating the effect of passive noise isolation in helping to tune out distractions.

SPECIFICATIONS

Feature	Detail
Model Number	SH057-White
Connectivity Technology	Wireless (Bluetooth)
Headphones Jack	3.5 mm Jack (for wired use)
Battery Life	Up to 23 Hours
Battery Type	1 Lithium Ion battery (included)
Control Type	Voice Control
Item Weight	180 Grams (6.3 ounces)
Product Dimensions	7.48 x 7.05 x 8.35 inches
Manufacturer	Binatone
UPC	816479017919, 816479017926
Noise Control	Passive Noise Cancellation

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the "General Information" document included in your package or visit the official Motorola Sound website. Keep your proof of purchase for warranty claims.

For further assistance, you may contact Motorola Sound customer service through their official channels.

© 2024 Motorola Sound. All rights reserved.

Motorola and the Stylized M Logo are trademarks or registered trademarks of Motorola Trademark Holdings, LLC.