

Cosatto CT3920

Cosatto Hug Isofix Anti-Escape Group 123 Car Seat Instruction Manual

Model: CT3920

INTRODUCTION

This manual provides essential instructions for the safe and correct installation, operation, and maintenance of your Cosatto Hug Isofix Anti-Escape Group 123 Car Seat. Designed for children weighing 9 kg to 36 kg (approximately 9 months to 12 years), this car seat features ISOFIX connectivity and the Cosatto 5-point Plus Anti-Escape System. Please read this manual thoroughly before use and keep it for future reference.

IMPORTANT SAFETY INFORMATION

- **Airbag Warning:** Never place a child in a passenger seat equipped with an active front airbag. Airbags are designed to protect adults but can have the opposite effect on children.
- **Correct Installation:** Always ensure the car seat and base are mounted correctly and are compatible with your child and vehicle. Refer to this instruction manual for proper installation.
- **Harness Use:** Ensure the 5-point harness is correctly adjusted and secured at all times.
- **Regular Checks:** Periodically check all components for wear, damage, or loose parts.

SETUP AND INSTALLATION

The Cosatto Hug Isofix car seat is designed for easy and secure installation using the ISOFIX system.

ISOFIX Installation

1. Locate the ISOFIX anchor points in your vehicle.
2. Extend the ISOFIX connectors from the car seat base.
3. Push the ISOFIX connectors onto the vehicle's anchor points until you hear a "click" and the indicators turn green.
4. Push the car seat firmly against the vehicle seat back to ensure a tight fit.

5. If applicable, connect the top tether strap to the designated anchor point in your vehicle and tighten it.



Image: Side view of the Cosatto Hug Isofix car seat, illustrating the extended ISOFIX connectors at the base for secure vehicle attachment.

Harness Adjustment

The 5-point harness system adjusts automatically when the headrest height is regulated. Ensure the shoulder straps are at or just below your child's shoulders when rear-facing, and at or just above when forward-facing.

OPERATING INSTRUCTIONS

Securing Your Child

1. Place your child in the car seat.
2. Bring the shoulder straps over your child's shoulders and connect the buckle tongues into the central buckle.
3. Pull the harness adjustment strap to tighten the harness until it is snug against your child's body, ensuring you can only fit one finger between the strap and your child's collarbone.

Anti-Escape System

The exclusive Cosatto 5-point Plus Anti-Escape System is designed to prevent children from wriggling out of the harness. Ensure the anti-escape mesh is properly positioned over your child's chest and secured with the harness.



Image: Front view of the car seat, highlighting the 5-point harness and the integrated anti-escape system designed to keep the child secure.

Recline Positions

The car seat features five recline positions for your child's comfort. To adjust, locate the recline lever (usually at the front or base of the seat) and move the seat to the desired position. Ensure the seat clicks securely into place.



Image: Side profile of the car seat, demonstrating an upright recline position suitable for older children.



Image: Side profile of the car seat, showing a reclined position for younger children or for napping.

MAINTENANCE

Cleaning Instructions

The car seat cover is removable and washable for convenience.

1. Carefully remove the fabric cover from the car seat frame.
2. Refer to the care label on the cover for specific washing instructions (typically machine wash cold on a gentle cycle).
3. Do not tumble dry. Allow to air dry completely before reattaching.
4. Wipe the plastic and metal parts of the car seat frame with a damp cloth and mild soap. Do not use harsh chemicals or abrasive cleaners.

TROUBLESHOOTING

- **Harness too tight/loose:** Adjust the harness strap and ensure the headrest is at the correct height for your child.

- **Difficulty with Anti-Escape System:** Ensure the mesh is flat and not twisted before securing the harness. If persistent issues occur, review the manual's operating section or contact support.
- **Seat feels insecure after ISOFIX installation:** Double-check that both ISOFIX connectors are fully engaged (green indicators visible) and that the seat is pushed firmly against the vehicle seat back. Ensure the top tether (if used) is taut.
- **Child escaping harness:** Re-verify the harness tightness and the correct use of the anti-escape system. Ensure the shoulder pads are correctly positioned.

SPECIFICATIONS

Feature	Detail
Product Dimensions	64 x 50 x 50 cm
Item Weight	11 kg
Model Number	CT3920
Gender	Unisex
Minimum Weight Recommendation	9 kg
Maximum Weight Recommendation	36 kg
Material	Polyester, Steel, Plastic
Additional Features	Exclusive Cosatto 5-point Plus Anti-Escape System
Harness Type	5-point
Installation Type	ISOFIX

WARRANTY INFORMATION

The Cosatto Hug Isofix Anti-Escape Group 123 Car Seat comes with a 4-year warranty. Please retain your proof of purchase for warranty claims. For full terms and conditions, refer to the warranty card included with your product or visit the official Cosatto website.

SUPPORT AND CONTACT

For further assistance, product registration, or to view other Cosatto products, please visit the official Cosatto store.

[Visit the Cosatto Store on Amazon](#)

PRODUCT VIDEOS

No official product videos from the seller were found to be relevant for embedding in this instruction manual.

