

## LucidSound LS15X

# LucidSound LS15X Wireless Gaming Headset User Manual

Model: LS15X | Brand: LucidSound

## INTRODUCTION

The LucidSound LS15X Wireless Gaming Headset is officially licensed for use on Xbox, offering an immersive audio experience for gamers. Designed for comfort and performance, this headset features intuitive on-earcup controls, low-latency wireless connectivity, and a versatile dual-mic system. Enjoy crystal-clear communication and rich audio across Xbox One, Xbox Series X|S, Nintendo Switch, PC, and mobile devices.

## WHAT'S IN THE BOX

- Wireless Headset
- Removable Boom Mic
- Micro-USB Charging Cable
- USB Wireless Transmitter
- Quick Start Guide



Image: LucidSound LS15X Wireless Gaming Headset, showing the main product.

## PRODUCT FEATURES

- **Quick Access Audio Controls:** Easily adjust headset volume, game/chat balance, mic mute, game audio mute, and mic monitoring via on-earcup controls.
- **Seamless Wireless Connectivity:** Low latency, interference-free wireless provides a strong connection even in crowded Wi-Fi environments. Quick and easy to set up.
- **Designed for Comfort:** Ultra-lightweight frame and memory foam earpads allow for hours of comfortable gaming.
- **Premium Audio:** Custom-tuned 50mm drivers and 3 EQ modes (Signature, Bass Boost, Neutral) enhance positional awareness. Supports spatial sound with Windows Sonic.
- **Dual-Mic System:** Features a flexible boom mic with an LED mute indicator for precision chat. Detach the boom mic to activate the built-in backup mic.
- **Mic Monitoring:** Hear your own voice in the headset to manage your output. Can be disabled by holding

the button on the right earcup for 3 seconds.

- **Rechargeable Battery:** Provides up to 15 hours of use on a single charge. Check battery level by holding the button on the left earcup for 3 seconds.

## SETUP GUIDE

---

### 1. Initial Charge

Before first use, fully charge your LS15X headset using the provided Micro-USB charging cable. Connect the cable to the headset's charging port and a USB power source. The LED indicator will show charging status.

### 2. Connecting to Xbox

1. Insert the USB Wireless Transmitter into an available USB port on your Xbox console.
2. Power on the headset by holding the power button on the left earcup.
3. The headset will automatically pair with the transmitter. A solid LED on both the headset and transmitter indicates a successful connection.

### 3. Connecting to PC/Nintendo Switch/Mobile

For PC, Nintendo Switch (docked mode), or other compatible devices, insert the USB Wireless Transmitter into an available USB port. The headset will connect automatically. For mobile devices, the headset can be used via a 3.5mm audio cable (not included) if wireless is not preferred or supported.

Your browser does not support the video tag.

Video: Official LucidSound LS15X Surround Sound overview, demonstrating key features and setup.

## OPERATING INSTRUCTIONS

---

### Headset Controls

- **Left Earcup:**
  - Rotate the outer ring to adjust *headset volume*.
  - Press the center button to *mute game audio*.
  - Hold the center button for 3 seconds to check *battery level*.
- **Right Earcup:**
  - Rotate the outer ring to adjust *game/chat balance*.
  - Press the center button to *mute microphone*. The boom mic LED will illuminate red when muted.
  - Hold the center button for 3 seconds to toggle *mic monitoring* on/off.
- **EQ Modes:** The headset features 3 EQ modes. Press the dedicated EQ button (location varies slightly by model, typically near the power button) to cycle through Signature, Bass Boost, and Neutral modes.



Image: LucidSound LS15X Headset with the removable boom microphone attached.



Image: Close-up of the LucidSound LS15X earcup, highlighting the intuitive control layout.

## MAINTENANCE

---

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use harsh chemicals or abrasive materials.
- **Storage:** Store the headset in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headset regularly, even if not in use for extended periods.

## TROUBLESHOOTING

---

### No Audio / Disconnection

- Ensure the headset is powered on and fully charged.
- Verify the USB Wireless Transmitter is securely plugged into the console/PC.
- Re-pair the headset by powering both off and on again.
- Check console/PC audio settings to ensure the headset is selected as the output device.

Microphone Issues

- Ensure the boom mic is securely attached.
- Check if the microphone is muted (red LED on boom mic indicates mute). Press the mic mute button on the right earcup to unmute.
- Verify mic monitoring is enabled if you wish to hear your own voice.
- Check console/PC audio settings for microphone input levels.

SPECIFICATIONS

Feature	Detail
Model Number	LS15X
Connectivity Technology	Wireless (Wi-Fi)
Headphones Jack	3.5 mm Jack
Material	Memory Foam
Item Weight	12.5 ounces (0.78 Pounds)
Product Dimensions	3.94 x 7.87 x 7.87 inches
Battery	1 Lithium Polymer battery (included)
Manufacturer	PowerA

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official LucidSound website or contact their customer service directly. Keep your proof of purchase for any warranty claims.

