

VASAGLE BBC001G01

VASAGLE BBC001G01 Under-Sink Bathroom Cabinet: Assembly and Care Instructions

Brand: VASAGLE | Model: BBC001G01

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your VASAGLE BBC001G01 under-sink bathroom cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

The VASAGLE BBC001G01 is a stylish and functional under-sink cabinet designed to maximize storage space in your bathroom. It features high-quality MDF construction with a durable lacquered surface, offering resistance to moisture and ease of cleaning. The cabinet includes two doors with chrome metal handles that open up to 180 degrees, protecting your stored items from dust and water. Inside, an adjustable shelf provides versatile storage options for various items.



Image: The VASAGLE BBC001G01 under-sink cabinet in grey, featuring two doors, positioned under a white rectangular sink in a modern bathroom setting.

2. SAFETY INFORMATION

Please observe the following safety precautions during assembly and use:

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Do not overtighten.
- Do not stand on or overload the cabinet.
- Always use the provided anti-tip device to secure the cabinet to the wall.

2.1 Anti-Tip Device Installation

To prevent accidental tipping and ensure stability, it is mandatory to install the anti-tip device. Follow the instructions provided in your assembly hardware kit to securely attach the strap to the top rear of the cabinet and fasten it to a solid wall stud or appropriate wall anchor.



Image: A close-up showing the anti-tip strap securely attached to the top rear of the cabinet and fastened to a wall, illustrating a crucial safety measure.

3. COMPONENTS AND DIMENSIONS

Before assembly, verify that all components listed in your hardware package are present. The cabinet's overall dimensions and the specific siphon cutout are critical for proper fit under your sink.




Image: A diagram illustrating the external dimensions of the grey VASAGLE under-sink cabinet (60 cm width, 30 cm depth, 60 cm height) and the siphon cutout dimensions (20 cm width, 15 cm depth). An internal view shows the adjustable shelf.

- **Overall Cabinet Dimensions (L x W x H):** 60 x 30 x 60 cm
- **Siphon Opening Dimensions:** 20 x 15 cm
- **Material:** Engineered Wood (MDF)
- **Color:** Grey

4. ASSEMBLY INSTRUCTIONS

4.1 Before You Begin

- **Measure Your Sink:** Before assembly, carefully measure the dimensions of your sink and siphon to

ensure compatibility with the cabinet's cutout. The cabinet's siphon opening is 20 x 15 cm.

- **Clear the Area:** Ensure you have sufficient space for assembly and that the area is clean and free of obstructions.
- **Identify Parts:** All parts are marked for easy identification. Refer to the included assembly diagram for a complete list of components and hardware.

4.2 Step-by-Step Assembly

Follow the detailed, step-by-step instructions and diagrams provided in your product packaging. General steps include:

1. Attach the side panels to the bottom panel.
2. Install the back panel.
3. Assemble the top panel, ensuring the siphon cutout is correctly oriented.
4. Attach the door hinges to the cabinet frame and doors.
5. Install the door handles and magnetic catches.
6. Insert the adjustable shelf at your desired height.
7. Install the anti-tip device as described in Section 2.1.



Image: Detailed view of the cabinet's features, including the magnetic catch for the door, the chrome metal door handles, and the metal hinges.

5. OPERATION

5.1 Door Usage

The cabinet features two doors equipped with chrome metal handles. These doors can be opened up to 180 degrees, providing full access to the interior. Close the doors gently to engage the magnetic catches and keep your items protected.

5.2 Adjustable Shelf

The interior of the cabinet includes one adjustable shelf. This shelf can be positioned at three different heights to accommodate items of varying sizes. To adjust the shelf, remove any items, lift the shelf, and reposition the shelf pins into the desired holes on the side panels. Ensure the shelf is level and securely seated on all four pins before placing items on it.



Image: An illustration demonstrating the adjustable shelf mechanism inside the cabinet, showing how the shelf can be moved up or down to three different height positions.



Image: The grey VASAGLE under-sink cabinet with both doors open, revealing an adjustable shelf inside. Various bathroom items like towels, soap dispensers, and bottles are stored within. A white rectangular sink is visible on top.



Image: A close-up view inside the VASAGLE under-sink cabinet, focusing on the siphon pipe passing through the top panel and the adjustable shelf below. Towels and bath salts are visible on the shelf.

6. CARE AND MAINTENANCE

- **Cleaning:** The lacquered surface is durable and easy to clean. Wipe the cabinet with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Moisture:** While the cabinet is moisture-resistant, avoid prolonged exposure to excessive water. Wipe up spills immediately.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

- **Cabinet Does Not Fit Under Sink:**
 - a. Verify your sink and siphon dimensions against the cabinet's specifications (60 x 30 x 60 cm, siphon opening 20 x 15 cm).
 - b. Note that the adjustable shelf inside the cabinet does **not** have a pre-cut siphon opening. Depending on your siphon's configuration, you may need to modify the adjustable shelf to accommodate the pipe.

- **Cabinet Appears Unstable:**

- a. Ensure all assembly screws are tightened securely.
- b. Confirm the cabinet is placed on a level surface.
- c. Verify that the anti-tip device is correctly installed and securely fastened to the wall.

- **Doors Do Not Close Properly:**

- a. Check that the hinges are correctly aligned and tightened.
- b. Ensure the magnetic catches are properly installed and aligned with the door magnets.

8. PRODUCT SPECIFICATIONS

Attribute	Value
Brand	VASAGLE
Model Number	BBC001G01
Color	Grey
Product Dimensions (L x W x H)	60 x 30 x 60 cm
Material	Engineered Wood (MDF)
Item Weight	9 Kilograms
Special Feature	Durable, Adjustable Shelf
Mounting Type	Floor Mount
Room Type	Bathroom
Door Style	Swing Door

9. WARRANTY AND SUPPORT

Specific warranty information for the VASAGLE BBC001G01 under-sink bathroom cabinet is not provided in the product details. For any questions regarding warranty, missing parts, or assembly assistance, please contact the retailer or manufacturer directly through their official support channels.

Spare parts availability information is not available. Please contact customer service for inquiries regarding replacement parts.