Yamazaki 5125

Yamazaki Kitchen Freestanding Steel Panel (Vertical, Black) Model 5125 Instruction Manual

1. Introduction

Thank you for purchasing the Yamazaki Kitchen Freestanding Steel Panel, Vertical, Black, Model 5125. This product is designed to enhance kitchen organization by providing a versatile surface for magnetic storage tools. It helps utilize space efficiently behind your stove, sink, or preparation area, and can also serve as a splash guard.

2. Product Overview

The Yamazaki Freestanding Steel Panel offers a customizable storage solution for your kitchen. Its robust steel construction ensures stability and durability. The panel is designed to be freestanding, allowing flexible placement without permanent installation. It is compatible with a wide range of separately sold magnetic accessories, enabling you to create a personalized storage system.

Key Features:

- **Magnetic Surface:** Allows attachment of various magnetic kitchen tools and accessories.
- **Freestanding Design:** No drilling or permanent installation required.
- **Space Utilization:** Maximizes vertical space behind cooking or sink areas.
- **Splash Guard Functionality:** Protects walls from oil and water splashes.
- **Customizable:** Arrange magnetic items to suit your specific needs.



Image: The freestanding steel panel showcasing various magnetic kitchen tools and spice containers.



Image: The panel positioned behind a kitchen sink, demonstrating its use for organizing cutting boards and cleaning items.

3. Setup

The Yamazaki Freestanding Steel Panel requires minimal assembly. Please follow these steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components are present: the main steel panel and its base feet.
2. **Attach Base Feet:** The panel comes with two base feet. Align each foot with the designated slots at the bottom of the main panel. Securely attach them. The panel is designed to stand upright once the feet are properly installed.
3. **Placement:** Position the assembled panel on a flat, stable surface in your desired kitchen area, such as behind the

stove, sink, or on a countertop. Ensure the panel is stable and does not wobble.

No tools are typically required for assembly, as the design is often snap-on or slide-in for the base feet.




Image: Product dimensions for proper placement and fit.

4. Operating Instructions (Usage)

This steel panel is designed to work with magnetic kitchen accessories (sold separately). Its primary function is to provide a vertical storage surface and act as a splash guard.

1. **Attaching Magnetic Accessories:** Simply place any magnetic storage tools (e.g., spice racks, utensil holders, hooks, timers) onto the steel panel. The strong magnetic surface will hold them securely.
2. **Customization:** Arrange your magnetic accessories in any configuration that best suits your workflow and storage needs. You can easily reposition them as required.
3. **Utilizing Included Hooks:** The product includes hooks that can be freely attached to the top bar of the panel. Use these for hanging utensils, dishcloths, or other small items.
4. **Splash Guard:** When placed behind a stove or sink, the panel acts as a barrier to protect your walls from oil splatters and water splashes, keeping your kitchen cleaner.



Image: Close-up view of the included hooks attached to the panel's top bar, suitable for hanging small items.



Image: The panel in use, demonstrating how magnetic accessories like a paper towel holder and spice jars can be organized.

5. Maintenance

To ensure the longevity and appearance of your steel panel, follow these maintenance guidelines:

- **Regular Cleaning:** Wipe the panel regularly with a soft, damp cloth and a mild detergent.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can scratch or damage the powder-coated finish.
- **Dry Thoroughly:** After cleaning, dry the panel completely with a clean, dry cloth to prevent water spots or rust.
- **Magnetic Surface Care:** Ensure that the magnetic accessories you use have smooth backs to avoid scratching the panel's surface.

6. Troubleshooting

If you encounter any issues with your Yamazaki Steel Panel, consider the following:

- **Panel Instability:** Ensure the base feet are fully and correctly attached. Make sure the panel is placed on a flat, even surface. Avoid placing excessively heavy items on one side, which could cause imbalance.
- **Magnetic Items Not Sticking:** Confirm that the items you are trying to attach are indeed magnetic. Ensure the panel surface is clean and free from debris that might interfere with magnetic adhesion.
- **Scratches on Surface:** Always handle magnetic accessories carefully. Avoid dragging items across the panel surface. Use magnetic accessories with protective backings if possible.

7. Specifications

Specification	Detail
Model Number	5125
Color	Black
Style Name	Freestanding Steel Panel Vertical
Product Dimensions (D x W x H)	14 cm x 56 cm x 51.5 cm (approx.)
Product Weight	2.9 kg
Material	Alloy Steel (Powder Coating finish)
Mounting Type	Magnetic
Room Type	Kitchen
Assembly Required	Yes
Special Feature	Customizable

8. Warranty and Support

For warranty information or product support, please refer to the documentation included with your purchase or contact Yamazaki customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question