Payper Wear 000218-0053-14000

Payper Wear Alaska Jacket User Manual

Model: 000218-0053-14000

Introduction Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

Introduction

This manual provides essential information for the proper use and care of your Payper Wear Alaska Jacket. Please read these instructions carefully before using the product to ensure optimal performance and longevity.
The Payper Wear Alaska Jacket is designed for adult men, featuring an ergonomic cut and water-resistant soft-shell material, making it suitable for autumn and winter conditions. It includes various functional elements for comfort and utility, such as a foldable hood, adjustable cuffs, and multiple zippered pockets. The jacket also features internal zippers to facilitate custom printing or embroidery.

Setup and Initial Inspection

Upon receiving your Payper Wear Alaska Jacket, perform the following steps:

1. **Unpacking:** Carefully remove the jacket from its packaging.
2. **Visual Inspection:** Examine the jacket for any signs of damage or manufacturing defects. Check all zippers, seams, and adjustable components.
3. **Fit Check:** Try on the jacket to ensure a comfortable and appropriate fit. Adjust cuffs and waist drawstring as needed.



Image: Front view of the Payper Wear Alaska Jacket. Note the full-length SBS zipper and the high collar.

Operating Instructions

The Alaska Jacket is designed for versatility and protection. Utilize its features as follows:

- **Main Zipper:** The full-length SBS zipper allows for easy donning and doffing, and ventilation control. Ensure the zipper is fully closed for maximum warmth and protection.
- **Foldable Hood:** The hood can be folded and stored within the collar. To deploy, unzip the collar compartment and pull out the hood. To store, fold neatly and secure it back into the collar.
- **Adjustable Cuffs:** Use the rubber wrist strap and Velcro fasteners on the cuffs to adjust tightness, providing a secure fit and preventing cold air entry.
- **Pockets:**

- **Side Pockets:** Two zippered side pockets for hand warming or storing small items.
- **Chest Pocket:** One zippered chest pocket with an invisible badge holder for identification or small essentials.
- **Skipass Pocket:** A zippered pocket on the sleeve, ideal for ski passes or other small, frequently accessed items.
- **Inner Pocket:** An internal pocket for secure storage of valuables.

- **Waist Drawstring:** Adjust the drawstring at the waist to cinch the jacket for a tighter fit, enhancing warmth and preventing drafts.



Image: Side view of the jacket, highlighting the zippered side pocket and the sleeve pocket.



Image: Angled front view, illustrating the chest pocket with its invisible badge holder.

Maintenance and Care

Proper care will extend the life and maintain the performance of your jacket.

Washing Instructions:

- **Machine Wash:** The jacket is machine washable. Always follow the care label instructions sewn into the garment.
- **Temperature:** Wash in cold or lukewarm water (maximum 30°C / 86°F) on a gentle cycle.
- **Detergent:** Use a mild detergent. Avoid bleach or harsh chemicals, as these can damage the fabric and water-resistant properties.

- **Zippers and Fasteners:** Close all zippers and Velcro fasteners before washing to prevent snagging or damage.
- **Drying:** Tumble dry on low heat or hang to air dry. Avoid high heat, which can damage the soft-shell material. Do not iron.
- **Storage:** Store the jacket in a cool, dry place away from direct sunlight when not in use.



Image: Back view of the jacket, illustrating the smooth soft-shell material.

Troubleshooting

This section addresses common issues you might encounter with your jacket.

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Zipper snagging or sticking	Fabric caught in zipper, dirt/debris, or lack of lubrication.	Gently pull fabric away. Clean zipper teeth with a small brush. Apply a zipper lubricant (e.g., wax or silicone spray) if needed.
Water repellency decreasing	Dirt buildup, detergent residue, or wear over time.	Wash the jacket according to care instructions. Consider using a DWR (Durable Water Repellent) re-treatment spray designed for outdoor apparel.
Velcro fasteners losing grip	Lint or debris accumulated in the hook side of the Velcro.	Use a stiff brush or tweezers to carefully remove lint and debris from the Velcro hooks.

Specifications

Feature	Detail
Brand	Payper Wear
Model Number	000218-0053-14000
Material Composition	93% Polyester, 7% Elastane (Soft-Shell)
Fabric Weight	330 GR/MQ
Color	Black (Note: Product images may show dark blue variant)
Water Resistance	Water-resistant / Waterproof
Closure Type	Full-length SBS Zipper
Sleeve Type	Long Sleeve
Collar Style	Officer Collar with Foldable Hood
Pockets	2 Zippered Side Pockets, 1 Zippered Chest Pocket (with invisible badge holder), 1 Zippered Skipass Pocket, 1 Inner Pocket
Adjustments	Adjustable Cuffs (rubber strap & Velcro), Waist Drawstring
Recommended Season	Autumn, Winter
Care Instructions	Machine Wash

Warranty and Support

For warranty information or product support, please refer to the official Payper Wear website or contact your retailer. Keep your purchase receipt as proof of purchase.
Manufacturer: Payper Wear
ASIN: B08MQ9QRKT
Reference Constructeur: 000218-0053-14000
For further assistance, please visit www.payperwear.com (example link, actual link not provided in data).

© 2023 Payper Wear. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question