

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Homecraft](#) /

› [Homecraft 3-Quart Iced Coffee and Tea Maker with Filter Basket, Flavor Enhancer, Adjustable Brew Strength, Black 3 Qt Iced Tea/Coffee Maker Black](#)

Homecraft HomeCraft

Homecraft 3-Quart Iced Coffee and Tea Maker

Model: HomeCraft | Brand: Homecraft

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions before operating this appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or any part of the main unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot liquid.
- Do not use appliance for other than intended use.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.

PARTS IDENTIFICATION

- Main Unit (Base)
- Water Reservoir
- Shower Head
- Removable Filter Basket
- Strength Selector (Potency Slider)
- Start/Stop Button
- 3-Quart Pitcher with Lid



Image: The complete Homecraft 3-Quart Iced Coffee and Tea Maker, showcasing its sleek black design and clear pitcher filled with iced tea and lemon slices.

ULTIMATE BREWING MACHINE



potency slider
choose your
preferred strength



**product
dimensions:**
13"d x 9"w x 17"h



Image: A close-up of the Homecraft brewing machine's top section, highlighting the potency slider for adjusting brew strength and indicating product dimensions.

REMOVABLE FILTER BASKET

works with **ground
coffee, tea bags
and loose tea**



Image: An overhead view showing the removable filter basket filled with coffee grounds, illustrating its compatibility with ground coffee, tea bags, and loose tea.

BEFORE FIRST USE

Before using your Homecraft Iced Coffee and Tea Maker for the first time, wash the pitcher, lid, and removable filter basket in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.

SETUP

1. Place the Iced Coffee and Tea Maker on a stable, level surface away from the edge of a countertop.
2. Ensure the 3-Quart Pitcher is correctly positioned on the base.
3. Open the lid of the water reservoir located on the side of the main unit. Fill the water reservoir with fresh, cold water up to the desired fill line indicated on the pitcher (either "Water" or "Ice" line, depending on whether you will add ice to the pitcher).
4. Place the removable filter basket into its designated slot under the shower head.
5. Add your desired amount of fresh ground coffee, loose-leaf tea, or tea bags into the removable filter basket. Refer to the "Operating Instructions" for recommended quantities.

OPERATING INSTRUCTIONS

Brewing Iced Tea or Coffee

1. Follow steps 1-5 in the "Setup" section.
2. If making iced tea/coffee, fill the 3-Quart Pitcher with ice cubes up to the "Ice" fill line. If making hot tea/coffee to be chilled later, fill the pitcher with cold water up to the "Water" fill line.
3. Adjust the Strength Selector (potency slider) on the front of the unit to your preferred brew strength. Slide it to the left for lighter brew or to the right for stronger brew.
4. Plug the appliance into a grounded electrical outlet.
5. Press the Start/Stop button located on the side of the unit. The indicator light will illuminate, and brewing will begin. The shower head design ensures optimal saturation of your ingredients.
6. Once the brewing cycle is complete, the unit will automatically shut off, and the indicator light will turn off.
7. Carefully remove the pitcher from the base. The brewed beverage is now ready to serve or store.
8. Always unplug the appliance from the electrical outlet immediately after use.



Image: The Homecraft Iced Tea and Coffee Maker alongside its pitcher filled with iced tea, demonstrating the ease of making gourmet iced drinks quickly.



Iced Tea



Iced Coffee



Iced Latte



Flavored
Water

Image: A collage showing various iced beverages that can be made with the machine, including iced tea, iced coffee, iced latte, and flavored water.

ADJUSTABLE BREW STRENGTH

The Homecraft Iced Coffee and Tea Maker features an adjustable strength selector. This allows you to customize the intensity of your brew to suit your personal preference. Simply slide the lever on the front of the unit:

- Slide to the **left** for a lighter, milder brew.
- Slide to the **right** for a stronger, more robust brew.

Experiment with different settings and quantities of tea/coffee to find your ideal strength.

CLEANING AND MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and optimal performance of your appliance.

1. Always unplug the unit from the electrical outlet and allow it to cool completely before cleaning.
2. Remove the 3-Quart Pitcher, lid, and removable filter basket. Wash these parts in warm, soapy water. They are also top-rack dishwasher safe.
3. Wipe the exterior of the main unit with a damp, non-abrasive cloth. Do not use harsh abrasive cleaners or scouring pads.
4. **NEVER** immerse the main unit, cord, or plug in water or any other liquid.

5. For optimal performance, periodically descale the unit by running a cycle with a mixture of water and white vinegar (1:1 ratio) through the machine without any tea or coffee. Follow with two cycles of plain water to rinse.
6. Ensure all parts are completely dry before reassembling and storing the appliance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit does not turn on.	Not plugged in; power button not pressed.	Ensure the unit is securely plugged into a working electrical outlet. Press the Start/Stop button firmly.
Brew is too weak.	Insufficient tea/coffee; strength selector set too low.	Increase the amount of tea/coffee used. Adjust the Strength Selector to a higher setting.
Brew is too strong.	Too much tea/coffee; strength selector set too high.	Decrease the amount of tea/coffee used. Adjust the Strength Selector to a lower setting.
Water overflows from the reservoir.	Overfilled water reservoir.	Do not fill the water reservoir beyond the maximum fill line. Ensure the pitcher is correctly placed.







SPECIFICATIONS

- **Brand:** Homecraft
- **Model Name:** HomeCraft 3-Quart Black Stainless Steel Café' Iced Tea And Iced Coffee
- **Model Number:** HomeCraft
- **Color:** Black
- **Product Dimensions:** 13"D x 9"W x 17"H
- **Item Weight:** 5.21 pounds
- **Capacity:** 3 Quarts (approx. 12 cups)
- **Voltage:** 120 Volts (AC)
- **Filter Type:** Reusable Filter Basket
- **Operation Mode:** Fully Automatic
- **UPC:** 082677002426

WARRANTY AND SUPPORT

For warranty information or product support, please refer to the warranty card included with your purchase or contact Homecraft customer service directly. Contact details can typically be found on the manufacturer's official website or on the product packaging.

Related Documents - HomeCraft

	<p>HomeCraft 100-Cup Stainless Steel Coffee Urn HCCU100SS Instruction Manual Nostalgia Products LLC</p> <p>Official instruction manual for the HomeCraft HCCU100SS 100-Cup Stainless Steel Coffee Urn. Includes setup, operation, safety guidelines, cleaning, maintenance, and warranty information from Nostalgia Products LLC.</p>
	<p>HomeCraft CU30SS 30-Cup Stainless Steel Coffee Urn Instruction Manual</p> <p>Instruction manual for the HomeCraft CU30SS 30-Cup Stainless Steel Coffee Urn. Learn how to safely operate, clean, and maintain your coffee urn for optimal performance. Includes safety precautions, features, and warranty information.</p>
	<p>Homecraft Revive Sauna Heater Installation Manual</p> <p>Installation guide for Homecraft Revive sauna heaters (6kw, 7.5kw, 9kw). Covers electrical specifications, safety guidelines, sauna rock usage, control installation, and warranty. ETL approved.</p>
	<p>Homecraft Apex Sauna Heater Installation and User Guide</p> <p>Comprehensive guide for installing and using the Homecraft Apex sauna heater, covering safety, electrical specifications, installation steps, and warranty information for models 10kW, 12kW, 15kW, and 18kW.</p>
	<p>HomeCraft 30-Cup Stainless Steel Coffee Urn: Operation and Maintenance Guide</p> <p>A comprehensive guide on how to operate and maintain the HomeCraft 30-Cup Stainless Steel Coffee Urn, including brewing coffee and heating water, along with cleaning instructions and helpful tips.</p>
	<p>HOMECRAFT Sauna Heater and Controls Installation & Wiring Guide</p> <p>Official installation and wiring manual for HOMECRAFT FHSH series sauna heaters and TKE2-3 control systems. Includes safety, specifications, step-by-step setup, operation, troubleshooting, and warranty information.</p>

