

Bush Furniture WC31331

Bush Furniture Cabot 60W Hutch User Manual

Model: WC31331 - Modern Gray

1. INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Bush Furniture Cabot 60W Hutch. Designed to complement coordinating Cabot 60W Computer Desks (sold separately), this hutch offers additional storage and display space for your home office. Please read these instructions carefully before beginning assembly and retain for future reference.

2. SAFETY INFORMATION

Your safety is important. Please observe the following guidelines:

- **Wall Attachment:** For maximum stability and safety, especially in homes with children, it is crucial to anchor the hutch to a wall using the included hardware. Failure to do so may result in tipping and potential injury.
- **Weight Limits:** Do not overload shelves or compartments. Distribute weight evenly to maintain stability.
- **Assembly:** Ensure all components are correctly assembled and fasteners are tightened according to the assembly instructions. Periodically check all connections for tightness.
- **Standards Compliance:** This product has been rigorously tested to meet or exceed ANSI/SOHO quality standards for safety and performance.




Image 2.1: Safety features including the anti-tip restraint wall anchor.

3. PRODUCT OVERVIEW

The Bush Furniture Cabot 60W Hutch provides versatile storage and display options. Key features include:

- **Closed Storage:** A center cabinet with a fluted glass door that flips up to conceal items.
- **Open Shelves:** Two open shelves on the left and right sides for books, decorations, or frequently accessed items.
- **Open Cubbies:** Three open cubbies at the bottom for easy access to work-in-progress materials.
- **Cable Management:** A dedicated space at the bottom allows for convenient routing of cords and cables.



Image 3.1: Front view of the Cabot 60W Hutch, showcasing its storage compartments.



Image 3.2: The hutch integrated into a home office setup, demonstrating its functional use.



Image 3.3: Detail of the fluted glass door, providing a semi-transparent view of stored items.

4. ASSEMBLY INSTRUCTIONS

Assembly of the Bush Furniture Cabot 60W Hutch is required. Please follow the detailed instructions provided in the separate assembly guide included with your product packaging. Ensure you have all components and tools listed before beginning. It is recommended to assemble the hutch on a soft, clean surface to prevent scratches.

- **Component Identification:** Refer to the parts list in your assembly guide to identify all pieces.
- **Step-by-Step Process:** Follow the numbered steps precisely. Do not skip steps.
- **Fasteners:** Use the correct fasteners for each connection and tighten them securely, but do not overtighten.
- **Wall Anchoring:** Once assembled and placed on your desk, securely attach the hutch to the wall using the provided anti-tip hardware. This is a critical safety step.



Image 4.1: Detail of the flip-up mechanism for the fluted glass door, which remains open for convenience.

5. OPERATION

The Cabot 60W Hutch is designed for straightforward use:

- **Fluted Glass Door:** To access the center compartment, gently lift the fluted glass door. The mechanism is designed to hold the door in an open position for ease of use. To close, gently pull the door down until it latches.
- **Open Shelves and Cubbies:** Utilize the open shelves and bottom cubbies for organizing books, displaying decorative items, or storing frequently used office supplies.
- **Cable Management:** Route power cords and data cables through the designated opening at the bottom of the hutch to maintain a tidy workspace.

6. MAINTENANCE

To ensure the longevity and appearance of your hutch, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Retighten as

necessary.

7. TROUBLESHOOTING

If you encounter any issues with your hutch, consider the following:

- **Stability Issues:** Ensure the hutch is placed on a level surface. Verify that all assembly fasteners are tightened. Confirm the wall attachment hardware is securely installed.
- **Door Malfunction:** If the fluted glass door does not open or close smoothly, check for any obstructions in the mechanism or ensure all hinge screws are properly tightened.
- **Missing Parts:** If any parts were missing during assembly, refer to the contact information in the Customer Support section to request replacements.

8. SPECIFICATIONS

Detailed specifications for the Bush Furniture Cabot 60W Hutch (Model WC31331):

Feature	Detail
Brand	Bush Furniture
Model Name	Cabot
Model Number	WC31331
Color	Modern Gray
Product Dimensions (D x W x H)	11.46"D x 59.45"W x 36.3"H (29.1cm D x 151.0cm W x 92.2cm H)
Item Weight	63.7 Pounds (28.9 kg)
Material	Engineered Wood
Number of Shelves	2 (open)
Number of Compartments	6 (including cubbies and closed storage)
Assembly Required	Yes
Mounting Type	Wall Mount (for safety)
UPC	042976131975




Image 8.1: Detailed dimensions of the hutch, including closed storage measurements.

9. WARRANTY INFORMATION






The Bush Furniture Cabot 60W Hutch is backed by the Bush Furniture **1 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. Please refer to the warranty documentation included with your product for full terms and conditions, or visit the official Bush Furniture website for more details.

10. CUSTOMER SUPPORT


For assistance with assembly, missing parts, or any other inquiries regarding your Bush Furniture Cabot 60W Hutch, please contact Bush Furniture customer support. Refer to the contact information provided in your product packaging or visit the Bush Furniture official website for support options.

Online Resources: [Visit the Bush Furniture Store on Amazon](#)

Related Documents - WC31331

 <p>Assembly Guide <i>Bush</i> If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-955-4182. For customer support, please visit our website at www.bushfurniture.com. Part Number: 60W L-Desk List Code: F Part Number: 60W L-Desk Part Number: 60W L-Desk</p>	<p>Bush Furniture 60W L-Desk Assembly Guide</p> <p>Comprehensive assembly guide for the Bush Furniture 60W L-Desk, model series KWD160. This document provides step-by-step instructions, a detailed parts list, safety warnings, and contact information for assistance. It is designed for easy understanding and efficient assembly.</p>
 <p>Assembly Guide <i>Bush</i> If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-955-4182. For customer support, please visit our website at www.bushfurniture.com. Part Number: L-Desk List Code: F Part Number: L-Desk Part Number: L-Desk</p>	<p>Bush Furniture L-Desk Assembly Guide - Model A159345K</p> <p>Comprehensive assembly guide for the Bush Furniture L-Desk (Model A159345K). Includes step-by-step instructions, parts list, hardware identification, safety warnings, and customer support contact information.</p>
 <p>HOW TO Tighten KD Cams 1. Place the KD Cam into the hole. 2. Turn the cam clockwise until it is tight. 3. Repeat the KD Cam completely. Click here to view the KD Cam to tighten the video.</p>	<p>Bush Furniture Assembly and Care Instructions</p> <p>Comprehensive guide for assembling Bush Furniture products, including instructions for tightening KD cams, cleaning surfaces, and installing drawer slides, with links to video tutorials.</p>
 <p>MODEL: HM66315A, HM66615A, HM66915A, HM66115A The Bush Furniture difference • QUALITY • INNOVATION • SERVICE • VALUE A1'4877 1 Year</p>	<p>Bush Furniture Desk Assembly Guide and Product Information</p> <p>Comprehensive assembly guide and product details for Bush Furniture desks (Models HM66315A, HM66615A, HM66915A, HM66115A), including safety warnings, parts lists, step-by-step instructions, and warranty information.</p>
 <p>Assembly Guide <i>Bush</i> If you're having any difficulty during assembly of this product, don't hesitate to call us at 1-800-955-4182. For customer support, please visit our website at www.bushfurniture.com. Part Number: Narrow Bookcase List Code: M Part Number: Narrow Bookcase Part Number: Narrow Bookcase</p>	<p>Bush Furniture Narrow Bookcase Assembly Guide</p> <p>Step-by-step assembly instructions and safety information for the Bush Furniture Narrow Bookcase (Model A219294). Includes parts list, hardware identification, and assembly tips.</p>

Top Coffee Table



[YOKO Soft Close Lift Top Coffee Table with Storage - Assembly Instructions & Warranty](#)

Detailed assembly instructions, safety warnings, parts list, and warranty information for the YOKO Soft Close Lift Top Coffee Table with Storage by Bush Furniture.