

Manuals.plus /

> iWALK /

> iWALK AmourDuo PlusWireless Earbuds Compatible with iPhone, Bluetooth Earbuds with Charging Case 10mm Drivers Deep Bass & Clear Mids Highs,20H Playtime Mono & Twin Modes Touch Control Compact & 4g User Manual

iWALK BTA005

iWALK AmourDuo Plus Wireless Earbuds User Manual

Model: BTA005 | Brand: iWALK

INTRODUCTION

Thank you for choosing the iWALK AmourDuo Plus Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

WHAT'S IN THE BOX

- iWALK AmourDuo Plus Wireless Earbuds (Left & Right)
- Charging Case
- USB-C Charging Cable
- Multiple Sizes of Ear Tips (S/M/L)
- User Manual

PRODUCT OVERVIEW



The iWALK AmourDuo Plus Wireless Earbuds and their compact charging case.

10mm Dynamic Drivers

Immersive sound with deep bass



Equipped with 10mm dynamic drivers for immersive sound with deep bass.

Unique and Lightweight

4.0g



Each earbud weighs approximately 4.0g, offering a unique and lightweight design for comfortable wear.

Your browser does not support the video tag.

Official product video showcasing the iWALK Ear Pods Wireless Earbuds, highlighting their 10mm drivers and super light design.

SETUP

Initial Charging


Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case and connect the USB-C cable to a power source. The indicator lights on the case will show charging status.

Bluetooth Pairing

1. Ensure the charging case is charged and the earbuds are inside.
2. Open the charging case lid. The earbuds will automatically enter pairing mode.
3. On your device (e.g., smartphone), go to Bluetooth settings and turn on Bluetooth.

4. Search for available devices and select "Amour Air Duo 2" from the list.
5. Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change.

One Step Pairing



- 1 Lift earbud out of case
- 2 Turn on Bluetooth, search and click "Amour Air Duo2 "

Visual guide for the one-step Bluetooth pairing process with your device.

OPERATING INSTRUCTIONS

Touch Controls

The iWALK AmourDuo Plus Earbuds feature intuitive touch controls on each earbud.

Action	Function
Single Tap (L/R)	Play/Pause, Answer/End Call
Double Tap (L)	Previous Track

Action	Function
Double Tap (R)	Next Track
Triple Tap (L/R)	Activate Voice Assistant
Long Press (2s) (L/R)	Reject Call

Mono & Twin Modes

The earbuds support both mono and twin modes, allowing for flexible usage.

- **Twin Mode:** Use both earbuds simultaneously for a stereo audio experience.
- **Mono Mode:** Use either the left or right earbud independently for calls or music, while the other earbud remains in the case or is turned off. This is useful for awareness of your surroundings.

Mono Mode



Twin Mode



Illustrates the difference between using one earbud (Mono Mode) and both earbuds (Twin Mode).

CHARGING

The iWALK AmourDuo Plus offers convenient charging options to keep your music playing.

20H Playtime



4.5_{hr}
Single charge

1_{hr}
Fully charge earbud

20_{hr}
Charging case

Enjoy up to 4.5 hours of playback on a single charge, with a total of 20 hours using the charging case.

Charging Methods

- **USB-C Charging:** Connect the provided USB-C cable to the charging port on the case and a power adapter.
- **Wireless Charging:** Place the charging case on a compatible wireless charging pad.

Support Wireless Charging



The charging case supports convenient wireless charging.

MAINTENANCE

Cleaning

Regularly clean your earbuds and charging case to ensure optimal performance and hygiene. Use a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.

Water & Sweat Resistance

The iWALK AmourDuo Plus Earbuds are IPX5 water and sweat resistant, making them suitable for workouts and light rain. However, they are not designed for swimming or submersion in water. Ensure the earbuds are dry before placing them back in the charging case.

IPX5 Water & Sweat Resistant

Remain intact from splash water and sweat



The earbuds are IPX5 water and sweat resistant, remaining intact from splash water and sweat.

Comfortable Fit

To ensure the best sound quality and comfort, choose the ear tips that provide a snug fit in your ear canals. Different sizes (S, M, L) are included to accommodate various ear shapes.

Comfortable and Snugly Fit



Select the appropriate ear tip size for a comfortable and secure fit.

TROUBLESHOOTING

If you encounter any issues with your iWALK AmourDuo Plus Earbuds, please refer to the following common solutions:

Problem	Solution
Earbuds not pairing	Ensure earbuds are charged. Turn off and on Bluetooth on your device. Forget "Amour Air Duo 2" from your device's Bluetooth list and re-pair.
Only one earbud working	Place both earbuds back in the case, close the lid, then open it again. Ensure both earbuds are charged.
Low volume or poor sound quality	Adjust volume on your device. Ensure ear tips are properly sealed in your ear. Clean any debris from earbud speakers.

Problem	Solution
Charging case not charging	Check USB-C cable connection and power source. Ensure wireless charging pad is compatible and properly aligned.

SPECIFICATIONS

Feature	Detail
Model Name	AmourDuo Plus (BTA005)
Connectivity Technology	Wireless (Bluetooth 5.0)
Driver Size	10mm Dynamic Drivers
Playtime (Single Charge)	Up to 4.5 hours
Total Playtime (with Case)	Up to 20 hours
Charging Interface	USB-C, Wireless Charging
Water Resistance	IPX5 (Water & Sweat Resistant)
Control Type	Touch Control
Earbud Weight	Approx. 4g per earbud
Item Weight	6.5 ounces (total product)
Batteries	2 Lithium Ion batteries (included)

WARRANTY & SUPPORT

iWALK products are designed and manufactured to the highest quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of original purchase. Please retain your proof of purchase for warranty claims.

For technical support, warranty service, or more information, please visit the official iWALK website or contact their customer service directly. Contact details can typically be found on the product packaging or the official iWALK support page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08MSXY84G>

More documents and user manuals: <https://manuals.plus/>