

[Manuals.plus](#) /

› [UOGIC](#) /

› Uogic Pen F95 for Microsoft Surface: Instruction Manual

UOGIC F95

Uogic Pen F95 for Microsoft Surface: Instruction Manual

Model: F95

1. INTRODUCTION

This manual provides detailed instructions for the Uogic Pen F95, a high-performance stylus designed for Microsoft Surface devices. Featuring 4096 levels of pressure sensitivity and palm rejection technology, this pen enhances your digital writing and drawing experience. Please read this manual thoroughly before use to ensure proper operation and longevity of your device.



Figure 1.1: Uogic Pen F95 with included accessories.

2. PACKAGE CONTENTS

- Uogic Pen F95 Stylus
- Replacement Pen Tips (various hardness)

- Tip Replacement Tool
- AAAA Battery

Compatible Models



Model Name	Model Number
Surface Pro	Pro 9/8/7+/7/6/5/4/3/X
Surface Duo	Duo/ Duo 2
Surface Go	Go 3/2/1
Surface Book	Book 3/2/1
Surface Studio	Studio 2+/2/1
Surface Laptop	Laptop 5/4/3/2/1/Studio

Figure 2.1: Contents of the Uogic Pen F95 package.

3. COMPATIBILITY

The Uogic Pen F95 is compatible with a wide range of Microsoft Surface devices and other touchscreen devices running

Windows 10 or 11 that support MPP1.5 or MPP2.0 protocols. No Bluetooth connection or pairing is required for operation.

Compatible Microsoft Surface Models

Model Name	Model Number
Surface Pro	3rd/4th/5th/6th/7th/7+/8th/9th/10th/X gen
Surface Duo	1st/2nd gen
Surface Go	1st/2nd/3rd gen
Surface Book	1st/2nd/3rd gen
Surface Studio	1st/2nd/2+ gen
Surface Laptop	1st/2nd/3rd/4th/5th gen, Surface Laptop Studio

4096 Pressure Sensitivity




Figure 3.1: Visual representation of compatible Surface models.

4.1. Battery Installation

1. Unscrew the top cap of the stylus to reveal the battery compartment.
2. Insert the provided AAAA battery with the positive (+) end facing towards the pen tip.
3. Screw the top cap back on securely.

4.2. Pen Tip Installation/Replacement

1. To remove an existing tip, use the tip replacement tool to gently pull the tip straight out.
2. Select your desired replacement tip (HB, 2H, or H for different hardness levels).
3. Gently push the new tip straight into the pen until it is securely seated.




Figure 4.1: Using the pen tip replacement tool.



Figure 4.2: Available pen tip hardness options.

5. OPERATING INSTRUCTIONS

5.1. Power On/Off

The Ulogic Pen F95 automatically powers on when in use and enters an auto-sleep mode after 5 minutes of inactivity to conserve battery life. No manual power button is required.

Tilt Function



Figure 5.1: Automatic power management features.

5.2. Pressure Sensitivity (4096 Levels)

The stylus supports 4096 levels of pressure sensitivity, allowing for precise control over line thickness and opacity. Apply varying pressure to achieve different artistic effects, from fine lines to broad strokes.

Palm Rejection

Uogic



Rest your hand on screen freely

Others



Wear palm rejection gloves

Figure 5.2: Illustrating 4096 pressure sensitivity.

5.3. Tilt Function

The tilt function allows the pen to mimic a real pencil, enabling shading strokes when the pen is angled. This feature provides a more natural drawing and writing experience.

Your browser does not support the video tag.

Video 5.1: Demonstration of Uogic stylus pressure sensitivity and tilt function.

5.4. Palm Rejection

With palm rejection technology, you can comfortably rest your hand on the screen while writing or drawing without creating unintended marks. This ensures a smooth and uninterrupted workflow.

Convenient Button Function



Right-click Button



Eraser Button



Figure 5.3: Palm rejection feature in action.

5.5. Button Functions

The stylus features two side buttons for convenient shortcuts:

- **Right-click Button:** Press and hold the upper button to activate the right-click function.
- **Eraser Button:** Press and hold the lower button to activate the eraser function.



Figure 5.4: Stylus button functions.

6. MAINTENANCE

6.1. Battery Replacement

When the pen's performance diminishes, it may be time to replace the AAAA battery. Follow the battery installation steps in Section 4.1.

6.2. Pen Tip Replacement

Pen tips may wear down with extended use. Replace them as needed following the instructions in Section 4.2 to maintain optimal performance.

6.3. Cleaning

Wipe the stylus body with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the pen's finish.

7. TROUBLESHOOTING

7.1. Pen Not Responding

- Ensure the AAAA battery is correctly installed and has sufficient charge. Replace if necessary.
- Verify that your device is compatible with MPP1.5 or MPP2.0 protocols.
- Restart your Surface device.

7.2. Inaccurate or Lagging Performance

- Check if the pen tip is securely installed. Replace if it appears worn or damaged.
- Ensure your device's screen is clean and free of debris.
- Confirm that your device's operating system and drivers are up to date.

8. SPECIFICATIONS

- **Model Number:** F95
- **Pressure Sensitivity:** 4096 levels
- **Battery Type:** 1 x AAAA (included)
- **Battery Life:** Up to 1500 hours
- **Material:** Aluminum
- **Item Weight:** 20 Grams (0.705 ounces)
- **Dimensions:** 7.64 x 7.4 x 0.67 inches (Package)
- **Color:** Black
- **Connectivity:** No Bluetooth Connection (MPP protocol)

9. WARRANTY AND SUPPORT

The Uogic Pen F95 comes with a 12-month warranty from the date of purchase. For any questions, concerns, or technical assistance, please contact our customer support team. We offer 24/7 online customer support to ensure your satisfaction.

For support, please visit the official UOGIC website or refer to the contact information provided with your product packaging.

© 2025 UOGIC. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question