

[Manuals.plus](#) /

> [JVC](#) /

> JVC HA-FX100T Wireless Earphones Instruction Manual

JVC HA-FX100T

JVC HA-FX100T Wireless Earphones Instruction Manual

INTRODUCTION

The JVC HA-FX100T Wireless Earphones are designed to deliver high-quality audio with a focus on comfort and durability. This manual provides essential information for setting up, operating, and maintaining your earphones to ensure optimal performance and longevity.



Image: The JVC HA-FX100T wireless earphones, black in color, are shown alongside their matching charging case. The earphones feature the 'Victor' logo and are designed for in-ear use.

PACKAGE CONTENTS

Before you begin, please ensure all items are present in the package:

- JVC HA-FX100T Wireless Earphones (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- Spiral Dot Earpieces (5 sizes: S, MS, M, ML, L)



Image: The JVC HA-FX100T wireless earphones are shown resting inside their open charging case. The case is black, and the earphones are visible with their 'Victor' branding.

SETUP

1. Charging

The earphones and charging case are designed for extended use. Ensure both are adequately charged before first use.

- To charge the earphones, place them securely into the charging case.
- To charge the charging case, connect the supplied USB Type-C cable to the charging port on the case and a compatible USB power source.
- A 10-minute quick charge can provide approximately 1 hour of playback.
- A full charge allows for approximately 8 hours of continuous earphone playback. The charging case provides an additional 2.5 full charges, totaling up to 28 hours of use.



Image: The JVC HA-FX100T wireless earphones are shown inside their closed charging case. The compact black case is ready for portability and charging.

2. Earpiece Selection and Fit

Proper earpiece selection is crucial for achieving optimal sound quality, comfort, and passive noise cancellation.

- The included Spiral Dot Earpieces feature a unique dimple design on the inner wall, which helps to diffuse sound reflections and enhance audio clarity.
- Experiment with the five provided sizes (S, MS, M, ML, L) to find the best fit for your ears. A good seal is essential for rich bass response and effective passive noise isolation.
- Insert the earphones gently into your ear canal and twist slightly until they feel secure and comfortable.



Image: A woman is shown wearing a JVC HA-FX100T earbud in her right ear, demonstrating a comfortable and secure fit.



Image: A man is shown wearing a JVC HA-FX100T earbud in his right ear, illustrating the discreet and ergonomic design.

3. Bluetooth Pairing

Follow these steps to connect your earphones to a Bluetooth-enabled device:

1. Open the charging case. The earphones will automatically power on and enter pairing mode.
2. On your device (e.g., smartphone, tablet), enable Bluetooth and search for available devices.
3. Select "**JVC HA-FX100T**" from the list of detected devices.
4. Once successfully paired, the earphones will automatically connect to your device when removed from the case in the future.

OPERATING INSTRUCTIONS

The JVC HA-FX100T earphones feature intuitive touch controls for various functions.

Power On/Off

- **Power On:** The earphones automatically power on when removed from the charging case.
- **Power Off:** The earphones automatically power off when placed back into the charging case and the lid is closed.

Music Playback

- **Play/Pause:** Tap once on either earbud.
- **Next Track:** Tap twice on the **right** earbud.
- **Previous Track:** Tap twice on the **left** earbud.

Call Functions

- **Answer/End Call:** Tap once on either earbud.
- **Reject Call:** Tap and hold on either earbud.
- The "**Clear Voice**" function automatically optimizes voice frequencies during calls for enhanced clarity. Qualcomm® cVc™ technology further reduces background noise for clear hands-free conversations.

Touch and Talk Function

- To temporarily lower music volume and allow external sounds to be heard, facilitating conversations without removing the earphones, tap and hold the **left** earbud.

Single Earphone Use

- Thanks to Qualcomm TrueWireless™ Stereo Plus technology, either the left or right earphone can be used independently. Simply remove one earbud from the case and leave the other in the case.

MAINTENANCE

Cleaning

- Regularly clean the earpieces and earphone surfaces with a soft, dry cloth.
- Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the earphones.
- Ensure the charging contacts on both the earphones and the case are clean and free of debris for reliable charging.

Water Resistance (IPX4)

- The HA-FX100T earphones are rated IPX4, meaning they are resistant to splashes of water from any direction. This protection applies to the earphone body only.
- Do not submerge the earphones or the charging case in water.
- Avoid exposing the earphones to high-pressure water jets or steam.

- If the earphones get wet, wipe them dry thoroughly before placing them back in the charging case.

Storage

- When not in use, always store the earphones in their charging case to protect them from damage and keep them charged.
- Store the earphones in a cool, dry place, away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter any issues with your JVC HA-FX100T earphones, refer to the common problems and solutions below:

- **No Sound:**
 - Ensure the earphones are charged.
 - Verify the Bluetooth connection to your device.
 - Adjust the volume on both the earphones and your connected device.
- **Cannot Pair:**
 - Ensure the earphones are in pairing mode (open the charging case).
 - Turn off and then turn on Bluetooth on your device.
 - Try resetting the earphones. Refer to the official JVC website for specific reset instructions if needed.
- **Poor Sound Quality:**
 - Ensure the earpieces are properly fitted and creating a good seal in your ear.
 - Move closer to your connected device to avoid interference.
 - Check for any physical obstructions between the earphones and your device.

SPECIFICATIONS

Feature	Detail
Model Number	HA-FX100T
Connectivity	Bluetooth 5.1
Supported Codecs	AAC, Qualcomm® aptX™ audio
Wireless Frequency Range	2.4 GHz (2.4000 GHz - 2.4835 GHz)
Audio Frequency Response	20Hz - 20kHz
Earphone Weight (Each)	Approx. 4.5 g (0.1 oz)
Battery Life (Earphones)	Approx. 8 hours
Total Battery Life (with Case)	Up to 28 hours
Charging Port	USB Type-C
Water Resistance	IPX4 (Earphone body only)
Microphone	Built-in (MEMS microphone with Qualcomm® cVc™)
Control Method	Touch

Noise Control

Passive Noise Cancellation

WARRANTY AND SUPPORT

For detailed warranty information, technical support, or further assistance with your JVC HA-FX100T Wireless Earphones, please refer to the official JVC website or contact their customer service department. It is recommended to keep your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question