

FLEXISPOT EN2

FLEXISPOT EN2 Electric Height Adjustable Standing Desk Instruction Manual

Model: EN2 | Brand: FLEXISPOT

INTRODUCTION

This manual provides comprehensive instructions for the assembly, operation, and maintenance of your FLEXISPOT EN2 Electric Height Adjustable Standing Desk. Please read this manual thoroughly before use to ensure proper function and longevity of your product.

The FLEXISPOT EN2 features a whole-piece bamboo desktop, a removable power outlet with USB ports, a 6-button digital controller with 4 memory presets, and a durable steel frame designed for a stable and productive workspace.

SAFETY INFORMATION

- Maximum weight capacity: 176 pounds (80 kg). Do not exceed this limit.
- Assembly requires an electric drill (not included). Exercise caution during assembly.
- Ensure all connections are secure before operating the desk.
- Keep children and pets away from the desk during operation.
- Avoid contact with water or abrasive materials during cleaning.

SETUP AND ASSEMBLY

Your FLEXISPOT EN2 desk will arrive in two separate packages, which may be shipped separately. Assembly is required and is recommended for two people to facilitate handling of components. An electric drill is necessary for proper setup, but is not included.

Components Overview



Figure 1: Overview of FLEXISPOT EN2 desk components. This image displays the various parts included for assembly, such as the desktop, leg frames, and hardware.

Cable Management

The desk includes a cable management device to help organize cords, contributing to a tidy workspace. Fasteners and Velcro straps are provided to secure cables neatly under the desktop.



Figure 2: Illustration of effective cable management. The "Before" section shows disorganized cables, while the "After" section demonstrates how the integrated cable management system tidies them.

Assembly Video

Your browser does not support the video tag.

Video 1: Flexispot Standing Desk - Embrace a Healthier Lifestyle. This official video demonstrates the desk's features and includes brief segments on assembly and operation.

OPERATING INSTRUCTIONS

Multifunctional Controller

The desk is equipped with a 6-button digital controller for easy height adjustment and memory preset functions. The controller features an LED display showing the current height.

MULTIFUNCTIONAL CONTROLLER




Figure 3: Detailed view of the multifunctional controller. It shows the LED display, up/down arrows, and four programmable height setting buttons.

Height Adjustment

- Use the **Up** (^) and **Down** (v) arrows to manually adjust the desk height.
- The motorized system adjusts smoothly from 28.1 inches (71.4 cm) to 45.7 inches (116.1 cm).
- The motor operates quietly at less than 50 dB.

Memory Presets

The controller allows you to save up to 4 preferred height settings for quick transitions between sitting and standing positions.

1. Adjust the desk to your desired height using the up/down arrows.
2. Press the "**M**" button. The LED display will flash.
3. Press one of the numbered preset buttons (**1**, **2**, **3**, or **4**) while the display is flashing to save the current height to that preset.
4. To recall a saved height, simply press the corresponding numbered preset button.

Removable Desktop Power Outlet

The desktop includes a removable power outlet with 3 AC outlets and 2 USB charging ports (5V/2A). This can be clipped to the back or side of your desk for convenient access.



Figure 4: The removable desktop power outlet, featuring 3 AC outlets (125V/12A) and 2 USB ports (5V/2A) for charging devices.

Anti-Collision System

The desk is equipped with a smart anti-collision system. If the desk encounters an obstruction during height adjustment, it will stop and reverse slightly to prevent damage.

MAINTENANCE

- Dust regularly with a dry cloth to keep the desktop clean.
- Avoid contact with water or abrasive cleaning materials to prevent damage to the bamboo surface.
- Periodically check all screws and connections to ensure they remain tight and secure.

TROUBLESHOOTING

If you encounter any issues with your FLEXISPOT EN2 desk, please refer to the following general advice:

- **Desk not moving:** Check all power connections and ensure the power outlet is functioning. Verify that the control panel is properly connected.
- **Uneven movement:** Ensure the desk is placed on a level surface. Check that all leg components are securely fastened.
- **Error codes on display:** Consult the full troubleshooting guide available on the FLEXISPOT website or contact customer support for specific error code interpretations.

For further assistance, please contact FLEXISPOT customer support.

SPECIFICATIONS




Figure 5: Dimensional specifications of the FLEXISPOT EN2 desk. This diagram illustrates the table size, adjustable height range, and dimensions of the power strip and cable manager.

FLEXISPOT EN2 Standing Desk Specifications

| Feature | Detail |
|---------|--------|
|---------|--------|

| Feature | Detail |
|--------------------------------|---|
| Brand | FLEXISPOT |
| Model Number | EN2 |
| Desktop Material | Whole-Piece Bamboo |
| Frame Material | Alloy Steel |
| Product Dimensions (D x W x H) | 24"D x 48"W x 28"H (61cm D x 122cm W x 71cm H) |
| Adjustable Height Range | 28.1" - 45.7" (71.4cm - 116.1cm) |
| Maximum Weight Capacity | 176 lbs (80 kg) |
| Motor Noise Level | Less than 50 dB |
| Power Outlet | 3 AC Outlets (125V/12A), 2 USB Charging Ports (5V/2A) |
| Assembly Required | Yes (Recommended 2 people, electric drill not included) |




WARRANTY AND SUPPORT




FLEXISPOT provides the following warranty for your EN2 standing desk:

- **5-Year Warranty:** Covers frames, motors, and other mechanical devices.
- **2-Year Warranty:** Covers controllers, switches, and electronics.

For customer support, warranty claims, or additional product information, please visit the official FLEXISPOT website or contact their customer service department. You can also visit the [FLEXISPOT Store on Amazon](#).

Related Documents - EN2

| | |
|---|---|
|  | <p>FlexiSpot E2Q Electric Standing Desk: Installation Guide and Specifications</p> <p>Comprehensive installation guide and specifications for the FlexiSpot E2Q electric standing desk. Learn how to assemble, operate, and troubleshoot your adjustable height desk.</p> |
|  | <p>FlexiSpot EH1-EU Electric Standing Desk Frame User Manual</p> <p>Comprehensive user manual for the FlexiSpot EH1-EU electric standing desk frame, detailing specifications, assembly instructions, wiring, operation, and troubleshooting for optimal use.</p> |
|  | <p>FlexiSpot E7QB 4-Leg Standing Desk Frame User Manual and Warranty</p> <p>Comprehensive user manual for the FlexiSpot E7QB 4-Leg Standing Desk Frame, covering installation, usage, troubleshooting, and warranty information. Learn how to assemble, operate, and maintain your adjustable desk.</p> |

| | |
|---|--|
|  <p>FLEXISPOT</p> <p>EG8B/EG8W</p> | <p>FlexiSpot EG8B/EG8W Installation Guide and Limited Warranty</p> <p>This document provides a comprehensive installation guide and limited warranty information for the FlexiSpot EG8B/EG8W adjustable standing desk. It details specifications, assembly steps, keypad operation, troubleshooting, safety precautions, and warranty terms.</p> |
|  <p>FLEXISPOT</p> <p>EC1</p> | <p>FlexiSpot EC1 Electric Height Adjustable Standing Desk Assembly Guide</p> <p>This assembly guide provides step-by-step instructions for setting up the FlexiSpot EC1 electric height-adjustable standing desk. It includes specifications, parts list, assembly procedures, keypad operation, troubleshooting tips, and warranty information.</p> |
|  <p>FLEXISPOT</p> <p>E2LB-V2/E2LW-V2</p> | <p>FlexiSpot E2LB-V2/E2LW-V2 Electric Height-Adjustable Desk User Manual</p> <p>User manual for the FlexiSpot E2LB-V2 and E2LW-V2 electric height-adjustable desks, covering assembly, operation, technical specifications, and troubleshooting.</p> |