

[manuals.plus](#) /

› [RL LIVE YOUR LIGHT](#) /

› [User Manual for Reality Leuchten Blake LED Floor Lamp](#)

RL LIVE YOUR LIGHT R42111107

User Manual for Reality Leuchten Blake LED Floor Lamp

Model: **R42111107** | Brand: **RL LIVE YOUR LIGHT**

1. INTRODUCTION

Thank you for choosing the Reality Leuchten Blake LED Floor Lamp. This minimalist and elegant floor lamp (Model R42111107) is designed to provide optimal lighting conditions with its integrated 4.5 Watt LED. Featuring a matte nickel finish, it seamlessly blends into various interior designs. The lamp is battery-operated, offering portability, and can be conveniently recharged via a USB-C port. Its intuitive 4-step touch control allows you to adjust light intensity and ambiance.



Image 1.1: The Blake LED Floor Lamp in a contemporary living space. This image showcases the lamp's sleek design and how it complements modern decor.

2. SAFETY INSTRUCTIONS

Please read these safety instructions carefully before using the lamp. Keep this manual for future reference.

- Ensure the lamp is placed on a stable, level surface to prevent tipping.
- Do not expose the lamp to extreme temperatures, direct sunlight, or high humidity.
- Do not attempt to disassemble or modify the lamp. This will void the warranty and may cause damage or injury.
- Use only the provided or recommended USB charger for recharging. Using incompatible chargers may damage the battery or lamp.
- Keep the lamp away from water and other liquids.
- The integrated LED light source is not replaceable. If the LED fails, the entire luminaire must be replaced.
- Clean the lamp only with a soft, dry cloth. Do not use abrasive cleaners or solvents.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all items are present and in good condition. If any items are missing or damaged, please contact customer support.

- Blake LED Floor Lamp (Model R42111107)
- USB Charging Cable (Type-C)
- User Manual (this document)

4. SETUP AND ASSEMBLY

The Blake LED Floor Lamp comes largely pre-assembled. Follow these simple steps to set up your lamp:

1. Carefully remove all packaging materials from the lamp.
2. Place the lamp base on a flat, stable surface.
3. Ensure the lamp head is securely attached to the pole. The lamp head can be adjusted to direct light as needed.
4. Before first use, it is recommended to fully charge the lamp's integrated battery. Refer to Section 6 for charging instructions.






Image 4.1: The Blake LED Floor Lamp, showing its full height and design. The lamp is ready for placement after unboxing.

5. OPERATING INSTRUCTIONS

The Blake LED Floor Lamp features an intuitive touch control located on the top of the lamp head. This allows for easy

power control and brightness adjustment.



Image 5.1: Detail of the touch-sensitive area on the top of the lamp head, used for controlling power and brightness.

1. **Power On/Off:** Lightly touch the control area once to turn the lamp ON. Touch it again to turn the lamp OFF.
2. **Adjust Brightness (Dimming):** The lamp offers 3 levels of brightness. After turning the lamp ON, repeatedly touch the control area to cycle through the brightness levels (Low → Medium → High → Off).
3. **Adjusting Lamp Head:** The lamp head is adjustable, allowing you to direct the light beam as desired. Gently pivot the lamp head to the desired angle.



Image 5.2: The adjustable joint connecting the lamp head to the main pole, enabling flexible light direction.

6. CHARGING THE BATTERY

The Blake LED Floor Lamp is equipped with an integrated rechargeable battery, providing approximately three hours of light at maximum brightness on a full charge. The USB-C charging port is located on the lamp's base.



Image 6.1: The USB-C charging port located on the side of the lamp's base.

1. Locate the USB-C port on the side of the lamp's base.
2. Connect the provided USB charging cable to the lamp's USB-C port.
3. Connect the other end of the USB cable to a compatible USB power adapter (e.g., a phone charger, computer USB port, or power bank).
4. A small indicator light near the USB port will illuminate during charging. It will change color or turn off when charging is complete.
5. For optimal battery life, avoid completely draining the battery before recharging.

Note: Some users have reported that charging works best with the original or a specific type of charger. If you experience issues, try different compatible USB power adapters.

7. MAINTENANCE

To ensure the longevity and optimal performance of your Blake LED Floor Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Dust the lamp regularly with a soft, dry, lint-free cloth. For stubborn marks, slightly dampen the cloth with water and wipe gently, then dry immediately. Do not use abrasive cleaners, solvents, or chemical sprays.
- **Storage:** If storing the lamp for an extended period, ensure the battery is partially charged (around 50%) and store it in a cool, dry place. Recharge the battery every few months to prevent deep discharge.
- **LED Care:** The integrated LED is designed for long life and does not require replacement. Avoid touching the LED directly.

8. TROUBLESHOOTING

If you encounter any issues with your Blake LED Floor Lamp, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Lamp does not turn on.	Battery is depleted.	Charge the lamp fully using the USB-C cable.
Lamp light is dim or flickers.	Low battery.	Recharge the lamp.
Lamp does not charge.	Faulty USB cable or power adapter; loose connection.	Ensure the USB cable is securely connected. Try a different USB-C cable or power adapter. Ensure the power adapter meets the lamp's charging requirements.
Battery life is shorter than expected.	Battery degradation over time; frequent use at maximum brightness.	Battery capacity naturally decreases over time. Consider using lower brightness settings to extend runtime. Ensure full charges.
Lamp glows faintly when turned off.	Residual power in circuitry; minor electrical leakage.	This is a known characteristic for some LED devices. If it's bothersome, ensure the lamp is fully discharged or contact support if it affects functionality.

9. SPECIFICATIONS

Model Number:	R42111107
Brand:	RL LIVE YOUR LIGHT
Light Source:	Integrated LED, 4.5 Watt
Power Source:	Rechargeable Battery, USB-C Charging
Battery Life (Max Brightness):	Approx. 3 hours
Control Type:	4-step Touch Dimmer
Finish:	Matte Nickel
Product Dimensions (L x W x H):	30 x 20 x 125 cm (approx. 11.8 x 7.9 x 49.2 inches)
Weight:	2.94 kg (approx. 6.48 lbs)
Included Components:	Lamp, USB Charging Cable



Image 9.1: Technical drawing illustrating the dimensions of the Blake LED Floor Lamp (R42111107).



Image 9.2: Energy efficiency label for the Blake LED Floor Lamp, indicating its energy class.

10. WARRANTY AND SUPPORT

This product comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation provided with your purchase or contact the retailer.

For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact RL LIVE YOUR LIGHT customer service through their official website or the retailer where you purchased the product.

Please retain your proof of purchase for warranty claims.

© 2024 RL LIVE YOUR LIGHT. All rights reserved.
This manual is subject to change without notice.