

[manuals.plus](#) /› [Audibax](#) /› [Audibax TOP-40 Universal Tripod Stand for Laptop, MIDI Controller, and Projector - Instruction Manual](#)

Audibax 10176035

Audibax TOP-40 Universal Tripod Stand

Model: 10176035

[Product Overview](#) [Package Contents](#) [Assembly Instructions](#) [Operation & Adjustment](#) [Care & Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The Audibax TOP-40 is a versatile and robust tripod stand designed to securely hold laptops, MIDI controllers, projectors, and other electronic devices. Its adjustable height and foldable design make it ideal for various settings, including DJ booths, recording studios, presentations, and home use. Constructed from durable steel with anti-slip features, it ensures stability and ease of transport.

2. PACKAGE CONTENTS

Please ensure all components are present before assembly:

- Tripod Base
- Adjustable Central Pole
- Device Tray (47.5 x 25.5 cm)
- Mounting Hardware (screws, clamps)
- Instruction Manual

3. ASSEMBLY INSTRUCTIONS

Follow these steps for quick and easy assembly:

1. **Unfold the Tripod Base:** Carefully extend the legs of the tripod base until they are fully spread and stable. Ensure the locking mechanism is engaged.
2. **Attach the Central Pole:** Insert the adjustable central pole into the top of the tripod base. Secure it by tightening the knob on the base.
3. **Mount the Device Tray:** Place the device tray onto the top of the central pole. Use the provided screws and tighten them securely to ensure the tray is firmly attached.

4. **Adjust Height:** Loosen the height adjustment clamp on the central pole, extend the pole to your desired height (between 92 cm and 130 cm), and then firmly tighten the clamp to lock it in place.





Figure 1: Fully assembled Audibax TOP-40 stand.



Figure 2: Detail of the stable tripod base with anti-slip feet.

4. OPERATION AND ADJUSTMENT

The Audibax TOP-40 is designed for flexible use with various devices.

- **Device Placement:** Place your laptop, MIDI controller, or projector securely on the 47.5 x 25.5 cm tray. The tray surface is designed to provide a stable grip.
- **Height Adjustment:** To adjust the height, loosen the central pole's clamp, raise or lower the pole to your desired position (between 92 cm and 130 cm), and firmly re-tighten the clamp.

- **Angle Adjustment:** The device tray can be tilted to achieve an optimal viewing or operating angle. Loosen the angle adjustment knob beneath the tray, set the desired tilt, and tighten the knob to secure it.
- **Stability:** The tripod features anti-slip rubber feet for maximum grip on various surfaces, preventing accidental slips or falls.





Figure 3: Laptop positioned on the stand's tray for use.



Figure 4: Detailed view of a laptop securely resting on the stand's tray.

5. CARE AND MAINTENANCE

- **Cleaning:** Wipe the stand with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Inspection:** Regularly check all knobs, clamps, and screws to ensure they are tight and secure.
- **Storage:** When not in use, fold the stand for compact storage. Store in a dry place away from extreme temperatures.

6. TROUBLESHOOTING

Issue: Stand feels unstable.

Possible Causes & Solutions:

- **Incorrect Leg Angle:** Ensure the tripod legs are fully extended and spread at the correct angle, as shown in the product images.
- **Loose Clamps/Knobs:** Verify that all height adjustment clamps and tray attachment knobs are firmly tightened. Over-tightening plastic clamps should be avoided to prevent damage, but they must be snug.
- **Uneven Surface:** Place the stand on a flat, stable surface. The anti-slip rubber feet are designed to provide grip, but an uneven surface can still affect stability.
- **Overload:** Ensure the weight of your device does not exceed the stand's maximum bearing capacity.

7. SPECIFICATIONS

Model Number	10176035
Brand	Audibax
Material	Steel (stand), Anti-slip rubber (feet)
Color	White (as per product title, though images show black)
Adjustable Height Range	92 cm to 130 cm
Device Tray Dimensions	47.5 cm x 25.5 cm
Product Weight	1 kg
Foldable	Yes

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact Audibax customer service directly. Keep your proof of purchase for any warranty claims.

