

[Manuals.plus](#) /

› [Olox](#) /

› Olox MF950V 4G LTE Mobile WiFi Hotspot User Manual

Olox MF950V

Olox MF950V 4G LTE Mobile WiFi Hotspot User Manual

Model: MF950V

1. INTRODUCTION

The Olox MF950V is a portable 4G LTE mobile Wi-Fi hotspot designed to provide high-speed internet access on the go. It allows you to connect multiple devices simultaneously to a secure Wi-Fi network using a standard SIM card. This manual provides essential information for setting up, operating, and maintaining your device.

Package Contents

- Olox MF950V Mobile WiFi Hotspot
- Rechargeable Li-ion Battery (2100 mAh)
- USB Charging Cable
- User Manual (this document)



Image 1.1: Olax MF950V device, USB charging cable, and rechargeable battery.

2. SETUP

2.1 Installing the SIM Card and Battery

1. **Remove the back cover:** Gently pry open the back cover of the Olax MF950V device.
2. **Insert the Nano SIM card:** Locate the SIM card slot. Insert your Nano SIM card into the slot with the gold contacts facing down and the notched corner aligned correctly. Ensure it clicks into place.
3. **Insert the battery:** Align the contacts of the 2100 mAh Li-ion battery with the terminals in the battery compartment and gently press it into place.
4. **Replace the back cover:** Carefully snap the back cover back onto the device until it is securely closed.

2.2 Charging the Device

Before initial use, fully charge the device. Connect the provided USB charging cable to the micro USB port on the Olax MF950V and the other end to a compatible USB power adapter (not included) or a computer's USB port. The charging indicator will show

the charging status.

2.3 Powering On/Off

- **To Power On:** Press and hold the Power button for a few seconds until the screen illuminates.
- **To Power Off:** Press and hold the Power button for a few seconds until the device powers down.

3. OPERATING INSTRUCTIONS

3.1 Connecting Devices via Wi-Fi

The Olax MF950V supports up to 10 Wi-Fi enabled devices simultaneously.

1. **Power on** your Olax MF950V.
2. **Access Wi-Fi information:** The Wi-Fi network name (SSID) and password (Wi-Fi Key) are typically displayed on the device screen or on a label inside the battery compartment.
3. **Connect from your device:** On your smartphone, laptop, tablet, or other Wi-Fi enabled device, go to the Wi-Fi settings.
4. **Select the network:** Find and select the SSID of your Olax MF950V from the list of available networks.
5. **Enter the password:** Input the Wi-Fi Key when prompted.
6. Your device should now be connected to the internet.

3.2 Accessing the Web Management Interface

You can manage your hotspot settings through a web interface.

1. Connect your device (e.g., laptop, smartphone) to the Olax MF950V via Wi-Fi or USB.
2. Open a web browser and enter the default IP address (usually [192.168.0.1](#) or [192.168.1.1](#)). Refer to your device's specific information for the exact address.
3. Enter the username and password (default is often 'admin' for both, or found on the device label).
4. From the interface, you can change Wi-Fi settings, view connected devices, check data usage, and configure other network parameters.

3.3 Connecting via USB

The Olax MF950V can also provide internet access to a single computer via a USB connection.

- Connect the Olax MF950V to your computer using the provided USB cable.
- The device may prompt you to install drivers or software. Follow the on-screen instructions.
- Once installed, the computer should recognize the device as a network adapter and connect to the internet.

4. MAINTENANCE

4.1 Battery Care

- Use only the authorized charger and cable provided or recommended by Olax.
- Avoid exposing the battery to extreme temperatures (below 0°C or above 45°C).
- Do not disassemble, puncture, or short-circuit the battery.
- If the device will not be used for an extended period, charge the battery to about 50% and store it in a cool, dry place.

4.2 Cleaning

- Wipe the device with a soft, dry cloth.

- Do not use liquid cleaners or aerosols.
- Keep the device free from dust and debris.

5. TROUBLESHOOTING

- **No Network Signal:** Ensure your SIM card is correctly inserted and active. Check if you are in an area with 4G LTE coverage. Restart the device.
- **Cannot Connect to Wi-Fi:** Verify the Wi-Fi password. Ensure the device is powered on and broadcasting its Wi-Fi signal. Try restarting both the hotspot and the connecting device.
- **Slow Internet Speed:** Check your data plan and signal strength. Too many devices connected simultaneously can reduce speed. Try moving to an area with better signal.
- **Device Not Powering On:** Ensure the battery is fully charged. If the issue persists, try connecting the device to a power source without the battery to see if it powers on.
- **Web Interface Inaccessible:** Ensure your device is connected to the hotspot's Wi-Fi or via USB. Verify the correct IP address and login credentials.

6. SPECIFICATIONS

Model	Olax MF950V
Network Type	4G LTE (GSM Unlocked)
LTE Bands Supported	B1, B3, B4, B5, B8
Wi-Fi Standard	802.11 b/g/n, 2.4 GHz
Max Download Speed	150 Mbps
Max Upload Speed	50 Mbps
Battery Capacity	2100 mAh Li-ion (8-10 hours usage)
Dimensions	85 x 55 x 16 mm
Interfaces	Nano SIM slot, Micro USB port, Micro-SD card slot
Supported Devices	Up to 10 Wi-Fi devices + 1 USB device
Security Protocol	WPS

Battery Details

The device uses a rechargeable Li-ion battery with the following specifications:

- **Voltage:** 3.8V
- **Capacity:** 2100mAh (7.98Wh)
- **Limited Charge Voltage:** 4.35V
- **Standard:** GB/T18287-2013
- **Manufacturer:** Shenzhen Powercome Electronics Co.,LTD

7. SAFETY INFORMATION

Please read and follow these safety guidelines to prevent damage to your device or injury:

- **Charger:** Use only the authorized charger and USB cable.
- **Battery Disposal:** Batteries may explode if disposed of in fire. Dispose of batteries according to local regulations.
- **Children:** Keep the battery out of the reach of children.
- **Temperature:** Operate and store the device within the temperature range of 0°C to 45°C (32°F to 113°F).
- **Disassembly:** Do not disassemble the device or battery.
- **Short Circuit:** Do not short circuit the battery terminals.

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided with your purchase or visit the official Olax website. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08MV7CYR4>

More documents and user manuals: <https://manuals.plus/>