

[manuals.plus](#) /

› [VEIKK](#) /

› [VEIKK Sketchpad Pro Graphic Tablet User Manual](#)

VEIKK Sketchpad Pro

VEIKK Sketchpad Pro Graphic Tablet User Manual

Model: Sketchpad Pro



1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your VEIKK Sketchpad Pro Graphic Tablet. Please read this manual thoroughly before using the device to ensure optimal performance and longevity.



Figure 1: VEIKK Sketchpad Pro Graphic Tablet and Stylus.

2. PACKAGE CONTENTS

Verify that all items are present in the package:

- VEIKK Sketchpad Pro Graphic Tablet
- Stylus
- USB Cable (for connection)
- Quick Start Guide (may be included)

Note: Additional accessories may be sold separately.

3. SETUP INSTRUCTIONS

3.1 System Requirements

- **Operating System:** Windows 7 or later, macOS 10.12 or later, Android 6.0 or later.
- **Connectivity:** USB port.

3.2 Driver Installation (for Windows/macOS)

1. **Disconnect the Tablet:** Ensure the VEIKK Sketchpad Pro is not connected to your computer.
2. **Download Drivers:** Visit the official VEIKK website (e.g., www.veikk.com) and download the latest drivers for your specific operating system and model.
3. **Install Drivers:** Run the downloaded installer and follow the on-screen instructions. It is recommended to close all other applications during installation.
4. **Restart Computer:** After installation, restart your computer if prompted.
5. **Connect Tablet:** Connect the VEIKK Sketchpad Pro to your computer using the provided USB cable. The system should automatically recognize the device.



Figure 2: The VEIKK Sketchpad Pro features a battery-free passive pen with 8192 levels of pressure sensitivity, 5080 LPI resolution, and a 250 PPS data report rate. The pen allows switching between pen and eraser functions and includes a right-click button.

3.3 Android Device Connection

For Android devices (Android 6.0 or later), the tablet can be connected using an OTG connector (not included). Ensure your Android device supports OTG functionality.

1. Connect the VEIKK Sketchpad Pro to the OTG connector.

2. Connect the OTG connector to your Android device.

3. The tablet should be recognized automatically.

Choose the way you prefer to work



Android Devices Supported

Android 6.0 or later

**It can be easily connected with
the OTG Connector.**



Laptop & Desktop Computer Supported:

Mac OS 10.12 or later

Win7 or later

Figure 3: The VEIKK Sketchpad Pro supports connection to both Android devices (via OTG connector) and desktop/laptop computers (Windows 7+ and macOS 10.12+).

4. OPERATING INSTRUCTIONS

4.1 Using the Stylus

- The stylus is battery-free and does not require charging.
- It features 8192 levels of pressure sensitivity for precise control.
- The buttons on the stylus can be customized via the driver software to switch between pen/eraser or perform other functions (e.g., right-click).
- Hover the stylus over the tablet surface without touching to move the cursor.
- Tap the stylus on the tablet surface to click or draw.

4.2 Customizing Settings

After driver installation, you can access the VEIKK driver panel from your computer's system tray or applications folder. Here you can:

- Adjust pressure sensitivity.
- Customize stylus button functions.
- Map the tablet's active area to your screen.
- Configure for left-handed or right-handed use.



Figure 4: The VEIKK Sketchpad Pro can be configured to accommodate both left-handed and right-handed users, allowing for comfortable drawing habits.

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the tablet surface and stylus. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the tablet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Stylus Nibs:** Regularly check the stylus nib for wear. Replace worn nibs with new ones provided with the tablet or purchased separately to maintain optimal drawing performance.

- **Cable Care:** Avoid bending or twisting the USB cable excessively to prevent damage.

6. TROUBLESHOOTING

6.1 No Cursor Movement

- Ensure the USB cable is securely connected to both the tablet and the computer.
- Verify that the drivers are correctly installed. Reinstall if necessary.
- Try connecting the tablet to a different USB port.
- Restart your computer.

6.2 Pressure Sensitivity Not Working

- Confirm that the drivers are installed and running.
- Check the pressure settings in the VEIKK driver panel.
- Ensure the application you are using supports pressure sensitivity.
- Test with a different drawing application.

6.3 Stylus Buttons Not Responding

- Check the button assignments in the VEIKK driver panel.
- Ensure the stylus is within the active area of the tablet.

7. SPECIFICATIONS

Feature	Detail
Brand	VEIKK
Model Series	Sketchpad Pro
Connectivity Technology	USB
Pressure Sensitivity	8192 Levels
Resolution	5080 LPI
Data Report Rate	250 PPS
Operating System Support	Windows 7+, macOS 10.12+, Android 6.0+
Item Weight	11.3 ounces (approx. 320g)
Product Dimensions (LxWxH)	9.06 x 6.69 x 1.18 inches (approx. 230 x 170 x 30 mm)
Color	Black
Special Feature	Portable, Battery-Free Passive Pen




Figure 5: Physical dimensions of the VEIKK Sketchpad Pro, highlighting its compact size and thin profile.



Figure 6: The ultra-thin and slim design of the VEIKK Sketchpad Pro makes it highly portable for on-the-go use.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

For specific warranty details, please refer to the warranty card included with your product or visit the official VEIKK

website. Warranty terms typically cover manufacturing defects for a specified period from the date of purchase.

8.2 Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact VEIKK customer support through their official website:

- **Website:** www.veikk.com/support (example link, actual link may vary)
- Refer to the product packaging or official website for the most current contact information.

© 2023 VEIKK. All rights reserved.

Related Documents - Sketchpad Pro

 VEIKK A15Pro Graphic Pen Tablet User Manual BATTERY-FREE PEN TABLET www.veikk.com	<p>VEIKK A15Pro Graphic Pen Tablet User Manual</p> <p>Comprehensive user manual for the VEIKK A15Pro Graphic Pen Tablet, covering setup, installation, driver settings, safety precautions, and specifications for digital artists.</p>
 VEIKK A30 Graphic Pen Tablet User Manual BATTERY-FREE PEN TABLET www.veikk.com	<p>VEIKK A30 Graphic Pen Tablet User Manual</p> <p>User manual for the VEIKK A30 Battery-Free Pen Tablet, covering product overview, packing list, driver installation, tablet connection, nib replacement, specifications, driver settings, and FAQs.</p>
 VEIKK A15 Graphic Pen Tablet User Manual BATTERY-FREE PEN TABLET www.veikk.com	<p>VEIKK A15 Graphic Pen Tablet User Manual</p> <p>User manual for the VEIKK A15 Battery-Free Pen Tablet, covering safety precautions, product overview, packing list, driver installation, tablet connection, nib replacement, specifications, driver settings, and frequently asked questions.</p>
 VEIKK A30 BATTERY-FREE PEN TABLET Quick Start Guide www.veikk.com	<p>VEIKK A30 Battery-Free Pen Tablet: Quick Start Guide and Specifications</p> <p>A comprehensive guide to setting up and using the VEIKK A30 battery-free pen tablet, including product overview, packing list, driver installation, connection instructions for PC and Android, nib replacement, and technical specifications.</p>

 <p>VEIKK User Manual VK1200 PEN DISPLAY www.veikk.com</p>	<p><u>VEIKK VK1200 Pen Display User Manual</u></p> <p>User manual for the VEIKK VK1200 Pen Display, covering product overview, specifications, driver installation, and settings.</p>
 <p>VEIKK VK1200 User Manual English manual • Uživatelský návod • Manual del usuario • Benutzershandbuch</p>	<p><u>VEIKK VK1200 User Manual</u></p> <p>Comprehensive user manual for the VEIKK VK1200 Pen Display, covering setup, driver installation, and usage for Windows and Mac systems. Includes product overview, specifications, and troubleshooting.</p>