

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Audibax](#) /

› [Audibax Neo 30 Professional Speaker Wall Mount User Manual](#)

Audibax Neo 30

Audibax Neo 30 Professional Speaker Wall Mount User Manual

Model: Neo 30 | Brand: Audibax

INTRODUCTION

Thank you for choosing the Audibax Neo 30 Professional Speaker Wall Mount. This manual provides essential information for the safe and correct installation, operation, and maintenance of your speaker mount. Please read these instructions carefully before installation and keep them for future reference.

The Audibax Neo 30 is designed to securely hold professional speakers with a 35mm socket, offering adjustable positioning for optimal sound projection. Its robust metal construction ensures durability and stability for speakers up to 35 kg.

SAFETY INFORMATION

- **Weight Limit:** Do not exceed the maximum weight capacity of 35 kg (77 lbs). Overloading can cause instability and potential injury or damage.
- **Wall Type:** Ensure the wall structure is capable of supporting the combined weight of the mount and the speaker. Consult a professional if unsure.
- **Installation:** Always use appropriate tools and follow all installation steps precisely. Improper installation can lead to product failure.
- **Secure Fasteners:** Ensure all screws and bolts are tightened securely before mounting the speaker.
- **Regular Checks:** Periodically inspect the mount and fasteners for any signs of wear, loosening, or damage.

PACKAGE CONTENTS

Please check that all components are present before beginning installation:

- Audibax Neo 30 Speaker Wall Mount (main assembly)
- Mounting hardware (screws, wall anchors - specific types may vary based on region and wall material)
- User Manual



Image: Audibax Neo 30 speaker wall mount components.

SETUP INSTRUCTIONS

Tools Required (Not Included):

- Drill
- Drill bits appropriate for wall material and anchors
- Level
- Pencil
- Screwdriver (Phillips or flathead, depending on screws)
- Measuring tape

Installation Steps:

1. **Choose Location:** Select a suitable wall location, ensuring it can support the weight and allows for desired speaker positioning. Avoid electrical wires or plumbing within the wall.
2. **Mark Drilling Points:** Hold the wall plate of the mount against the wall at the desired height. Use a level to ensure it is straight. Mark the drilling points through the holes on the wall plate with a pencil.
3. **Drill Holes:** Drill pilot holes at the marked points. The size of the drill bit should match the wall anchors provided or recommended for your wall type.
4. **Insert Wall Anchors:** Insert the appropriate wall anchors into the drilled holes. For concrete or brick, use expansion anchors. For wood studs, screws can be driven directly.

5. **Attach Wall Plate:** Align the wall plate with the anchors and secure it to the wall using the provided screws. Tighten all screws firmly.
6. **Assemble Mount (if necessary):** If the mount comes in multiple pieces, assemble them according to the diagrams, ensuring all pivot points and locking mechanisms are correctly aligned and secured.
7. **Mount Speaker:** Carefully lift your speaker and slide its 35mm socket onto the pole of the wall mount. Ensure the speaker is fully seated and stable.
8. **Secure Speaker:** Use any locking pins or knobs on the mount to secure the speaker in place, preventing accidental dislodgement.



Image: Speaker mounted on the Audibax Neo 30 wall mount.

OPERATING INSTRUCTIONS (ADJUSTMENTS)

The Audibax Neo 30 mount allows for flexible positioning of your speaker to achieve optimal sound direction.

1. **Adjusting Tilt:** Loosen the tilt adjustment knob or bolt on the mount. Carefully tilt the speaker to the desired vertical angle. Once positioned, tighten the knob/bolt securely to lock the tilt.
2. **Adjusting Swivel/Pan:** Loosen the swivel adjustment knob or bolt. Rotate the speaker horizontally to the desired direction. Tighten the knob/bolt firmly to lock the swivel.
3. **Securing the Speaker:** After making all adjustments, double-check that all locking mechanisms (knobs, bolts, pins) are fully tightened to ensure the speaker is stable and secure.



Image: Arrows indicating adjustable movement of the mount.



Image: Close-up of the adjustment knob.

MAINTENANCE

- **Cleaning:** Wipe the mount with a soft, dry cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Periodic Inspection:** Regularly check all mounting screws and adjustment knobs to ensure they remain tight. Inspect the mount for any signs of corrosion, bending, or stress.
- **Lubrication:** Moving parts generally do not require lubrication. If any joint becomes stiff, consult Audibax support before applying any lubricants.

TROUBLESHOOTING

Issue: Speaker feels unstable or wobbly.

- **Solution 1:** Ensure the speaker's 35mm socket is fully seated on the mount's pole.
- **Solution 2:** Check all adjustment knobs and bolts. Tighten any that are loose.
- **Solution 3:** Verify that the wall mounting screws are securely fastened to the wall. If the wall anchors are failing, consider using stronger anchors or relocating the mount to a more secure part of the wall.
- **Solution 4:** Confirm the speaker's weight does not exceed the 35 kg limit.

Issue: Difficulty adjusting the mount.

- **Solution 1:** Ensure the relevant adjustment knob or bolt is sufficiently loosened before attempting to move the mount.

- **Solution 2:** Do not force adjustments. If a part is stuck, inspect for obstructions or damage.

SPECIFICATIONS

Feature	Specification
Model Number	10176026
Item Weight	2.43 kg
Product Dimensions (L x W x H)	43 x 23 x 7 cm
Material	Alloy Steel
Mounting Type	Wall Mount
Weight Limit	35 kg
Compatible Devices	Speaker (with 35mm socket)
Color	Black/White
Special Features	Universal, Adjustable
Country of Origin	China

WARRANTY AND SUPPORT

Audibax products are manufactured to high-quality standards. For information regarding warranty terms and conditions, please refer to the documentation included with your purchase or visit the official Audibax website. If you encounter any issues or have questions not covered in this manual, please contact Audibax customer support for assistance. Contact details can typically be found on the product packaging or the official Audibax website.