

V-Guard Victo Insta Lite 3 Litre

V-Guard Victo Insta Lite 3 Litre Instant Water Heater User Manual

MODEL: VICTO INSTA LITE 3 LITRE

Introduction

This manual provides essential information for the safe and efficient operation, installation, and maintenance of your V-Guard Victo Insta Lite 3 Litre Instant Water Heater. Please read these instructions carefully before using the appliance and retain them for future reference.

Safety Instructions

To ensure safe operation and prevent injury or damage, always adhere to the following safety guidelines:

- Ensure the water heater is installed by a qualified technician.
- Do not operate the appliance if the power cord or plug is damaged.
- Do not attempt to repair the water heater yourself. Contact authorized service personnel.
- Ensure the electrical supply matches the specifications of the appliance.
- Keep flammable materials away from the water heater.
- Always disconnect power before performing any maintenance or cleaning.
- This appliance is equipped with a four-layered safety mechanism including a Snap Action Thermostat and Thermal Cut-off for enhanced protection.

Product Overview

The V-Guard Victo Insta Lite is a 3-litre instant water heater designed for quick hot water delivery. It features a durable stainless steel inner tank and a rust-proof engineered polymer outer body. An LED indicator displays the operational status.



Image: Front view of the V-Guard Victo Insta Lite 3 Litre Instant Water Heater in Ivory, showcasing its compact design and LED indicator.

Setup and Installation

Installation of the V-Guard Victo Insta Lite water heater requires plumbing and electrical connections. For safety and optimal performance, it is strongly recommended that installation be performed by a qualified and authorized service technician.

- **Location:** Choose a suitable location near the point of use, ensuring adequate space for maintenance and ventilation.
- **Mounting:** Securely mount the water heater to a sturdy wall using appropriate fasteners.
- **Water Connections:** Connect the inlet and outlet water pipes according to the markings on the unit. Ensure all connections are watertight.
- **Electrical Connection:** Connect the appliance to a dedicated electrical circuit with proper grounding, matching the voltage and wattage requirements.
- **Initial Fill:** Before switching on the power, ensure the water heater is completely filled with water by opening a hot water tap until water flows freely.

Note: V-Guard offers PAN India installation services (chargeable). Please contact customer support for assistance.

Operating Instructions

Follow these steps to operate your instant water heater:

1. Ensure the water heater is properly installed and filled with water.
2. Switch on the main power supply to the water heater.
3. The LED indicator on the unit will illuminate, indicating that the heater is active and heating water.
4. Hot water will be available almost instantly from the hot water tap.
5. After use, switch off the power supply to the water heater.

Maintenance

Regular maintenance helps ensure the longevity and efficiency of your water heater. Always disconnect the power supply before performing any maintenance.

- **Cleaning:** Wipe the outer body with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Descaling:** In areas with hard water, mineral deposits can accumulate. It is recommended to have the heating element descaled periodically by a qualified technician to maintain efficiency.
- **Inspection:** Periodically check for any signs of leaks or damage to the pipes and connections.

Troubleshooting

If you encounter issues with your water heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No hot water	No power supply; Thermal cut-off activated; Faulty heating element.	Check power switch and circuit breaker; Contact service technician.
Water not hot enough	Low water pressure; Mineral buildup on heating element.	Check water supply; Contact service technician for descaling.
Water leakage	Loose connections; Damaged tank or pipes.	Tighten connections; Contact service technician immediately.

If the problem persists after attempting these solutions, please contact V-Guard customer support. Do not attempt to repair the unit yourself.

Specifications

- **Type:** Instant Water Geyser
- **Capacity:** 3 Litres
- **Wattage:** 3000 Watts
- **Pressure:** 6.5 Bar (Maximum working pressure)
- **Inner Tank Material:** Stainless Steel
- **Outer Body Material:** Rust-Proof High Quality Engineering Polymer
- **Insulation:** CFC free PUF (Polyurethane Foam) for Maximum Heat Retention
- **Heating Element:** Copper
- **Safety:** Four Layered Safety Mechanism (Snap Action Thermostat, Thermal Cut-off)
- **Display:** LED Indicator
- **Certification:** ISI
- **Color:** Ivory

Warranty

Your V-Guard Victo Insta Lite water heater comes with the following warranty:

- **Product:** 1 Year
- **Heating Element:** 1 Year
- **Inner Tank:** 5 Years

Please retain your purchase invoice for warranty claims. The warranty is subject to terms and conditions.

Customer Support

For installation services, technical assistance, or warranty claims, please contact V-Guard customer support:

- **Toll-Free:** 1800-103-1300
- **Toll:** 1860-180-3000

V-Guard offers PAN India service.