

Southern Enterprises FR9314

Southern Enterprises Electric Corner Fireplace

MODEL: FR9314 - USER MANUAL

Introduction

This manual provides essential instructions for the safe setup, operation, and maintenance of your Southern Enterprises FR9314 48-inch Ivory and Black Modern Style Triangular Electric Corner Fireplace. Please read all instructions carefully before assembly and use to ensure proper function and safety.

The FR9314 is an electric fireplace designed for corner placement, featuring media storage cabinets and a central electric firebox. It provides supplemental heat for areas up to 400 square feet and includes realistic flame effects that can be operated independently of the heating function.

Safety Information

- Always connect the fireplace to a properly grounded outlet.
- Do not operate the fireplace with a damaged cord or plug.
- Keep combustible materials at least 3 feet (0.9 meters) away from the front of the fireplace.
- Never block the air vents of the fireplace.
- Do not immerse the fireplace in water or other liquids.
- Unplug the fireplace before performing any maintenance or cleaning.

Setup

This electric fireplace is designed for freestanding, corner installation. Ensure the chosen location has a stable, level surface and is near a standard wall outlet.

Assembly

Refer to the separate assembly instructions included with your product for detailed steps on putting together the fireplace mantel and integrating the electric firebox. Ensure all components are securely fastened before proceeding.

Placement

Position the fireplace in a corner of the room, ensuring adequate clearance from walls and other furniture for proper air circulation and safety. The unit requires a standard wall outlet; no additional electrical equipment is necessary.



Image: The FR9314 electric corner fireplace positioned in a living room, demonstrating its corner-fit design and integration with home decor.

Operating Instructions

The FR9314 electric fireplace offers both realistic flame effects and supplemental heating. Control is available via a touch screen panel on the firebox or the included remote control.

Powering On/Off

- Press the power button on the touch screen panel or remote control to turn the unit on or off.

Flame Effect

- The realistic flame and ember effects can be activated independently of the heating function. This allows for year-round enjoyment of the ambiance without additional heat.
- Adjust flame brightness or speed using the dedicated buttons on the control panel or remote.

Heating Function

- To activate the supplemental heat, press the heater button on the control panel or remote. The unit provides heat for rooms up to 400 square feet.
- Adjust the desired temperature setting using the temperature control buttons.
- The fireplace utilizes long-life, energy-efficient LED bulbs for both flame effects and heating indicators.



Image: A detailed view of the electric firebox, showcasing the realistic flame effect and the integrated touch screen control panel.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your electric fireplace. Always unplug the unit from the power outlet before cleaning or performing any maintenance.

Cleaning the Exterior

- Wipe the exterior surfaces (Poplar, engineered wood, metal) with a soft, damp cloth. Avoid abrasive cleaners or solvents that may damage the finish.
- For glass panels, use a standard glass cleaner applied to a cloth, then wipe the glass. Do not spray cleaner directly onto the glass near electrical components.

Cleaning the Air Vents

- Periodically use a vacuum cleaner with a brush attachment to remove dust and debris from the air intake and exhaust vents. This helps maintain efficient heating and prevents overheating.

Light Bulb Replacement

- The fireplace uses long-life LED bulbs. If replacement is ever needed, refer to the specific instructions in the assembly guide or contact customer support for guidance.

Troubleshooting

If you encounter issues with your electric fireplace, consult the following common troubleshooting steps:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check your home's circuit breaker or fuse box.
- **No Heat:** Verify that the heater function is activated via the control panel or remote. Ensure the temperature setting is higher than the ambient room temperature. Check for any obstructions in the air vents.
- **Flame Effect Not Working:** Confirm the flame effect is turned on. If the unit has power but no flame, there might be an issue with the LED components; contact customer support.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace's receiver.
- **Unusual Noises:** A slight fan noise is normal during heating operation. If you hear loud or unusual noises, turn off and unplug the unit immediately and contact customer support.

For issues not resolved by these steps, please contact Southern Enterprises customer support.

Specifications

Detailed technical specifications for the Southern Enterprises FR9314 Electric Corner Fireplace:

- **Model Name:** Southern Enterprises 48" Ivory and Black Modern Style Triangular Electric Corner Fireplace
- **Model Number:** FR9314
- **Brand:** Southern Enterprises
- **Product Dimensions:** 48" W x 15.75" D x 32.25" H (121.9 cm W x 40 cm D x 81.9 cm H)
- **Item Weight:** 126 lbs (57.15 kg)
- **Weight Capacity:** Supports up to 85 lbs (38.56 kg)
- **Materials:** Poplar, Engineered Wood, 4mm Tempered Glass, Metal, Resin
- **Finish Type:** Ivory
- **Color:** Black (firebox components)
- **Power Source:** Corded Electric
- **Installation Type:** Freestanding
- **Heat Output:** 5100 British Thermal Units (BTU)
- **Heating Coverage:** Up to 400 square feet
- **Ventilation Type:** Vent Free
- **Special Feature:** Flame Effect (operates with or without heat)
- **Burner Type:** Quartz

• **UPC:** 037732113142



Image: A diagram illustrating the dimensions of the FR9314 electric corner fireplace, showing its width, depth, and height.

Warranty and Support

For warranty information, please refer to the documentation included with your purchase or visit the official Southern Enterprises website. For technical support, replacement parts, or further assistance, please contact Southern Enterprises customer service directly.

Please have your model number (FR9314) and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question