

Tribit BTS31

Tribit StormBox Pro Portable Bluetooth Speaker User Manual

Model: BTS31 | Brand: Tribit

INTRODUCTION

The Tribit StormBox Pro is a high-fidelity portable Bluetooth speaker designed for robust audio performance and outdoor durability. It features 360° sound, enhanced XBass technology, and a long-lasting battery, making it suitable for various environments. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your speaker.

WHAT'S IN THE BOX

- Portable Bluetooth Speaker
- User Manual
- Charging Cable

PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your Tribit StormBox Pro speaker.





Figure 1: Front view of the Tribit StormBox Pro speaker, highlighting its portable design and top control panel.

FULLY WATERPROOF

From getting dunked in a pool to getting soaked in a storm, StormBox Pro is fully protected by its IP67-rated waterproof fabric



Figure 2: Close-up of the top control panel, showing the power button, volume controls, Bluetooth pairing button, and XBass button.

Body-Shaking **XBass**[®]

Our exclusive Xbass[®] technology
instantly intensifies
the bass




Figure 3: Side view illustrating the rubberized cover protecting the charging and auxiliary ports.

Your browser does not support the video tag.

Video 1: Official product video demonstrating the Tribit StormBox Pro's features, including its 360° sound, XBass technology, and waterproof design.

SETUP

Charging the Speaker

Before first use, fully charge your Tribit StormBox Pro. Connect the provided USB-C charging cable to the speaker's input port and a compatible power source. The LED indicators on the top panel will show charging progress. A full charge provides up to 24 hours of playtime.

Body-Shaking **XBass**[®]

Our exclusive Xbass[®] technology instantly intensifies the bass




Figure 4: The USB-C input port for charging the speaker.

Bluetooth Pairing

1. Power on the speaker by pressing and holding the power button until the indicator lights illuminate.
2. The Bluetooth indicator light will flash blue, indicating it's in pairing mode.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "Tribit StormBox Pro" in the list of available devices.
4. Select the speaker to connect. Once connected, the Bluetooth indicator light will turn solid blue.

The speaker supports Bluetooth 5.3 for stable and high-quality wireless connection. It also features multi-point functionality, allowing two devices to be connected simultaneously.

OPERATING INSTRUCTIONS

Basic Controls

- **Power On/Off:** Press and hold the power button.

- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Play/Pause:** Press the 'O' (circle) button.
- **Next Track:** Double-press the 'O' button.
- **Previous Track:** Triple-press the 'O' button.

XBass Technology

Activate the enhanced XBass mode by pressing the 'XBass' button on the top panel. This intensifies bass frequencies for a richer audio experience. Press again to deactivate.



Figure 5: The XBass button is located on the top control panel for easy access.

Wireless Stereo Pairing (TWS)

For an immersive stereo experience, you can pair two Tribit StormBox Pro speakers together. Note: Due to chip upgrades, the latest version of StormBox Pro cannot be stereo paired with previous versions.

1. Ensure both speakers are powered on and not connected to any other Bluetooth devices.

2. On one speaker, press and hold the Bluetooth button for 5 seconds until you hear a prompt. Repeat on the second speaker.
3. The speakers will automatically connect to each other. Once paired, connect your device to one of the speakers via Bluetooth.

Your browser does not support the video tag.

Video 2: Demonstration of the wireless stereo pairing feature, showing two StormBox Pro speakers connecting for a wider soundstage.

FEATURES

High Fidelity 360° Audio Quality

The StormBox Pro delivers a full, 360° sound experience with dual-passive radiators that convert vibrations into acoustic output, ensuring no dead zones. It features multiple drivers for clear highs, rich mids, and deep bass.



Figure 6: Internal diagram illustrating the transducer, dual-passive radiators, and 3-inch neodymium subwoofer contributing to the 360° sound.

Extreme Battery Life

Equipped with a powerful 2*5,000mAh battery, the speaker offers up to 24 hours of continuous listening time, ensuring your music lasts all day and night.



EXTENDED PLAYTIME

A massive battery
fuels up to **24 hours**
of non-stop music to keep
the party going 'til dawn

*The battery life data is sourced from TRIBIT laboratory
under normal temperature conditions - at 60% volume, with
XBass off. Actual battery life may vary depending on volume
level, music content, and usage habits.

Figure 7: The speaker's ability to charge other devices, emphasizing its extended battery life.

IP67 Waterproof and Dustproof

The StormBox Pro is IP67 rated, meaning it is fully protected against dust ingress and can withstand submersion in water up to 1 meter for 30 minutes. This makes it ideal for outdoor use, including beach or pool environments.

FULLY WATERPROOF

From getting dunked in a pool to getting soaked in a storm, StormBox Pro is fully protected by its IP67-rated waterproof fabric



Figure 8: The speaker being splashed with water, showcasing its IP67 waterproof rating.

Incredibly Portable

With its flexible handle, the StormBox Pro is easy to carry wherever you go, making it a perfect companion for any adventure.

TOTALLY TOTE-ABLE



Figure 9: A person carrying the speaker by its handle, emphasizing its portability.

MAINTENANCE

- **Cleaning:** Use a soft, damp cloth to wipe the speaker's surface. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Exposure:** While waterproof, ensure the charging port cover is securely closed before exposing the speaker to water. After water exposure, dry the speaker thoroughly before charging.
- **Dust/Sand:** The fabric is dustproof, but it's recommended to gently brush off any accumulated dust or sand to maintain appearance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Speaker won't turn on	Low battery.	Charge the speaker fully.
Cannot pair with device	Speaker not in pairing mode; device Bluetooth off; speaker already connected to another device.	Ensure speaker is in pairing mode (flashing blue light). Turn on device Bluetooth. Disconnect speaker from other devices.
No sound	Volume too low; device not connected; audio source paused.	Increase speaker/device volume. Reconnect Bluetooth. Check audio source playback.
Poor sound quality	Device too far; interference; low battery.	Move device closer. Avoid obstacles. Charge speaker.
Cannot stereo pair	Speakers are different versions; one speaker already paired.	Ensure speakers are the same version (check model number). Disconnect speakers from other devices before TWS pairing.

SPECIFICATIONS

Feature	Detail
Model Name	StormBox Pro
Item Model Number	BTS31
Brand	Tribit
Connectivity Technology	Bluetooth 5.3, Wireless
Speaker Maximum Output Power	40 Watts
Battery Life	24 Hours
Water Resistance Level	IP67 (Waterproof & Dustproof)
Product Dimensions	9.6"D x 18"W x 9.6"H
Item Weight	2.57 pounds
Special Features	XBass, 360 Sound, Waterproof, Stereo Pairing
Included Components	Charging Cable, Portable Bluetooth Speaker, User Manual

WARRANTY AND SUPPORT

Tribit products come with a standard warranty. For detailed warranty information, technical support, or any inquiries, please visit the official Tribit website or contact their customer service. You can often find support contact information in the product packaging or on the brand's Amazon store page.

For questions, click "Your Account" -> "Your Order" -> "Tribit" on Amazon and contact customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B08MZZTH1N>

More documents and user manuals: <https://manuals.plus/>