

[Manuals.plus](#) /

› [TTY Store](#) /

› TTY Store 4 Wheels Pet Stroller Instruction Manual

TTY Store B08N12J9PJ

TTY Store 4 Wheels Pet Stroller Instruction Manual

Model: B08N12J9PJ

INTRODUCTION

Thank you for choosing the TTY Store 4 Wheels Pet Stroller. This manual provides essential information for the safe assembly, operation, and maintenance of your pet stroller. Please read these instructions carefully before use and retain them for future reference.

This pet stroller is designed to provide a comfortable and secure way to transport your small to medium-sized pets, such as dogs and cats, weighing up to 25 pounds. It features a lightweight, foldable design, durable wheels, and convenient storage options.

SAFETY INFORMATION

- Always ensure your pet is securely fastened inside the stroller using a harness or leash attached to the internal safety clip (if available).
- Do not exceed the maximum weight capacity of 25 pounds (11.3 kg).
- Engage the rear brakes when the stroller is stationary to prevent accidental movement.
- Never leave your pet unattended in the stroller, especially on inclines or near traffic.
- Keep fingers and hands clear of moving parts, especially during folding and unfolding.
- Regularly inspect the stroller for any signs of wear, damage, or loose parts. Do not use if damaged.
- Avoid using the stroller on rough terrain or steep slopes that could compromise stability.

PACKAGE CONTENTS

Please verify that all components are present before assembly:

- Pet Stroller Frame with main compartment
- 4 Wheels (2 front swivel, 2 rear with brake)
- Removable Liner/Pad
- Storage Basket (pre-attached or separate)
- Cup Holders/Center Tray (pre-attached or separate)

SETUP AND ASSEMBLY

1. **Unfolding the Stroller:** Place the folded stroller on a flat surface. Release any locking mechanisms. Gently pull the handle upwards and spread the frame until it locks into the open position. Ensure all frame joints are securely engaged.
2. **Attaching the Wheels:** Insert the front swivel wheels into their designated slots on the front legs until they click into place. Attach the rear wheels to the rear axle, ensuring the brake mechanism is correctly aligned. Pull on each wheel to confirm it is securely attached.
3. **Installing the Removable Liner:** Place the soft, removable pad inside the main pet compartment for comfort.
4. **Attaching Cup Holders/Storage Basket:** If not pre-attached, secure the cup holders to the handle and the storage basket to the lower frame according to the design.

Collapsible and lightweight



Figure 1: The pet stroller shown in its open configuration and then folded for compact storage. This demonstrates the collapsible and lightweight design for easy transport and storage.



Figure 2: Detailed view of key features: the 360-degree swivel front wheel for maneuverability, the convenient cup holder on the handle, the comfortable soft handle grip, and the rear brake system for secure parking.

OPERATING INSTRUCTIONS

1. **Placing Your Pet:** Open the zippered entrance of the main compartment. Gently place your pet inside. Ensure they have enough space and are comfortable. Close the zippers securely.
2. **Securing Your Pet:** If your pet wears a harness or collar, attach it to the internal safety leash provided within the stroller compartment. This prevents your pet from jumping out.
3. **Using the Brakes:** To engage the rear brakes, press down on the brake levers located near the rear wheels. To release, lift the levers. Always engage the brakes when the stroller is stationary.
4. **Maneuvering:** The front wheels are designed to swivel 360 degrees for easy navigation. For stability on uneven terrain, you may lock the front swivel wheels by pushing down the locking mechanism on each front wheel assembly.
5. **Using Storage:** Utilize the cup holders for beverages and the lower storage basket for pet essentials, personal

items, or groceries.

6. **Folding for Storage:** To fold the stroller, ensure your pet is removed. Locate the folding mechanism (usually a latch or button near the handle or side frame). Follow the reverse steps of unfolding to collapse the stroller into a compact size. Secure with any locking clips.



Figure 3: A close-up image highlighting the durable #8 fiber zippers used on the pet compartment, designed for longevity and security.




Figure 4: The spacious storage basket positioned beneath the main pet compartment, offering convenient space for carrying pet supplies or personal items.

MAINTENANCE

- **Cleaning the Fabric:** The stroller features waterproof material. For minor spills or dirt, wipe clean with a damp cloth and mild soap. Air dry completely before folding or storing.
- **Cleaning the Removable Pad:** The internal pad can be removed for cleaning. Hand wash with mild detergent and air dry. Do not bleach or tumble dry.
- **Wheel Maintenance:** Periodically check the wheels for debris (hair, dirt) and remove them. Lubricate axles if wheels become stiff.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight when not in use.

Waterproof Material



Breathable Mesh Window



Storage Basket



Removeable Cleaning Pad



Figure 5: Features contributing to ease of maintenance: the waterproof exterior material, breathable mesh windows for ventilation, the under-stroller storage basket, and the removable cleaning pad for hygiene.

TROUBLESHOOTING

- **Stroller does not fold/unfold smoothly:** Ensure all locking mechanisms are disengaged before folding. Check for any obstructions in the frame joints. Apply a small amount of silicone lubricant to moving parts if necessary.
- **Wheels are stiff or squeaky:** Remove any hair or debris from the wheel axles. Apply a silicone-based lubricant to the axle points.
- **Zippers are difficult to operate:** Ensure the fabric is not caught in the zipper teeth. Apply a zipper lubricant or rub a pencil lead along the teeth to smooth operation.
- **Stroller feels unstable:** Verify that all wheels are securely attached and the frame is fully locked into the open position. Avoid overloading the stroller beyond its weight capacity.

SPECIFICATIONS

Feature	Detail
Product Dimensions (L x W x H)	34" x 17.5" x 39" (86.36 cm x 44.45 cm x 99.06 cm)
Folded Size	32" x 17" x 11" (81.28 cm x 43.18 cm x 27.94 cm)
Item Weight	11 Pounds (5 kg)
Maximum Weight Recommendation	25 Pounds (11.3 kg)
Number of Wheels	4 (Front: 360-degree swivel; Rear: with brake)
Material	Plastic frame, Mesh fabric, Waterproof material
Included Components	Cup Holders, Center Tray, Storage Basket
Color	Purple (as per current model)
ASIN	B08N12J9PJ
UPC	840137933549

Suitable for a variety of pets

0-33 lbs



Figure 6: An overview of the pet stroller, illustrating its dimensions (34"L x 17.5"W x 39"H) and suitability for a variety of pets weighing up to 33 lbs (note: product specifications state 25 lbs max weight).

WARRANTY INFORMATION

For detailed warranty information, please refer to the manufacturer's official website or contact customer support directly. Warranty terms and conditions may vary.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need troubleshooting support, please contact TTY Store customer service. Refer to the product packaging or the retailer's website for the most current contact information.

Online Support: Visit the TTY Store brand page on Amazon: [TTY Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question