

[manuals.plus](#) /› [Fusion5](#) /› [Fusion5 10" Windows 10 FWIN232 PRO S2 Ultra Slim Full HD Windows Tablet PC User Manual](#)

Fusion5 FWIN232PROS2

Fusion5 FWIN232 PRO S2 Tablet PC User Manual

Model: FWIN232PROS2 | Brand: Fusion5

1. INTRODUCTION

This user manual provides comprehensive instructions for the Fusion5 FWIN232 PRO S2 Ultra Slim Full HD Windows Tablet PC. Please read this manual carefully before using your device to ensure proper operation and to maximize its lifespan. Keep this manual for future reference.

Safety Information

- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the original charger and accessories provided by Fusion5.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Keep the device away from water and other liquids.

2. PACKAGE CONTENTS

Please check the box for the following items:

- Fusion5 FWIN232 PRO S2 Tablet PC
- Power Adapter (12V)
- USB-C to USB-A Adapter
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the physical features and ports of your Fusion5 FWIN232 PRO S2 tablet.



This image shows the front of the Fusion5 FWIN232 PRO S2 tablet, highlighting its 10.1-inch Full HD IPS display.



This image provides an angled view of the tablet's rear, detailing the placement of ports such as HDMI, USB, and the DC charging input, along with product information.

Key Components:

- **10.1-inch Full HD IPS Display:** High-resolution screen for clear visuals.
- **Front Camera (2MP):** Located above the screen, suitable for video calls.
- **Rear Camera (2MP):** Located on the back, for capturing photos and videos.
- **Power Button:** On the top edge, used to power on/off or put the device to sleep.
- **Volume Buttons:** On the top edge, to adjust audio volume.
- **USB-C Port:** Multi-functional port for charging and data transfer.
- **USB-A Port:** Standard USB port for connecting peripherals.
- **Micro-SD Card Slot:** For expanding storage capacity.
- **Mini-HDMI Port:** For connecting to external displays.
- **Headphone Jack:** For audio output.
- **DC Charging Port:** Dedicated port for power input.
- **Speakers:** Integrated for audio output.

4. SETUP

Initial Charging

Before first use, fully charge your tablet. Connect the provided power adapter to the DC charging port or the USB-C port on the tablet and plug it into a power outlet. The charging indicator light will illuminate. The tablet features FusionCharge FastCharge, allowing it to charge to 80% in approximately 45-50 minutes and 100% in 70-80 minutes.

First Power On and Windows Setup

1. Press and hold the Power button until the Fusion5 logo appears.
2. Follow the on-screen prompts to complete the Windows 10 Professional setup process. This includes selecting your region, language, and setting up your user account.
3. It is recommended to connect to a Wi-Fi network during setup to allow for initial Windows updates.

Connecting to Wi-Fi

- Go to **Settings > Network & Internet > Wi-Fi**.
- Turn on Wi-Fi and select your desired network from the list.
- Enter the network password if prompted and click **Connect**.

5. OPERATING YOUR TABLET

Basic Navigation

- **Touchscreen:** Navigate the interface by tapping, swiping, pinching, and zooming.
- **Optional Keyboard/Mouse:** For enhanced productivity, you can connect a compatible Bluetooth keyboard and mouse or use the provided USB-C to USB-A adapter for wired peripherals.

Using the Cameras

The tablet is equipped with 2MP front and rear cameras. To use them:

- Open the **Camera** application from the Start Menu.
- Switch between front and rear cameras as needed.
- Tap the screen to focus and press the shutter button to capture photos or start/stop video recording.

Connecting Peripherals

- **Bluetooth:** Go to **Settings > Devices > Bluetooth & other devices** to pair Bluetooth headphones, speakers, keyboards, or mice.
- **USB Devices:** Insert USB drives or other USB peripherals into the USB-A port or via the USB-C to USB-A adapter.
- **HDMI Output:** Connect a Mini-HDMI cable from the tablet's Mini-HDMI port to an external monitor or TV for extended display.

6. MAINTENANCE

Cleaning Your Tablet

- Use a soft, lint-free cloth to clean the screen and body of the tablet.
- For stubborn smudges, slightly dampen the cloth with water or a screen-cleaning solution.
- Avoid using harsh chemicals or abrasive materials.

Software Updates

Regularly check for and install Windows updates to ensure your tablet has the latest features, security patches, and performance improvements.

- Go to **Settings > Update & Security > Windows Update**.
- Click **Check for updates** and install any available updates.

Storage Management

To maintain optimal performance, manage your tablet's 128GB storage:

- Regularly delete unnecessary files and uninstall unused applications.
- Utilize cloud storage services for large files.
- Consider adding a Micro-SD card for additional storage.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your tablet.

Slow Performance / Lagging

- **Solution:** Close unnecessary applications running in the background. Check for and install Windows updates. Ensure sufficient free storage space. Restart the tablet.

Touchscreen Inaccuracy

- **Solution:** Ensure the screen is clean and free of debris. If a screen protector is installed, ensure it is properly applied without bubbles. For precise tasks, consider using an external mouse.

Battery Drains Quickly

- **Solution:** Reduce screen brightness. Close background apps. Disable Wi-Fi or Bluetooth when not in use. Adjust power settings in Windows to optimize battery life.

Tablet Not Charging

- **Solution:** Ensure the power adapter is securely connected to both the tablet and the power outlet. Use only the original 12V power adapter provided. Try a different power outlet. Inspect the charging ports for any damage or debris.

8. SPECIFICATIONS

Feature	Specification
Standing screen display size	10.1 Inches
Screen Resolution	1920 X 1200 (Full HD IPS)
Processor	Intel N3450 Quad-core (2.2 GHz)
RAM	6 GB DDR4_SDRAM
Hard Drive	128 GB

Operating System	Windows 10 Professional
Item Weight	1.3 pounds
Rear Webcam Resolution	2 MP
Color	Black
Batteries	1 Lithium Polymer battery (included)

9. WARRANTY AND SUPPORT

Warranty Information

The Fusion5 FWIN232 PRO S2 Tablet PC comes with a **12-month USA warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and malfunctions under normal use conditions.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Fusion5 customer support through their official website or the retailer where the product was purchased. Provide your model number and a detailed description of the issue for efficient service.