

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [KLARSTEIN](#) /

› [Klarstein Delicatessa Slim Domino Induction Cooker \(CP4-Delicatessa-D-WH\) User Manual](#)

## KLARSTEIN CP4-Delicatessa-D-WH

# Klarstein Delicatessa Slim Domino Induction Cooker User Manual

Model: CP4-Delicatessa-D-WH

## INTRODUCTION

This manual provides essential information for the safe and efficient operation of your Klarstein Delicatessa Slim Domino Induction Cooker. Please read all instructions carefully before installation and use, and retain this manual for future reference.

## IMPORTANT SAFETY INFORMATION

To prevent personal injury or property damage, always observe basic safety precautions, including the following:

- Ensure proper installation by a qualified technician.
- Do not operate the appliance if it is damaged.
- Keep children away from the appliance during operation and cooling.
- Use only induction-compatible cookware.
- Avoid placing metallic objects on the cooktop surface.
- Do not clean the cooktop with steam cleaners.
- The appliance features an automatic shut-off, child safety lock, and overheating protection.

Auto shut-off

  
KLARSTEIN

Child safety lock

Overheating  
protection



Figure 1: Safety features of the Klarstein Delicatessa Slim Induction Cooker, including auto shut-off, child safety lock, and overheating protection.

## PRODUCT OVERVIEW

The Klarstein Delicatessa Slim Domino Induction Cooker is a built-in hob designed for efficient and flexible cooking. It features two cooking zones with VarioHeating technology, allowing for combined use of the zones.



Figure 2: Top view of the Klarstein Delicatessa Slim Domino Induction Cooker, highlighting its sleek glass-ceramic surface and control panel.

## Key Features:

- Two cooking zones with a total power of 3500 Watts.
- VarioHeating for combining cooking zones into a flexible area.
- Sensor-touch control panel with digital display.
- ThermoBoost function for rapid heating.
- Timer function up to 99 minutes.
- Pot detection.
- Keep-warm function.
- EcoThermal Control with residual heat display.
- Child safety lock and overheating protection.

**Fits seamlessly**

Elegant glass ceramic hob  
with 2 cooking surfaces

  
**KLARSTEIN**

Figure 3: The Klarstein Delicatessa Slim Induction Cooker seamlessly installed in a modern kitchen setting.

## SETUP AND INSTALLATION

The Klarstein Delicatessa Slim Domino Induction Cooker is designed for drop-in installation. Professional installation is

recommended to ensure correct electrical connection and proper ventilation.

## **Included Components:**

- Built-in electric induction hob
- Mounting material

## **Installation Dimensions:**

- Total dimensions: approximately 29 x 5.5 x 52 cm (W x H x D)
- Installation dimensions: approximately 27 x 5 x 50 cm (W x H x D)
- Cable length: approximately 100 cm


Refer to the detailed installation guide provided with the product for specific cutout dimensions and electrical requirements (220-240 V~ | 50/60 Hz).

## **OPERATING INSTRUCTIONS**

---

### **Control Panel:**

The cooktop is operated via a sensor-touch control panel located at the front. The digital display shows power levels and timer settings.



**SenseControl  
with touch & slide  
function**



**9 power levels**



**Pot detection**



**Keep-warm function**



**Timer up to 99  
minutes**



**KLARSTEIN**

Figure 4: Detailed view of the SenseControl panel, illustrating touch and slide functionality for power adjustment and other features.

### Power Levels and Zones:

- The cooktop has 9 adjustable power levels.
- Two cooking zones: one with 2000 Watt (Boost 2300W) and one with 1500 Watt (Boost 1800W).
- Total power output is 3500 Watts.

Powerful at your fingertips

# 4100W



Touch control with  
ThermoBoost for  
quick heating

Figure 5: Power distribution diagram for the two cooking zones and the combined flex zone.

#### Special Functions:

- **VarioHeating (Flex Zone):** Combine both cooking zones to create a larger flexible cooking area, ideal for larger pots or griddle pans.


# Flexible hobs

VarioHeating for combining two hobs for shared use as a flex zone



Figure 6: VarioHeating in action, allowing for the use of larger cookware across both zones.

- **ThermoBoost:** Activates maximum power for rapid heating. Each zone has an individual boost function (1800W or 2800W).
- **Timer:** Set a cooking duration up to 99 minutes for each zone. The cooktop will automatically switch off when the timer expires.
- **Pot Detection:** The cooktop automatically detects suitable induction-compatible cookware. Operation will not begin without a pot or with an incompatible pot.
- **Keep-Warm Function:** Maintains a low temperature to keep food warm after cooking.
- **EcoThermal Control:** Displays residual heat, allowing you to use the remaining heat to save energy.
- **Stop & Go (ThermalRecall System):** Temporarily pauses cooking and saves the current temperature settings, allowing you to resume cooking without re-entering settings.



ThermalRecall  
System



## STOP & GO

*ThermalRecall function to save the temperature for interruptions in the cooking process*

Figure 7: The Stop & Go function, also known as ThermalRecall System, for pausing and resuming cooking.



## PRECISION COOKING

Power adjustable in 9 steps, programmable  
shut-off timer up to 99 minutes

Figure 8: Precision cooking with 9 power levels and a programmable timer up to 99 minutes.

## MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your induction cooker.

- Always disconnect the appliance from the power supply before cleaning.
- Allow the cooktop to cool completely before cleaning.
- Wipe the glass-ceramic surface with a soft, damp cloth and a mild detergent.
- For stubborn stains, use a specialized ceramic hob cleaner.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals that can damage the surface.
- Do not use steam cleaners.

## TROUBLESHOOTING

If you encounter issues with your induction cooker, refer to the following common troubleshooting tips:

- **Appliance does not turn on:** Check if the appliance is properly connected to the power supply. Ensure the child safety lock is not activated.
- **Cooktop not heating:** Verify that induction-compatible cookware is being used and is correctly placed on the cooking zone.
- **Error codes displayed:** Consult the full user manual for a list of specific error codes and their solutions.
- **Unusual noises:** A slight humming or clicking sound during operation is normal for induction cooktops.

If the problem persists, contact qualified service personnel.

## TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	KLARSTEIN
Model Info	Klarstein Delicatessa
Item Model Number	CP4-Delicatessa-D-WH
Installation Type	Drop-In
Burner Type	Induction
Heating Elements	2
Total Wattage	3500 watts
Voltage	220-240 Volts
Fuel Type	Electric
Material Type	Glass Ceramic
Color	White
Item Weight	10.12 pounds (approx. 4.6 kg)
Product Dimensions (D x W x H)	20.47" x 11.42" x 2.17" (approx. 52 x 29 x 5.5 cm)
Special Features	Automatic Shut-Off, Safety Lock, Timer, Pot Detection, VarioHeating, ThermoBoost, Keep-Warm Function, EcoThermal Control

## WARRANTY AND SUPPORT

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Klarstein website. Keep your purchase receipt as proof of purchase.



## Related Documents - CP4-Delicatessa-D-WH

 <p><b>KLARSTEIN</b> Vstavaná varná doska</p> <p>VARICOOK NEO Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p>VARICOOK NEO Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p><b>KLARSTEIN</b> www.klarstein.com</p>	<p><b>Klarstein Virtuoso 3 Slim: Návod na použitie</b></p> <p>Kompletný návod na použitie pre sklokeramickú varnú dosku Klarstein Virtuoso 3 Slim. Tento manuál obsahuje technické údaje, bezpečnostné pokyny, montážne kroky, prevádzkové informácie a riešenie problémov pre rôzne modely Klarstein.</p>
 <p>VARICOOK NEO Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p>VARICOOK NEO Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p><b>KLARSTEIN</b> www.klarstein.com</p>	<p><b>Klarstein VARICOOK NEO Induction Hob User Manual</b></p> <p>User manual for the Klarstein VARICOOK NEO Induction Hob, detailing features, operation, safety instructions, and technical specifications. Learn how to use and maintain your induction hob for optimal cooking performance.</p>
 <p>VARICOOK SINGLE Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p>VARICOOK SINGLE Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p><b>KLARSTEIN</b> www.klarstein.com</p>	<p><b>VARICOOK SINGLE Induktionskochfeld Bedienungsanleitung</b></p> <p>Umfassende Bedienungsanleitung für das Klarstein VARICOOK SINGLE Induktionskochfeld (Modell 10012195), inklusive Installations-, Bedienungs-, Sicherheits- und Wartungshinweisen.</p>
 <p>VARICOOK SLIM Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p>VARICOOK SLIM Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p><b>KLARSTEIN</b> www.klarstein.com</p>	<p><b>Klarstein VARICOOK SLIM Induction Hob User Manual</b></p> <p>Comprehensive user manual for the Klarstein VARICOOK SLIM induction hob, covering installation, operation, safety, and maintenance. Learn how to use your induction hob efficiently and safely.</p>
 <p>VARICOOK DUO Kochfeld Placa de cocción Placa de cocción Панель котлов</p> <p>VARICOOK DUO Kochfeld Placa de cocción Placa de cocción Панель котлов</p> <p><b>KLARSTEIN</b> www.klarstein.com</p>	<p><b>Klarstein VariCook Duo Infrared Double Hob - User Manual and Safety Information</b></p> <p>User manual, safety instructions, operation guide, and technical specifications for the Klarstein VariCook Duo infrared double hob (models 10032124, 10032125). Learn how to safely operate, clean, and maintain your cooktop.</p>
 <p>VARICOOK NEO Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p>VARICOOK NEO Induktionskochfeld Induction Hob Table de cuisson à induction Placa de cocción a inducción Панель котлов с индукцией</p> <p><b>KLARSTEIN</b> www.klarstein.com</p>	<p><b>Klarstein Varicook Neo Induction Hob User Manual</b></p> <p>User manual for the Klarstein Varicook Neo induction hob, providing safety instructions, operating guidelines, technical specifications, and troubleshooting tips.</p>

