

[Manuals.plus](#) /

› [RYGHT](#) /

› RYGHT Nemesis + TrueWireless Headphones with Touchscreen and Automatic Connection Housing with Induction Charger (Induction Charger Included) - White User Manual

RYGHT R483836

RYGHT Nemesis + TrueWireless Headphones User Manual

Model: R483836

INTRODUCTION

The RYGHT Nemesis + TrueWireless Headphones are designed to provide a high-quality audio experience with advanced features such as automatic connection, touch control, and induction charging. This manual will guide you through the setup, operation, and maintenance of your new headphones.



Image: A person wearing the white RYGHT Nemesis+ earbuds, demonstrating their in-ear fit and discreet design.



Image: A graphic illustrating key features of the RYGHT Nemesis+ headphones, including powerful sound, 4.5 hours + 22 hours playtime, automatic pairing, stereo sound, touch controls, voice assistant, and wireless charging.

WHAT'S IN THE BOX

Please check the contents of your package to ensure all items are present:

- RYGHT Nemesis + TrueWireless Headphones (earbuds)
- Charging Case with Induction Charger
- Instruction Manual



Image: RYGHT Nemesis+ TrueWireless Headphones, including the earbuds and their charging case, placed on a circular induction charging pad. The earbuds are shown both inside and outside the case.

SETUP

Initial Charging

Before first use, fully charge your RYGHT Nemesis + headphones and charging case. The case supports induction charging.

1. Place the charging case on a compatible induction charging pad.
2. Alternatively, connect a USB-C cable to the charging port on the case and a power source.
3. The indicator lights on the case will show charging status. Ensure the earbuds are inside the case for them to charge simultaneously.



Image: The white RYGHT Nemesis+ charging case is shown connected to a USB-C cable for charging, while also resting on a circular induction charging pad, indicating dual charging capability.

Automatic Connection and Pairing

The Nemesis + headphones feature automatic connection for seamless pairing with your devices.

1. Ensure Bluetooth is enabled on your smartphone or tablet.
2. Open the lid of the RYGHT Nemesis + charging case. The headphones will automatically enter pairing mode or reconnect to the last paired device.
3. If pairing for the first time, select "RYGHT Nemesis +" from your device's Bluetooth settings.
4. Once connected, a confirmation sound will play through the headphones.



Image: The white RYGHT Nemesis+ charging case is shown open, revealing the two white earbuds securely seated inside their respective charging slots.

OPERATING INSTRUCTIONS

Touch Control

The Nemesis + earbuds feature intuitive touch controls for managing calls and music playback.

- **Play/Pause:** Single tap on either earbud.

- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call or active call.
- **Reject Call:** Press and hold on either earbud during an incoming call.



Image: A detailed close-up view of a single white RYGH T Nemesis+ earbud, highlighting its design and the touch-sensitive area.

Voice Assistant

Activate your smartphone's voice assistant directly from your Nemesis + headphones.

- **Activate Voice Assistant:** Triple tap on either earbud.
- Once activated, you can issue commands such as "Call [Contact Name]", "Play [Song Title]", or "What's the weather?".

Battery Life

The Nemesis + headphones offer up to 4 hours of playback on a single charge, with an additional 22 hours provided by the charging case, totaling 26 hours of working time.

- **Earbud Battery:** Up to 4 hours.
- **Charging Case Recharges:** Provides 5 full charges for the earbuds.
- **Total Playtime:** Up to 26 hours with the charging case.

MAINTENANCE

Proper maintenance ensures the longevity and optimal performance of your headphones.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them and keep them charged.
- **Avoid Moisture:** Keep the headphones and case away from water and excessive moisture.
- **Temperature:** Avoid exposing the device to extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Headphones not connecting/pairing.	Bluetooth is off on device; headphones not in pairing mode; interference.	1. Ensure Bluetooth is enabled on your device. 2. Place earbuds back in the case, close the lid, then open it again to re-enter pairing mode. 3. Forget "RYGHT Nemesis +" from your device's Bluetooth list and re-pair. 4. Move closer to your device and away from other wireless devices.
No sound from one or both earbuds.	Low battery; improper connection; volume too low.	1. Charge the headphones and case fully. 2. Reconnect the headphones to your device. 3. Adjust volume on both your device and via headphone touch controls.
Charging case not charging.	Improper placement on induction pad; faulty cable/power source.	1. Ensure the case is centered on the induction charging pad. 2. Try a different USB-C cable and power adapter. 3. Ensure the power source is active.

SPECIFICATIONS

Brand	RYGHT
Model Number	R483836
Product Dimensions	14 x 17 x 25 cm (Product); 52 x 58 x 22 mm (Case)

Item Weight	45 g
Colour	White
Connectivity Technology	Wireless (Bluetooth)
Compatible Devices	Smartphones, Tablets
Material Type	Plastic
Battery Life (Earbuds)	Up to 4 hours
Total Playtime (with Case)	Up to 26 hours
Charging	Induction Charging, USB-C




Image: A technical diagram illustrating the precise dimensions in millimeters and inches for both the RYGH T Nemesis+ earbuds and their charging case, alongside a key for scale.

WARRANTY AND SUPPORT

RYGHT products are designed for reliability and performance. For warranty information and technical support, please refer to the warranty card included with your product or visit the official RYGHT website.

For further assistance, you may contact RYGHT customer service through their official channels.

© 2024 RYGHT. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question