

[Manuals.plus](#) /

› [Sun Joe](#) /

› Sun Joe XTREAM Electric Pressure Washer SPX3000-XT1 User Manual

Sun Joe SPX3000-XT1

Sun Joe XTREAM Electric Pressure Washer SPX3000-XT1 User Manual

Model: SPX3000-XT1 | Brand: Sun Joe

INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Sun Joe XTREAM Electric Pressure Washer. Designed for home, outdoor, and auto cleaning, this powerful 14.9-amp motor delivers up to 2200 PSI and 1.1 GPM, making it suitable for a variety of cleaning tasks.



Figure 1: Sun Joe XTREAM Electric Pressure Washer and Included Accessories

IMPORTANT SAFETY INFORMATION

Please read and understand all safety warnings and instructions before operating the pressure washer. Failure to follow these instructions may result in electric shock, fire, and/or serious injury.

- This appliance is not intended for use by children or by unassisted, unsupervised persons whose physical, sensory or mental capabilities prevent them from using it safely. Children should be supervised to ensure that they do not play with the appliance.
- Before starting up your machine, please check it carefully for any defects.
- Exercise caution to avoid slipping or falling. Wear protective footwear that will protect your feet and improve your

footing on slippery surfaces.

- Do not direct discharge stream at persons.
- Keep proper footing and balance at all times.
- Do not carry a plugged in machine with your finger on the trigger.
- Make sure the switch is off before plugging in the machine.
- Never carry the machine by the cord or yank the cord to disconnect it from the receptacle. Keep the cord away from heat, oil, and sharp edges.

SETUP

1. Assembly

The assembly process for the Sun Joe XTREAM Electric Pressure Washer is straightforward. Ensure all components are present and undamaged before beginning.

2. Water Connection

- Connect your garden hose to the pressure washer's water inlet. Ensure a secure connection to prevent leaks.
- Attach the high-pressure hose to the pressure washer's outlet and to the spray gun.
- Turn on the water supply and allow water to flow through the system until all air is purged from the hoses and spray gun. This prevents air pockets from damaging the pump.

3. Power Connection

- Ensure the pressure washer's power switch is in the "OFF" position.
- Plug the 35-foot GFCI power cord into a suitable electrical outlet. The GFCI light should illuminate.

4. Attaching Accessories

The unit comes with various accessories for different cleaning needs.

YOU NAME IT. YOU AIM IT. GRIME IS GONE.®


SUNJOE

4 Quick-Connect Spray Nozzles

Ensure reliable and consistent outcomes with powerful and precise functionality.



Figure 2: Onboard Accessories and Storage

- **Quick-Connect Spray Tips:** Select the appropriate spray tip for your task and securely attach it to the quick-connect lance. The unit includes 4 Quick-Connect spray tips (0°, 15°, 25°, 40°).



Figure 3: Quick-Connect Spray Nozzles and Patterns

- **Foam Cannon:** Fill the onboard 33.8 FL OZ foam cannon with your desired cleaning solution. Attach it to the spray gun for Xtreme Triple-Action Power (foaming, cleaning, rinsing).

YOU NAME IT. YOU AIM IT. GRIME IS GONE.®

ONBOARD ACCESSORIES



✓ Utility Bristle Brush

Perfect for windows, patio furniture, autos, boats and BBQs

✓ Wheel + Rim Brush

Brings out the sparkle and shine in wheels, rims and tires

✓ Transfer Adapter

✓ 20-FT Steel-Reinforced High Pressure Hose

✓ Quick-Connect Lance

✓ Instant Start Squeeze Trigger

✓ 35-FT GFCI Protected Power Cord



Figure 4: Using the Xtreme Triple-Action Foam Cannon

- **Brushes:** Utilize the Utility Bristle Brush for windows, patio furniture, autos, boats, and BBQs, or the Wheel + Rim Brush for wheels, rims, and tires.

OPERATING INSTRUCTIONS

- Once all connections are secure and water is flowing, turn the pressure washer's power switch to the "ON" position. The pump will run briefly to build pressure and then shut off.
- Squeeze the trigger on the spray gun to begin spraying. The Total Stop System (TSS) automatically shuts off the pump when the trigger isn't engaged, prolonging pump life and saving energy.
- Adjust the spray pattern by changing the Quick-Connect spray tips as needed for different cleaning tasks.
- For applying detergent, ensure the foam cannon is filled and attached. The detergent will be dispensed when the appropriate setting or nozzle is selected (refer to specific foam cannon instructions if different from standard tips).

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your pressure washer.

- **After Each Use:** Detach all hoses and the spray gun. Drain all water from the hoses and the unit to prevent mineral buildup and freezing damage.
- **Nozzle Cleaning:** Use the provided needle clean-out tool to clear any blockages from the spray tips.
- **Winterization:** If storing in freezing temperatures, ensure the unit is completely drained of water or use a pump protector/antifreeze solution as per manufacturer guidelines to prevent internal damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Low pressure or pump "racing"	Insufficient water supply or restricted water flow.	Check the garden hose for kinks or blockages. Ensure the water faucet is fully open and providing adequate pressure. Avoid using multiple hoses or restrictive valves that can reduce water flow.
Unit does not start	Power cord not properly plugged in, GFCI tripped, or power switch off.	Ensure the GFCI plug is reset and properly connected. Check the power switch is in the "ON" position. Verify the electrical outlet is functional.
Water leaking from connections	Loose connections or damaged O-rings.	Tighten all hose and gun connections. Inspect O-rings for wear or damage and replace if necessary.

SPECIFICATIONS

Brand: Sun Joe

Model: SPX3000-XT1

Power Source: Corded Electric

Maximum Pressure: 2200 PSI (PWMA Certified)

Maximum Flow Rate: 1.1 GPM (1.65 Gallons Per Minute)

Motor: 14.9 Amp

Hose Length: 20 Feet (High-Pressure Hose)

Power Cord Length: 35 Feet (GFCI Protected)

Item Weight: 28.4 Pounds

Product Dimensions: 16"L x 14"W x 34"H

Tank Volume: 1.65 Gallons (Detergent Tank)

Included Accessories: 34-inch extension wand, 4 Quick-Connect spray tips, Foam Cannon, Wheel & Bristle Brushes, Needle Clean-Out Tool, Garden Hose Adapter.

Safety Features: Total Stop System (TSS)

Certifications: CSA, PWMA

WARRANTY

For detailed warranty information, please refer to the official product documentation included with your purchase or contact Sun Joe customer support. Protection plans may also be available for extended coverage.

SUPPORT

For further assistance, technical support, or to access the complete user manual, please visit the official Sun Joe website or refer to the PDF manual provided:

[Official User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question