

- Manuals.plus /
- > [Supersonic](#) /
 - > Supersonic SC-531KBM Ultra Slim Wireless Keyboard with Wireless Mouse Instruction Manual

Supersonic SC-531KBM

Supersonic SC-531KBM Ultra Slim Wireless Keyboard with Wireless Mouse

Instruction Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Supersonic SC-531KBM Ultra Slim Wireless Keyboard with Wireless Mouse. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.



Angled view of the Supersonic SC-531KBM Ultra Slim Wireless Keyboard, showcasing its sleek profile and key layout.

Important Legal Notice: This product contains chemicals known to the State of California to cause cancer and birth defects or

other reproductive harm.

PACKAGE CONTENTS

Carefully unpack your new wireless keyboard and mouse combo. Ensure all items listed below are present:

- 1 x Supersonic Ultra Slim Wireless Keyboard
- 1 x Supersonic Wireless Mouse
- 1 x USB 2.4G Wireless Receiver (often stored inside the mouse battery compartment)



Image showing the wireless mouse and the compact USB 2.4G wireless receiver. The receiver enables wireless communication between

SETUP

1. Installing Batteries

The keyboard and mouse require batteries for operation. Please use new batteries for best performance.

Keyboard:

1. Locate the battery compartment on the underside of the keyboard.
2. Open the battery compartment cover.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover.

Mouse:

1. Locate the battery compartment on the underside of the mouse.
2. Open the battery compartment cover. The USB wireless receiver may be stored here. Remove it if present.
3. Insert 2 AAA batteries, ensuring correct polarity (+/-).
4. Close the battery compartment cover.

2. Connecting the Devices

Your wireless keyboard and mouse connect to your computer via a single USB 2.4G wireless receiver.

1. Plug the USB 2.4G wireless receiver into an available USB port on your computer.
2. Your computer should automatically detect and install the necessary drivers. This may take a few moments.
3. Once installed, the keyboard and mouse are ready for use.



Top-down view of the Supersonic Ultra Slim Wireless Keyboard, illustrating its layout and compact design. This image helps users identify the keyboard for setup.

OPERATION

Keyboard Functions

The keyboard features a standard QWERTY layout with 78 keys, including function keys and multimedia controls.

- **Function Keys (F1-F12):** These keys often have secondary functions (e.g., volume control, media playback, brightness adjustment) accessible by pressing the 'Fn' key simultaneously. Refer to your operating system's documentation for specific key assignments.
- **Auto Sleep:** To conserve battery life, the keyboard will enter an automatic sleep mode after a period of inactivity. Press any key to wake it up.

Mouse Functions

The wireless mouse provides precise cursor control with 1200 DPI sensitivity.

- **Left/Right Click:** Standard mouse button functions.
- **Scroll Wheel:** For vertical scrolling.
- **DPI:** The mouse operates at 1200 DPI for accurate tracking.
- **Auto Sleep:** Similar to the keyboard, the mouse will enter an automatic sleep mode to save battery. Move the mouse or click a button to wake it.



Angled view of the Supersonic Ultra Slim Wireless Keyboard and Wireless Mouse together, demonstrating their compact size and matching silver finish. This image shows the complete combo in use.

MAINTENANCE

Proper care ensures the longevity of your wireless keyboard and mouse.

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the keyboard and mouse. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Battery Care:** Replace batteries when the low battery indicator appears. Remove batteries if the devices will not be used.

for an extended period to prevent leakage.

- **Storage:** Store the devices in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

If you encounter issues with your wireless keyboard and mouse, please refer to the following common solutions:

- **Devices not responding:**
 - Ensure batteries are correctly installed and not depleted. Replace if necessary.
 - Check that the USB wireless receiver is securely plugged into a working USB port.
 - Try plugging the receiver into a different USB port.
- **Lagging or intermittent connection:**
 - Ensure the devices are within the 33-foot operating range of the receiver.
 - Remove any large metal objects or other wireless devices that might cause interference between the keyboard/mouse and the receiver.
- **Keyboard typing incorrect characters:**
 - Check your computer's language and keyboard layout settings.
- **Mouse cursor erratic or not moving:**
 - Clean the optical sensor on the underside of the mouse.
 - Ensure you are using the mouse on a suitable surface (not highly reflective or transparent).

SPECIFICATIONS

Feature	Detail
Brand	Supersonic
Model Number	SC-531KBM
Connectivity	2.4G Wireless (USB Receiver)
Operating Range	Up to 33 feet (10 meters)
Keyboard Layout	QWERTY, 78 Keys
Mouse DPI	1200 DPI
Power Source	Keyboard: 2 x AAA Batteries; Mouse: 2 x AAA Batteries (Batteries not included)
Compatible OS	Android, Windows 7/8/10, Mac OS 10.3 or above
Special Features	Auto Sleep Function, Ergonomic Design (15° keyboard tilt), Low Battery Indicator
Color	Silver
Approx. Weight	1.6 ounces (for the combo, exact distribution not specified)

WARRANTY AND SUPPORT

Warranty Information: This product comes with a manufacturer's warranty. Please refer to the warranty card included in your package or visit the official Supersonic website for detailed warranty terms and conditions.

Customer Support: For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact Supersonic customer support. Contact information can typically be found on the official Supersonic website or on your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question